




<u>Detail</u>





Note — Dovetail clamping is not required, but can be utilized for more secure clamping as needed

Clamping Guidelines



Vise Operation and Maintenance


- 1. Keep lead screw well lubricated with Copper based Anti-Seize lubricant
- 2. Keep the lead screw clean and free of chips and other debris. Use a soft wire or nylon brush to clean the screw regularly
- 3. Do NOT over torque. Stay below the maximum torque marked on vise. Excess torque may result in damage not covered under warranty
- 4. Never use power tools to operate the vise
- 5. Never strike the vise handle with a mallet
- 6. If machining soft jaws, clamp a spacer block between the jaws at the desired operating torque for maximum precision and repeatability
- 7. If the vise will not be used for an extended period of time, clean thoroughly and liberally apply rust inhibitor to all surfaces


HAAS AUTOMATION, INC.


05-0004 A	ssembly	
PN	Description	Qty
05-0004	HSCV-5-05	1
	Red and Black Colored Ratchet Wrench	1
	Jaws:	
05-0051	Jaws	1 PR
	Clamping:	
05-0106	Toe Clamps	2
05-0092	Stud Bolt	2
05-0094	Flange Nut	2
05-0096	T-Slot Nuts	2
	Ways Fasteners:	
05-0101	SHCS	2
05-0096	T-nuts	2
	Locating Kit:	
05-0093	Dowel Pin	2
05-0100	SHCS	2
05-0099	BHCS	2
05-0095	Alignment Key: 16mm	2
	Keyways Set:	
05-0095	Alignment Key: 16mm	2
05-0099	BHCS	2

05-0004 O	ptional A	Accessory	Kits
-----------	-----------	-----------	------

Item:	PN:	Product Name	Description	Qty
1	Jaws:			
	05-0049	HMVJ-5-2.5-A	5" LONG, 2.5" WIDTH, ALUMINUM	1 pr
	05-0050	HMVJ-5-2.5-S	5" LONG, 2.5" WIDTH, STEEL	1 pr
	05-0051	HMV-5-HS	5" LONG, SERRATED HARDENED STEEL	1 pr
2	Riser Kit (05-0098):			
	05-0097	SHCS	M12 X 35MM	4
	05-0096	T-Slot Nut	M12, 16MM	4
	05-0099	BHCS	M6 X 12MM	4
	05-0095	Alignment Key	16MM X 9.9MM X 25MM	4
3	Clamping Kit (05-0042):			
	05-0106	Toe Clamps	12mm	2
	05-0092	Stud Bolt	M12 X 1.75	2
	05-0094	Flange Nut	M12 X 1.75	2
	05-0096	T-Slot Nut	M12, 16MM	2
4	Way Fasteners Kit (05-0074):			
	05-0101	SHCS	M12 X 1.75 X 65MM	2
	05-0096	T-nuts	M12, 16MM	2
5	Locating Kit (05-0075):			
	05-0093	Dowel Pin	10MM X 10MM LONG	2
	05-0100	SHCS	M6 X 1.0 X 16MM	2
	05-0099	BHCS	M6 X 12MM	2
	05-0095	Alignment Key	16MM X 9.9MM X 25MM	2
6	Screw Assembly (05-0076):			
	05-0076	Screw Assembly	RISER KIT HSCV-5-05	1








Re-Centering Vise Jaws

- 1. Check that both Vise Jaws are mounted securely and clean
- 2. Loosen (DO NOT REMOVE) the two center mounting block screws until the assembly can move freely



- 3. Insert (2) 3/4" diameter dowel pins into the vise as shown
- 4. Turn lead screw clockwise to lightly clamp the dowel pins between both jaws
- 5. Tighten the two center mounting block screws until snug, be careful not to over tighten
- 6. Turn lead screw counter-clockwise to unclamp jaws from dowel pins

