

Mill Operator's Manual

JUNE 2002

HAAS AUTOMATION INC. • 2800 STURGIS ROAD • OXNARD, CA 93030 TEL. 888-817-4227 FAX. 805-278-8561 www.HaasCNC.com



HAAS SERVICE AND OPERATOR MANUAL ARCHIVE

VF Series Operators Manual 96-8000 RevE English June 2002

- This content is for illustrative purposes.
- Historic machine Service Manuals are posted here to provide information for Haas machine owners.
- Publications are intended for use only with machines built at the time of original publication.
- As machine designs change the content of these publications can become obsolete.
- You should not do mechanical or electrical machine repairs or service procedures unless you are qualified and knowledgeable about the processes.
- Only authorized personnel with the proper training and certification should do many repair procedures.

WARNING: Some mechanical and electrical service procedures can be extremely dangerous or life-threatening. Know your skill level and abilities.

All information herein is provided as a courtesy for Haas machine owners for reference and illustrative purposes only. Haas Automation cannot be held responsible for repairs you perform. Only those services and repairs that are provided by authorized Haas Factory Outlet distributors are guaranteed.

Only an authorized Haas Factory Outlet distributor should service or repair a Haas machine that is protected by the original factory warranty. Servicing by any other party automatically voids the factory warranty.





Important – This machine is to be operated only by trained personnel in accordance with the Operator's Manual, safety decals, safety procedures and instructions for safe machine operation.



READ BEFORE OPERATING THIS MACHINE:

- Only authorized personnel should work on this machine. Untrained personnel present a hazard to themselves and the machine, and improper operation will void the warranty.
- Use appropriate eye and ear protection while operating the machine. ANSI approved impact safety goggles and OSHA approved ear protection are recommended to reduce the risks of sight damage and hearing loss.
- Do not operate the machine unless the doors are closed and the door interlocks are functioning properly. Rotating cutting tools can cause severe injury. When a program is running, the mill table and spindle head can move rapidly at any time in any direction.
- The Emergency Stop button is the large, circular red switch located on the Control Panel. Pressing the Emergency Stop button will instantly stop all motion of the machine, the servo motors, the tool changer, and the coolant pump. Use the Emergency Stop button only in emergencies to avoid crashing the machine.
- The electrical panel should be closed and the key and latches on the control cabinet should be secured at all times except during installation and service. At those times, only qualified electricians should have access to the panel. When the main circuit breaker is on, there is high voltage throughout the electrical panel (including the circuit boards and logic circuits) and some components operate at high temperatures. Therefore, extreme caution is required. Once the machine is installed, the control cabinet must be locked and the key available only to qualified service personnel.
- Consult your local safety codes and regulations before operating the machine. Contact you dealer anytime safety issues need to be addressed.
- DO NOT modify or alter this equipment in any way. If modifications are necessary, all such requests must be handled by Haas Automation, Inc. Any modification or alteration of any Haas Milling or Turning Center could lead to personal injury and/or mechanical damage and will void your warranty.
- It is the shop owner's responsibility to make sure that everyone who is involved in installing and operating the machine is thoroughly acquainted with the installation, operation, and safety instructions provided with the machine BEFORE they perform any actual work. The ultimate responsibility for safety rests with the shop owner and the individuals who work with the machine.
- This machine can cause bodily injury.
- Do not operate with the door open.
- Do not operate without proper training.
- Always wear safety goggles.
- The machine is automatically controlled and may start at any time.
- The electrical power must meet the specifications in this manual. Attempting to run the machine from any other source can cause severe damage and will void the warranty.
- Do not press POWER UP/RESTART on the control panel until after the installation is complete.
- Do not attempt to operate the machine before all of the installation instructions have been completed.
- Never service the machine with the power connected.
- Improperly clamped parts machine at high feeds/feed may be ejected and puncture the safety door. Machining
 oversized or marginally clamped parts is not safe.
- Windows must be replaced if damaged or severely scratched Replace damaged windows immediately.
- The spindle head can drop without notice. Personnel must avoid the area directly under the spindle head.
- Do not reset a circuit breaker until the reason for the fault is investigated. Only Haas-trained service personnel should troubleshoot and repair the equipment.



Follow these guidelines while performing jobs on the machine:

Normal operation - Keep the door closed and guards in place, while machine is operating. Part loading and unloading – An operator opens the door or guard, completes task, closes door or guard before pressing cycle start (starting automatic motion).

Tool loading or unloading – A machinist enters the machining area to load or unload tools. Exit the area completely before automatic movement is commanded (for example, next tool, ATC/Turret FWD/REV).

Machining job set-up – Press emergency stop before adding or removing machine fixtures.

Maintenance / Machine Cleaner- Press emergency stop or power off the machine before entering enclosure.

Do not enter the machining area anytime the machine is in motion; severe injury or death may result.

Unattended Operation

Fully enclosed Haas CNC machines are designed to operate unattended; however, your machining process may not be safe to operate unmonitored.

As it is the shop owner's responsibility to set up the machines safely and use best practice machining techniques, it is also their responsibility to manage the progress of these methods. The machining process must be monitored to prevent damage if a hazardous condition occurs.

For example, if there is the risk of fire due to the material machined, then an appropriate fire suppression system must be installed to reduce the risk of harm to personnel, equipment and the building. A suitable specialist must be contacted to install monitoring tools before machines are allowed to run unattended.

It is especially important to select monitoring equipment that can immediately perform an appropriate action without human intervention to prevent an accident, should a problem be detected.

MODIFICATIONS TO THE MACHINE

DO NOT modify or alter this equipment in any way. If modifications are necessary, all such requests must be handled by Haas Automation, Inc. Any modification or alteration of any Haas machining center could lead to personal injury and/or mechanical damage and will void your warranty.



SAFETY DECALS

To help ensure that CNC tool dangers are quickly communicated and understood, hazard symbol decals are placed on Haas Machines in locations where hazards exist. If decals become damaged or worn, or if additional decals are needed to emphasize a particular safety point, contact your dealer or the Haas factory.

Never alter or remove any safety decal or symbol.

Each hazard is defined and explained on the general safety decal, located at the front of the machine. Particular locations of hazards are marked with warning symbols. Review and understand the four parts of each safety warning, explained below, and familiarize yourself with the symbols on the following pages.

NEVER OPERATE THIS MACHINE WITH THE DOORS OPEN









LATHE WARNING DECALS DANGER A Automatic Machine may start at any time. Electrocution hazard. Injury or death could be Death by electric shock can 0 caused by untrained operator Read and understand operator's manual and safety signs before using this machine. 召 occur. Turn off and lock out system power before servicing. 1 Risk of serious physical Risk of serious bodily injury. Machine cannot injury. The enclosure may not stop protect from toxins. Coolant mist, fine particles, The enclosure may not stop every type of projectile. Double-check job set up before beginning any machining operations. Always follow safe machining practices. Do not operate with doors or windows open or guards removed. chips, and fumes can be dangerous. Follow specific material manufacturer's material safety data and warnings. Risk of fire and explosion. Risk of bodily injury. Serious cuts, abrasions, and Machine is not designed to resist or contain blasts or fire. Do not machine explosive or physical injury may result from slips and falls. Avoid using the machine in v damp, or poorly lit areas. flammable materials or coolants. Refer to specific material manufacturer's material safety data and warnings. Risk of eye and ear injury. Severe injury can occur. Flying debris into unprotected Moving parts can entangle, eves can cause loss of sight trap, and cut. Sharp tools or chips can cut skin easily. Noise levels can exceed 70 dBA. Ensure the machine is not in automatic operation before reaching Must wear safety glasses and hearing protection when operating or in the area of machine. Safety windows may become brittle and lose effectiveness when exposed to machine coolants and oils over time. If signs of discoloration, crazing, or cracking are found, replace immediately. Safety windows should be replaced every two years WARNING Severe injury can occur. Risk of serious bodily injury Moving parts can entangle and trap. Always secure loose clothing and long hair. and impact hazard. Unsupported bar can whip with deadly results. Do not extend barstock past end of drawtube without adequate support. Risk of serious bodily injury. Do not apply excessive machining Inadequately clamped parts forces, doing so can dislodge the torces, doing so can dislodge the bar from support. Do not allow the carriage or tool to strike the steady rest or tailstock; the part may come loose. Do not over tighten steady rest. can be thrown with deadly force High RPM reduces chuck clamping force. Do not machine using an unsafe setup or exceed rated chuck RPM. · Do not allow untrained personnel to operate this machine. Moving parts can cut. · Restrict access to open frame lathes Sharp tools can cut skin E · Use steady rest or tailstock to support long bars and always easily. Do not handle any part of the follow safe machining practices. Do not after or modify machine in any way. Do not operate this machine with worn or damaged components. machine during automatic operation Do not touch rotating work pieces. Machine must be repaired or serviced by authorized technicians only. NOTICE Clean the filter screen weekly. Remove the coolant tank cover and clean out any sediment inside the tank weekly. Do not use plain water, permanent corrosion damage will result. Rust inhibiting coolant is required. Hanging Do not use toxic or flammable liquids as a coolant. Slot ımn Baske 29-0765 F



OTHER SAFETY DECALS

Other decals may be found on your machine, depending on the model and options installed:





1. MAINTENANCE

1.1 General Requirements

General Requirements

Operating Temperature Range41°F to 104°F (5 to 40°C)Storage Temperature Range-4°F to 158°F (-20 to 70°C)Ambient Humidity: less than 90% relative humidity, non-condensingAltitude: 0-7000 ft.

ELECTRICITY REQUIREMENTS

ALL MACHINES REQUIRE:

AC input power is three phase Delta or Wye power, except that the power source must be grounded (e.g. leg or center leg for delta, neutral for Wye) Frequency range of 47-66 Hz Line voltage that does not fluctuate more than ± 5% Harmonic distortion not to exceed 10% of the total RMS voltage

vollage Requirements	High-Voltage Requirements
(195-260V)	(354-488V)
50 AMP	25 AMP
40 AMP	20 AMP
8 GA. WIRE	12 GA. WIRE
6 GA. WIRE	10 GA. WIRE
Voltage Requirements	High-Voltage Requirements ²
Voltage Requirements T) (195-260V)	High-Voltage Requirements ² (354-488V)
Voltage Requirements T) (195-260V) 100 AMP	High-Voltage Requirements ² (354-488V) 50 AMP
Voltage Requirements T) (195-260V) 100 AMP 80 AMP	High-Voltage Requirements ² (354-488V) 50 AMP 40 AMP
Voltage Requirements T) (195-260V) 100 AMP 80 AMP	High-Voltage Requirements ² (354-488V) 50 AMP 40 AMP
Voltage Requirements T) (195-260V) 100 AMP 80 AMP 4 GA. WIRE	High-Voltage Requirements ² (354-488V) 50 AMP 40 AMP 8 GA. WIRE
Voltage Requirements T) (195-260V) 100 AMP 80 AMP 4 GA. WIRE	High-Voltage Requirements ² (354-488V) 50 AMP 40 AMP 8 GA. WIRE
	(195-260V) 50 AMP 40 AMP 8 GA. WIRE 6 GA. WIRE

WARNING!

A separate earth ground wire of the same conductor size as the input power is required to be connected to the chassis of the machine. This ground wire is required for operator safety and for proper operation. This ground must be supplied from the main plant ground at the service entrance, and should be routed in the same conduit as the input power to the machine. A local cold water pipe or ground rod adjacent to the machine cannot be used for this purpose.

Input power to the machine must be grounded. For wye power, the neutral must be grounded. For delta power, a central leg ground or one leg ground should be used. The machine will not function properly on ungrounded power. (This is not a factor with the External 480V Option.)



The rated horsepower of the machine may not be achieved if the imbalance of the incoming voltage is beyond an acceptable limit. The machine may function properly, yet may not deliver the advertised power. This is noticed more often when using phase converters. A phase converter should only be used if all other methods cannot be used.

The maximum leg-to-leg or leg-to-ground voltage should not exceed 260 volts, or 504 volts for high-voltage machines with the Internal High Voltage Option.

¹The current requirements shown in the table reflect the circuit breaker size internal to the machine. This breaker has an extremely slow trip time. It may be necessary to size the external service breaker up by 20-25%, as indicated by "power supply", for proper operation.

²The high-voltage requirements shown reflect the Internal 400V configuration which is standard on Europeon machines. Domestic and all other users must use the External 480V option.

AIR REQUIREMENTS

The VMC requires a minimum of 100 psi at 4 scfm at the input to the pressure regulator on the back of the machine. This should be supplied by at least a two-horsepower compressor, with a minimum 20-gallon tank, that turns on when the pressure drops to 100 psi.

NOTE: Add 2 scfm to the above minimum air requirements if the operator will be using the air nozzle during pneumatic operations.

Machine Type	Main Air Regulator	Input Air line Hose Size
VF-1 through VF-11 (40 taper)	85 psi	3/8" I.D.
VF-5 through VF-11 (50 taper)	85 psi	1/2" I.D.

The recommended method of attaching the air hose is to the barb fitting at the back of the machine with a hose clamp. If a quick coupler is desired, use a 3/8" for 40 taper machines, or a 1/2" for 50 taper machines and machines with the side mount tool changer option.

- **NOTE:** Excessive oil and water in the air supply will cause the machine to malfunction. The air filter/regulator has an automatic bowl dump that should be empty before starting the machine. This must be checked for proper operation monthly. Also, excessive contaminants in the air line may clog the dump valve and cause oil and/or water to pass into the machine.
- **NOTE:** The nipple between the air filter/regulator and the oil lubricator (See illustration in "Air Connection" section) reservoir tank below the control box on the back of the machine is for the optional rotary table. DO NOT use this as a connection for an auxiliary air line. Auxiliary connections should be made on the left side of the air filter/regulator.

WARNING!

When the machine is operating and the pressure gauge (on the machine regulator) drops by more than 10 psi during tool changes, insufficient air is being supplied to the machine.

1.2 MAINTENANCE SCHEDULE

The following is a list of required regular maintenance for the HAAS VF Series Vertical Machining Centers. Listed are the frequency of service, capacities, and type of fluids required. These required specifications must be followed in order to keep your machine in good working order and protect your warranty.

INTERVAL	MAINTENANCE PERFORMED
DAILY	 ✓ Check coolant level each eight-hour shift (especially during heavy TSC usage). ✓ Check way lube lubrication tank level. ✓ Clean chips from way covers and bottom pan. ✓ Clean chips from tool changer. ✓ Wipe spindle taper with a clean cloth rag and apply light oil.
WEEKLY	 Check Through the Spindle Coolant (TSC) filters. Clean or replace element if needed. Check for proper operation of auto drain on filter regulator. On machines with the TSC option, clean the chip basket on the coolant tank. Remove the tank cover and remove any sediment inside the tank. Be careful to disconnect the coolant pump from the controller and POWER OFF the control before working on the coolant tank. Do this MONTHLY for machines without the TSC option. Check air gauge/regulator for 85 psi. For 15K-spindle machines, check spindle air pressure regulator for 20 psi. For machines with the TSC option, place a dab of grease on the V-flange of tools. Do this MONTHLY for machines without the TSC option. Clean exterior surfaces with mild cleaner. DO NOT use solvents. Check the hydraulic counterbalance pressure according to the machine's specifications.
MONTHLY	 ✓ Check oil level in gear box. For 40 taper spindles: Remove inspection cover beneath spindle head. Add oil slowly from top until oil begins dripping from overflow tube at bottom of sump tank. See section 1.4. For 50 taper spindles: Check oil level in sightglass. Add from side of gearbox if necessary. See section 1.5. ✓ Inspect way covers for proper operation and lubricate with light oil, if necessary. ✓ Place a dab of grease on the outside edge of the guide rails of the tool changer and run through all tools.
SIX MONTHS	 ✓ Replace coolant and thoroughly clean the coolant tank. ✓ Check all hoses and lubrication lines for cracking.
ANNUALLY	 Replace the gearbox oil. Drain the oil from the bottom of the gearbox. Remove inspection cover beneath spindle head. Add oil slowly from top until oil begins dripping from overflow tube at bottom of sump tank. For 50 taper spindles, add oil from the side of the transmission. Check oil filter and clean out residue at bottom of filter. Replace air filter on control box every 2 years.1.1 TSC Maintenance Check SMTC oil level in sight glass, (see Side Mount Tool Changer Oil Level in this section).



1.3 TSC MAINTENANCE

- Check the dirt indicator on the 100-micron mesh filter with the TSC system running and no tool in the spindle. Change the element when the indicator reaches the red zone.
- On newer machines, clean the pump intake filter when indicator is in the red zone. Reset indicator with button. All intake filters can be cleaned with a wire brush.
- After changing or cleaning filter elements, run TSC system with no tool in spindle for at least one minute to prime system.



TSC coolant pump assembly.



Cleaning the intake filter.



To clean the filter: Turn off the coolant pump. Remove the filter. Clean and reinstall filter.



1.4 LUBRICATION CHART

		-	-
SYSTEM	WAY LUBE AND PNEUMATICS	TRANSMISSION	COOLANT TANK
LOCATION	Under the control panel at the rear of the machine	Above the spindle head	Side of machine
DESCRIPTION	Piston pump with 30 minute cycle time. Pump is only on when spindle is turning or when axis is moving.		
LUBRICATES	Linear guides, ball nuts and spindle	Transmission only	
QUANTITY	2-2.5 qts. depending on pump style	40 taper 34 oz 50 taper 51 oz	40 Gallons 80 Gallons VF 6-11
LUBRICANT	Mobil Vactra #2	Mobil DTE 25	Water based coolant only * No Flammable Liquids.

* Mineral cutting oils will damage rubber components throughout the machine.

WARNING!

The TSC pump is a precision gear pump and will wear out faster and lose pressure if abrasive particles are present in the coolant.

Use of coolants with extremely low lubricity can damage the TSC Coolant tip and pump.

When machining castings, sand from the casting process and the abrasive properties of cast aluminum and cast iron will shorten pump life unless a special filter is used in addition to the 100-micron mesh suction filter. Contact Haas Automation for recommendations.

Machining of ceramics and the like voids all warranty claims for wear and is done entirely at the customer's risk. Increased maintenance schedules are absolutely required with abrasive swarf. The coolant must be changed more often, and the tank thoroughly cleaned of sediment on the bottom. A larger coolant tank is recommended.

Shortened pump life, reduction of pressure and increased maintenance are normal and to be expected in abrasive environments and are not covered by warranty.

6



1.5 LUBRICATION SYSTEM

All machine lubrication is supplied by the external lubrication system. The reservoir is located on the lower rear of the machine (see figure below). Current lube level is visible in the reservoir. If additional lube needs to be added, remove the cap from the fill port and add lube to the proper level.



External Lubrication System

WARNING!

DO NOT ADD LUBE ABOVE THE "HIGH" LINE MARKED ON THE RESERVOIR. DO NOT ALLOW THE LUBE LEVEL TO GO BELOW THE "LOW" LINE MARKED ON THE RESERVOIR AS MACHINE DAMAGE COULD RESULT.

To lubricate the system, pull up on the primer pull-tab located next to the fill port. The primer will automatically send 3 cc of lube through the system.

1.6 VF-1 through 6/40T - Transmission Oil

There is no visible indicator for the level of transmission oil in the VF 1-6/40T models.

To add transmission oil, remove the access panel located directly behind the spindle head. This will expose the Transmission Oil Overflow Pipe. Place a container on the table, beneath this outlet. Manually jog the Z axis to its full -Z travel. Power down the machine. Locate the Transmission Oil Fill Cup, accessed from the top of the motor housing (see figure below). There is a cut-out provided in the top of the motor housing sheetmetal for filling. Slowly pour in Mobil DTE 25 oil until oil starts to come out of the overflow pipe. This overflow indicates your transmission oil reservoir is full. Close the Transmission Oil Fill Cup. Wipe off the overflow pipe and replace the access cover. Consider any overflow oil to be used and dispose of properly.



VF 1-6/40T Transmission Oil Fill Cup



1.7 VF-6 THROUGH 11 50T - TRANSMISSION OIL

CAUTION! Power down the machine before performing any maintenance tasks.

The VF 6 through 11 50T machines provide a means to check the transmission oil level. The transmission oil level eye is located behind an access panel secured to the right side of the spindle housing (as viewed from the front; see figure below). To visually check the oil level, remove the 6 BHCS securing the access panel to the spindle housing sheetmetal. Remove the access panel. The transmission oil level eye will be visible. The oil level should reach the middle of the eye.



VF 6 through 11 50T Oil Level

If additional oil is necessary, remove the fill port plug located just to the left of the eye. Add Mobil DTE 25 oil until the proper level is reached. Replace the fill port bolt and tighten. Securely reattach the access panel.

1.8 CHIP AUGER

MAINTENANCE

During normal operation, most chips are discharged from the machine at the discharge tube. However, very small chips may flow through the drain and collect in the coolant tank strainer. To prevent drain blockage, clean this trap regularly. Should the drain become clogged and cause coolant to collect in the machine's pan, stop the machine, loosen the chips blocking the drain, and allow the coolant to drain. Empty the coolant tank strainer, then resume operation.

8

1.9 SIDE MOUNT TOOL CHANGER OIL LEVEL CHECK



The SMTC is factory filled with the appropriate level of oil and does not need to be changed under normal conditions. As a precaution, check the oil level annually. Oil will not need to be added as long as the level remains viewable in the sight glass as shown above. Should the level drop below the sight glass, call the HAAS service department.

1.10 Periodic Maintenance

A periodic maintenance page has been added to the control, it is found on the Current Commands screens titled SCHEDULED MAINTENANCE and accessed by pressing PAGE UP or PAGE DOWN which allows the operator to activate and deactivate a series of checks (see list below).

An item on the list can be selected by pressing the up and down arrow keys. The selected item is then activated or deactivated by pressing ORIGIN. If an item is active, the remaining hours will be displayed to the right. If an item is deactivated, "—" will be displayed instead. Items are tracked either by the time accumulated while power is on (ON-TIME) or by cycle-start time (CS-TIME). When power is applied, and every hour thereafter, the remaining time for each item is decremented. When it reaches zero (or has gone negative) the message MAINTENANCE DUE is displayed at the bottom of the screen. A negative number of hours indicates the hours past expiration. The maintenance item can have its time adjusted by using the left and right arrows. One hour is added or subtracted for each keypress, upto a maximum of 10,000 hours, and a minimum of 1 hour. Pressing the Origin key will reinstate the default time.

This message is not an alarm and does not interfere with machine operation in any way. The intent is to warn the operator that one of the items on the list requires attention. After the necessary maintenance has been performed, the operator can select that item on the SCHEDULED MAINTENANCE screen, press ORIGIN to deactivate it, then press ORIGIN again to reactivate it, and the countdown begins again with a default number of hours remaining (this value is determined by the software and cannot be altered by the operator.) Items available for checking are:

COOLANT - needs replacement	100 ON-TIME
AIR FILTER in control enclosure - replace	250 ON-TIME
OIL FILTER - replace	250 ON-TIME
GEARBOX OIL - replace	1800 ON-TIME
COOLANT TANK - check level, leakage, oil in coolant	10 ON-TIME
WAY LUBE SYSTEM - check level	50 CS-TIME
GEARBOX OIL - check level	250 ON-TIME
SEALS/WIPERS missing, torn, leaking - check	50 CS-TIME
AIR SUPPLY FILTER - check for water	10 ON-TIME
HYDRAULIC OIL - check level	250 ON-TIME

_///\45





1.11 WINDOWS / GUARDING

Polycarbonate windows and guarding can be weakened by exposure to cutting liquids and chemicals that contain amines. It is possible to loose up to 10% of the remaining strength annually. If degradation is suspected, window replacement should occur at no more than a six year interval.

Windows and guarding should be replaced if damaged or severely scratched - Replace damaged windows immediately

1.12 INTERIOR WORKLIGHT

Bulb Replacement

- 1. TURN OFF power to the machine at the main breaker.
- 3. Remove the retainer and the light lens.
- 4. Remove the light bulb and replace.
- 5. Replace the light lens and retainer.
- 6. Restore power to the machine.



Interior worklight assembly.

2. OPERATION

The Information contained in this manual is constantly being updated. The latest updates and other helpful information can be downloaded in .pdf format from the Haas website. Go to <u>www.HaasCNC.com</u> and click on "Manual Updates" under the "Customer Services" drop-down menu on the navigation bar.

Additional technical information is available in the Haas Reference Manual. The Reference Manual contains definitions of parameters and alarms, machine installation instructions, and explanations of the machine's mechanical and electrical subassemblies.

The Haas Reference Manual is available online as a free download in .pdf format (go to <u>www.HaasCNC.com</u> and click on "Manual Updates" under the "customer services" drop-down menu in the navigation bar), or may be purchased through the Haas Service Department.

2.1 BASIC INTRODUCTION

This section provides the basic programming and operation principles necessary to begin operating the machine. The remainder of this manual is divided into more detailed **Programming** and **Operation** sections.

In an "NC" (numerically controlled) machine, the tool is controlled by a code system that enables it to be operated with minimal supervision and with a great deal of repeatability. "CNC" (computerized numerical control) is the same type of operating system, with the exception that the machine tool is monitored by a computer.

The same principles used in operating a manual machine are used in programming an NC or CNC machine. The main difference is that instead of cranking handles to position a slide to a certain point, the dimension is stored in the memory of the machine control **once**. The control will then move the machine to these positions each time the program is run.

The operation of the VF Series Vertical Machining Center requires that a part program be designed, written, and entered into the memory of the control. The most common way of writing part programs is off-line, that is, away from the CNC in a facility that can save the program and send it to the CNC control. The most common way of sending a part program to the CNC is via an RS-232 interface. The HAAS VF Series Vertical Machining Center has an RS-232 interface that is compatible with most existing computers and CNCs.

In order to operate and program a CNC controlled machine, a basic understanding of machining practices and a working knowledge of math is necessary. It is also important to become familiar with the control console and the placement of the keys, switches, displays, etc., that are pertinent to the operation of the machine.

This manual can be used as both an operator's manual and as a programmer's manual. It is intended to give a **basic** understanding of CNC programming and its applications. It is not intended as an in-depth study of all ranges of machine use, but as an overview of common and potential situations facing CNC programmers. Much more training and information is necessary before attempting to program on the machine.

The programming section of this manual is meant as a supplementary teaching aid to users of the HAAS Vertical Machining Center. The information in this section may apply in whole or in part to the operation of other CNC machines. Its use is intended only as an aid in the operation of the HAAS Vertical Machining Center.



V e

r

t

i

С

а

l

n e 3 -

2

1



2.2 The Coordinate System

The first diagram we are concerned with is called a NUMBER LINE. This number line has a reference point that is called ABSOLUTE ZERO and may be placed at any point along the line.



Horizontal number line.

The number line also has numbered increments on either side of absolute zero. Moving away from zero to the right are positive increments. Moving away from zero to the left are negative increments. The "+", or positive increments, are understood, therefore no sign is needed.

We use positive and negative along with the increment's value to indicate its relationship to zero on the line. In the case of the previous line, if we choose to move to the third increment on the minus (-) side of zero, we would call for -3. If we choose the second increment in the plus range, we would call for 2. Our concern is with distance and direction from zero.

Remember that zero may be placed at any point along the line, and that once placed, one side of zero has negative increments and the other side has positive increments.

п 0 The next illustration shows the three directions of и travel on a vertical machining center. To carry the т -1 b number line idea a little further, imagine such a line е placed along each axis of the machine. r -2l -3 i

The first number line is easy to conceive as belonging to the left-to-right, or "X", axis of the machine. If we place a similar number line along the front-to-back, or "Y", axis, the increments toward the operator are the negative increments, and the increments on the other side of zero away from the operator are the positive increments.



VF-1 showing X, Y, and Z-axis lines.

The final axis of travel on our machine is the up-and-down, or "Z", axis. When we place a number line on the Z travel, the positive increments are up — above zero — and the negative values are down — below zero.

Remember, when we are moving the machine, we are concerned with positioning the spindle. Although the machine table is the moving part, we have to keep in mind our coordinates are based on our theoretical spindle movement.

Keep in mind that the zero position may be placed at any point along each of the three number lines, and in fact will probably be different for each setup of the machine. It is noteworthy to mention here that the Z axis is usually set with the machine zero position in the full upward position, or the tool change position. This will place all the **Z** moves in a negative range of travel. However, the work zero in the Z axis is usually set at the top of the part surface, and this will be entered in the tool length offset as a negative value.

12 -

SERIES Operator's Manual

The diagram shows a top view of the grid as it would appear on the machine tool. This view shows the **X** and **Y** axes as the operator faces the machine tool. Note that at the intersection of the two lines, a common zero point is established. The four areas to the sides and above and below the lines are called "QUADRANTS" and make up the basis for what is known as rectangular coordinate programming.



View of X,Y grid from above.

Whenever we set a zero somewhere on the X axis and somewhere on the Y axis, we have automatically caused an intersection of the two lines. This intersection where the two zeros come together will automatically have the four quadrants to its sides, above, and below it. How much of a quadrant we will be able to access is determined by where we placed the zero within the travel of the machine axis.

2.3 Machine Home

The principle may be seen when doing a manual reference return of all machine axes. When a zero return (ZERO RET) is performed at machine start-up, all three axes are brought to the extreme positive direction until the limit switch is reached. When this condition is satisfied, the only way to move any of the three axes is in the negative direction. This is because a new zero is set for each of the three axes automatically when the machine was brought Home. This is placed at the edge of each axis' travel. In effect, now the positive quadrants cannot be reached, and all the X and Y moves will be found to be in the -X, -Y quadrant. It is only by setting a new part zero somewhere within the travel of each axis that other quadrants are able to be reached.



All four quadrants will have to be accessed to machine this part.





Sometimes it is useful in the machining of a part to utilize more than one of the X,Y quadrants. A good example of this is a round part that has its datum lines running through the center. The setup of such a part may look like the figure above.

These are just some examples of how to make use of the four quadrants of the **X** and **Y** axes on the machine. As more experience is gained in the machine tool programming and setup techniques, each programmer and setup person develops their own methods and style. Some methods will be faster than others, but each individual will have to determine the needs of the job in question, and reflect back on notes and the previous jobs completed.

2.4 Absolute and Incremental Positioning

Up to this point, we have dealt with a system of positioning the tool that is known as absolute programming. In absolute, all coordinate points are given with regard to their relationship to the origin, a fixed zero point, are considered as part zero. This is the most common type of positioning.

Another type of positioning is called incremental positioning. Incremental positioning concerns itself with distance and direction. A new coordinate is entered in terms of its relationship to the previous position, and not from a fixed zero or origin. In other words, after a block of information has been executed, the position that the tool is now at is the new zero point for the next move to be made.

An example of the use of the incremental system is given below. Note that to move from X 4.25 to X 2.025 on the scale, an incremental move of X -2.225 was made, even though the move still places the tool on the plus side of the scale. Therefore the move was determined from the last point, with no regard for the zero position. The + and - signs are used in terms of direction, and not in regard to the position of zero.



An example of an incremental move.

Keep in mind that when positioning in **absolute**, we are concerned with distance and direction from a fixed zero reference point, and when positioning in **incremental** we are concerned with distance and direction from the last position.

14



2.5 Programming With Codes

A program is written as a set of instructions given in the order they are to be performed. The instructions, if given in English, might look like this:

Line #1 =	Select cutting tool.
Line #2 =	Turn the spindle on, select the rpm and the direction.
Line #3 =	Turn the coolant on.
Line #4 =	Rapid to the starting position of the part.
Line #5 =	Choose the proper feed rate and make the cut(s).
Line #6 =	Turn off the spindle and the coolant.
Line #7 =	Return tool to holding position and select next tool.

and so on. But our machine control understands these messages only when given in machine G-code.

Before considering the meaning and the use of codes, it is helpful to lay down a few guidelines:

- 1. Codes come in groups. Each group has an alphabetical address. The universal rule here is that except for G codes and macro calls, codes with the same alphabetical address cannot be used more than once on the same line.
- 2. **G** codes come in groups. Each G code group has a specific group number. G codes from the same group cannot be used more than once on the same line.
- 3. There are modal **G**-code groups which, once established, remain effective until replaced with another code from the same group.
- 4. There are non-modal **G**-codes group which, once called, are effective only in the calling block, and are immediately forgotten by the control.

2.6 MACHINE DEFAULTS

A **default** is an automatic function of the machine tool control. When powering up the machine, the control looks for the home position of all axes, then reads the default values or the preset G codes. If you have ever wondered why the machine went to the part zero that was entered in the G54 when it was never specified in the actual program, it is because the machine automatically reads G54 upon start-up. That is a **default**.

The defaults for the Haas mill are indicated by an asterisk (*) in the "G Codes (Preparatory Functions)" section of this manual.

The control automatically reads these G codes when power is turned on:

- G00 Rapid traverse
- G17 X,Y plane selection
- G20 Select inches
- G40 Cutter Compensation cancel
- G49 Tool length compensation cancel
- G54 Work coordinate zero #1 (1 of 26 available)
- G64 Exact stop cancel
- G80 Canned cycle cancel
- G90 Command absolute programming
- G94 Feed per minute mode
- G98 Canned cycle initial point return

There is no default FEED RATE (**F** code), but once an **F** code is programmed, it will apply until another is entered or the machine is turned off.

-/////5--





2.7 Program Format

Program format, or style, is an important part of CNC machining. Each individual will format programs differently and, in most cases, a programmer could identify a program he or she wrote. The point is that a programmer needs to be consistent and efficient, writing code in the way it is listed and in the order it appears in the program. For example:

X, Y, Z are in order of appearance. The machine will read X, Y, or Z in any order, but we want to be consistent. Write X first, Y second, Z third.

The first line or block in a program using active G codes should be a tool number and tool change command. This would be a good safety measure.

The second line or block will contain a rapid command (G00), an absolute or incremental command (G90, G91), a work zero for **X** and **Y** (G54), a positioning **X** and **Y** coordinate, a spindle speed command (S_____), and a spindle ON clockwise command (M03).

The third line or block will contain a "Read tool length offset" command (G43), a tool length offset number (H01), a Z-axis positioning move (Z.1), and an optional coolant ON command (M08).



Tool length offset and tool length compensation.

An example program's first three lines will look like this:

T1 M06; G00 G90 G54 X0 Y0 S2500 M03; G43 H01 Z.1 M08;

All the necessary codes for each operation are listed above. This format is a good practice and will separate your style from other programmers.

Tool number should always remain numerically matched with the tool length offset number. Setting 15 (the H & T agreement) will ensure the tool number and tool length offset will match. (Ex. T1 in line #1 should have H01 in line #3, and T2 should have H02 in line #3.)

2.8 CANNED CYCLES

A canned cycle is used to simplify programming of a part. Canned cycles are defined for most common Z-axis repetitive operations such as drilling, tapping, and boring. Once selected, a canned cycle is active until canceled with the G80 code. There are six operations involved in every canned cycle:

- 1. Positioning of **X** and **Y** axes (optional A, rotary axis).
- 2. Rapid traverse to the reference plane.
- 3. Drilling, boring, or tapping action.
- 4. Operation at the bottom of the hole.
- 5. Retraction to the reference plane.
- 6. Rapid traverse to the initial starting point.

A canned cycle is presently limited to operations in the Z axis; that is, only the G17 plane is allowed. This means the canned cycle will be executed in the Z axis whenever a new position is selected in the X or Y axis. The operation of a canned cycle will vary according to whether incremental (G91) or absolute (G90) is active. Incremental motion in a canned cycle is often useful as a loop count (L) and can be used to repeat the operation with an incremental X and/or Y move. G98 and G99 are modal commands which change the way the canned cycles operate. When G98 (the system default) is active, the Z axis will be returned to the starting position at the completion of the canned cycle. When G99 is active, the Z axis will be returned to the reference plane when the canned cycle is completed.

For more detailed information on canned cycles, refer to the "G Codes" section of this manual.

NOTE: If an L0 is in the canned cycle line, the cycle will not execute until the control reads an X or Y location.



2.9 Tool Changer Setup Procedure

The following sequence of operations is strongly recommended for setting up this machine:

- 1. Load a program into memory. This is either manually entered or downloaded from a CAM package via the RS-232 interface.
- 2. Determine the tools needed and get them ready.

NOTE:	If machine is equipped with the optional extended Z-clearance table , follow these guidelines: • Avoid extreme loads on the center of table or far end of table. The weight of the part should be distributed evenly over the table or one pad.
	of the part should be distributed evenly over the table or one pad. • Flatness of part should be within 0.002".

- 3. Use a vise or fixture to hold the part and mount it on the mill.
- 4. Locate the X and Y zero points of your program on the part. Usually these points will coincide with the print reference point where dimensioning begins, which needs to be clearly indicated by the programmer. Use an edge finder or indicator to locate this point with the handle function. After locating the programmed zero point, push the display offset key and page down until the work zero offset page appears. Cursor down to G54 X, the work zero offset. Push the PART ZERO SET button and the X-axis machine value will be stored at this location. Cursor to the G54 Y location and repeat the above. You have now told the machine where part zero is located. Usually Z and A values will not have to be set and should be zero.
- 5. Remove any tools from the changer and MDI a T1 M6 command to install tool #1 into the spindle (it should be empty). Put your tool #1 into the spindle using the TOOL RELEASE button. Push the OFSET key and page down to get to the tool offset page and cursor to tool #1. Do not install any tools directly into the carousel. Use MDI or ATC FWD/REV to retrieve tools.
- 6. Push the Z-JOG key until you are close to the top of your part. (The top of your part should be Z0). Use the Handle to accurately position the tool edge to Z0. Push the TOOL OFSET MESUR key and the Z machine value will be stored in tool offset #1. Note that this automatic offset measurement works with G43 only and the work Z offset must be zero.
- Push the NEXT TOOL key and the Z-axis will retract to tool change position and tool #2 (empty) will be installed in the spindle. Put your tool #2 into the spindle and jog to Z zero as you did for tool #1. The cursor will automatically be on offset #2. Push TOOL OFSET MESUR.
- 8. Repeat this procedure until all tools are measured and installed.
- 9. MDI a T1 M6 to return to tool #1.
- 10. You are now ready to run your program.
- 11. Please note that in order to load and measure all of your tools, you do not need to use any keys other than JOG, TOOL OFSET MESUR, and NEXT TOOL. Also note that this automatic offset measurement works with G43 only.



2.10 Operator's Control Panel



Control panel keypad with operating and display keys highlighted.

In operation, it is important to be aware of the operating mode selected for the CNC. There are six operating modes and one simulation mode in this control. The operating mode is selected with the six buttons labeled:



SERIES Operator's Manual

EDIT	To edit a program already in memory
MEM	To run a program stored in memory
MDI / DNC	To directly run a manually entered program or to select DNC mode
HANDLE JOG	To use jog keys or jog handle
ZERO RET	To establish machine zero
LIST PROG	To list, send, or receive programs

The Graphics simulation mode is entered with the DISPLAY select buttons.

In MEM or MDI mode, a program can be started with the CYCLE START button. While a program is running, you cannot change to another mode; you must wait until it finishes or press RESET to stop the program.

When already in MDI, a second push of the MDI button will select DNC if the DNC mode is enabled by settings and parameters in your machine.

In any of the above modes, you can select any of the following displays using the eight DISPLAY buttons:

PRGRM/CNVRS	To show the program selected
POSIT	To show the axes' positions
OFSET	To show or enter working Offsets
CURNT COMDS	To show Current Commands and times
ALARM / MESGS	To show Alarms and User Messages
PARAM / DGNOS	To show Parameters or Diagnostic data
SETNG/GRAPH	To show or enter Settings or to select Graphics simulation mode
HELP / CALC	To show the Help data and Calculator

In addition to the above displays, when a program is already running, you may press LIST PROG to select a list of the programs in memory. This is useful to determine what programs can be edited in BACKGROUND EDIT. BACKGROUND EDIT is selected from the PROGRAM DISPLAY.

All operation of the CNC is controlled from the operator's panel. The control panel is composed of the CRT display, the keypad, On/Off switches, Load meter, Jog handle, and EMERGENCY STOP, CYCLE START, and FEED HOLD buttons.

The **keypad** is a flat membrane type that requires approximately eight (8) ounces of pressure. The **SHIFT** button replaces the function of the numeric buttons with the white characters in the upper left corner. The **SHIFT** button must be pressed once before each shifted character. Pressing the **SHIFT** button twice will turn off shift.

The **jog handle** is used to jog one of the axes. Each step of the crank can be set to 0.0001, 0.001, 0.01 or 0.1 inch (0.001, 0.01, 0.1, 0.1, or 1.0 degree per step for a rotary axis). When using metric units, the smallest handle step is 0.001 mm and the largest is 1.0 mm. The handle has 100 steps per rotation. It can also be used to move the screen cursor while in EDIT mode, or to change feed/spindle overrides by $\pm 1\%$.

The EMERGENCY STOP button will instantly stop all motion of the machine, including the servo motors, the spindle, the tool changer, and the coolant pump. It will also stop any auxiliary axes.

_/////5__

Operator's Manual

CYCLE START will start a program running in MEM or MDI mode, continue motion after a FEED HOLD, or continue after a SINGLE BLOCK stop. The CYCLE START button on the optional remote jog handle performs exactly the same functions.

FEED HOLD will stop all axis motion until the CYCLE START is pressed. The FEED HOLD button on the optional remote jog handle will perform exactly the same functions.

WARNING!

FEED HOLD will not stop the spindle, the tool changer, or the coolant pump. It will not stop motion of any auxiliary axes.

The optional **Memory Lock Key Switch** will prevent the operator from editing programs and from altering settings when turned to the locked position.

The following describes the hierarchy of locks:

Key switch locks Settings and all programs. Setting 7 locks parameters; parameters 57, 209 and 278 lock other features. Setting 8 locks all programs. Setting 23 locks 9xxx programs. Setting 119 locks offsets. Setting 120 locks macro variables.

The SINGLE BLOCK button on the keypad will turn on and off the SINGLE BLOCK condition. When in SINGLE BLOCK, the control will operate one block and stop. Every press of the START button will then operate one more block.

The RESET button on the keypad will always stop motion of the servos, the spindle, the coolant pump, and tool changer. It will also stop the operation of a running program. This is not, however, a recommended method to stop the machine as it may be difficult to continue from that point. SINGLE BLOCK and FEED HOLD provide for continuation of the program. RESET will not stop motion of any auxiliary axes but they will stop at the end of any motion in progress.

Function Buttons

The **F1** Button: In EDIT mode and PROGRAM DISPLAY, this will start a block definition. In LIST PROG mode, F1 will duplicate a program already stored and give it a new name from the command line. In offsets display, F1 will set the entered value into the offsets.

The F2 Button: In EDIT mode and PROGRAM DISPLAY, this will end a block definition.

The **F3** Button: In EDIT and MDI modes, the F3 key will copy the highlighted circular help line into the data entry line at the bottom of the screen. This is useful when you want to use the solution developed for a circular motion. Push INSERT to add that circular motion command line to your program. In the Calculator Help function, this button copies the value in the calculator window to the highlighted data entry for Trig, Circular, or Milling Help.

The **F4** Button: In MEM mode and PROGRAM DISPLAY, this will select either BACKGROUND EDIT or PRO-GRAM REVIEW. BACKGROUND EDIT is selected by entering **Onnnn** with the program number to edit. Program review is selected with just F4. Program review shows the running program on the left half of the screen and allows the operator to review the program on the right half of the screen. In the Calculator Help function, this button uses the highlighted Trig, Circular, or Milling data value to load, add, subtract, multiply, or divide with the calculator.





REAL-TIME CLOCK

Displays current Date and Time. The date and time as supplied by the real-time clock are displayed on the diagnostics screen.

Alarm history tagged with date and time. The alarm history is now displayed with the date and time that each alarm occurred. See the Alarms section on how to access alarm history.

Macro variables. Macro variable #3011 contains the date in the format yymmdd (two digit year* 1000+ month* 100+ day). Macro variable #3012 contains the time in the format hhmmss (hours* 10000 + minutes* 100 + seconds).

Parameter output contains date and time. When outputting a parameter file to a floppy disk or the serial port, it will contain two new comments near the top containing the current date and time.

DISPLAY BRIGHTNESS ADJUSTMENT



Remove plug to access the brightness adjustment knob. Be sure to replace plug.

2.11 Keyboard

The control panel keyboard is divided into nine separate regions. They are:

RESET keys	Three (3) keys
FUNCTION keys	Eight (8) keys
JOG keys	Fifteen (15) keys
OVERRIDES	Sixteen (16) keys
DISPLAYS	Eight (8) keys
CURSOR keys	Eight (8) keys
ALPHA keys	Thirty (30) keys
MODE keys	Thirty (30) keys
NUMERIC keys	Fifteen (15) keys

The following are short descriptions of the control panel keys' usage.

SERIES Operator's Manual

ē I

_

RESET KEYS:	The keys are in the upper left corner of the control panel.
RESET	Stops all machine motion and places the program pointer at the top of the current program.
POWER UP/ RESTART	Automatically initializes the machine at power-up. After initial power-up, when this key is pressed, the axes zero return and tool one is put in the spindle.
TOOL CHANGE RESTORE	R Restores the tool changer to normal operation after the tool changer has encountered an interruption during a tool change. The button initiates a user prompt screen to assist the operator in recovering from a tool changer crash.
	A flow chart showing the steps to restore the side mount tool changer is shown in the Programming section.
FUNCTION KEYS:	Below the reset keys are the function keys. There are eight function keys. They are used to execute special functions implemented throughout the control software.
F1-F4	Used in editing, graphics, background edit, and for help/calculator to execute special functions.
TOOL OFSET MESUR	Used to record tool length offsets in the offset page during part setup.
NEXT TOOL	Used to select the next tool during part setup.
TOOL RELEAS	E Releases the tool from the spindle when in MDI mode, zero return, or handle jog. (The remote TOOL RELEASE button is located on the front of the cover to the spindle head. It operates the same as the one on the keypad. It must be held for ½ second before the tool will be released, and the tool will remain released for ½ second after the button is released. While the tool is unclamped, air is forced down the spindle to clear chips, oil, or coolant away from the tool holder.
PART ZERO SE	T Used to automatically set work coordinate offsets during part setup.
JOG KEYS:	The jog keys are on the left below the function keys. These keys select which axes the jog handle sends signals to and provide for continuous jogging. When a key is pressed briefly, that axis is selected for use by the jogging handle. When a key is pressed and held down, that axis is moved as long as the key is held down. If a "+" key is pressed and held, the axis is moved so that the tool position is changed in a positive direction relative to the work coordinates. If a "-" key is pressed and held, the axis is moved so that the tool position is changed in a negative direction relative to the work coordinates. The jog keys are locked out if the machine is running.
+A, -A	Selects the A axis. Selects the B axis when used with the shift key and control is configured with a fifth-axis option.
+Z, -Z	Selects the Z axis.
+Y, -Y	Selects the Y axis.
+X, -X	Selects the X axis.



JOG LOCK When pressed prior to one of the above keys, the axis is moved in a continuous motion without the need to hold the axis key depressed. Another press of the JOG LOCK key stops jogging motion.

To the left side of the jog keys are three keys to control the optional chip auger. If the auger is enabled with Parameter 209, these keys perform the following functions:

CHIP FWD	Turns the auger in	n a direction that	removes chip	os from the work ce	II.

CHIP STOP Stops auger movement.

CHIP REV Turns the chip auger in the reverse direction.

To the right side of the jog keys are three keys to control the optional automatic spigots. If the spigot is enabled with Parameter 57, these keys perform the following functions:

CLNT UP	Pressing this key positions the coolant stream direction one position higher, if possible.
CLNT DOWN	Pressing this key positions the coolant stream direction one position lower, if possible.
AUX CLNT	Pressing this key while in MDI mode will turn on the Through the Spindle Coolant system, and pressing it again will shut off the system.
OVERRIDES:	The overrides are at the lower left of the control panel. They give the user the ability to override the speed of rapid traverse motion, as well as programmed feeds and spindle speeds.
HANDLE CONTROL FEEDRATE	Allows jog handle to be used to control feedrate in $\pm 1\%$ increments (from 0 to 999%).
-10	Decreases current feedrate by 10% (from 10 to 200%).
100%	Sets control feedrate to programmed feedrate.
+10	Increases current feedrate by 10% (from 10 to 200%).
HANDLE CONTROL SPINDLE	Allows jog handle to be used to control spindle speed in $\pm 1\%$ increments (from 0 to 999%).
-10	Decreases current spindle speed by 10% (from 10 to 150%).
100%	Sets spindle speed to programmed speed.
+10	Increases current spindle speed by 10% (from 10 to 150%).
CW	Starts the spindle in the clockwise direction. Except CE machines.
STOP	Stops the spindle.
CCW	Starts the spindle in the counterclockwise direction. Except CE machines.

Series Operator's Manual



- 25% RAPID Limits rapid traverse to 25% of maximum.
- 50% RAPID Limits rapid traverse to 50% of maximum.

100% RAPID Allows rapid traverse to feed at its maximum.

- **DISPLAYS:** The display keys are in the center at the top. These eight keys provide access to the different displays, operational information and help routines available to the user. Some of these keys are multi-action keys in that they will display different screens when pressed multiple times. The current display is always displayed on the top left line of the video screen.
 - PRGRM / CONVRS Displays the currently selected program. Also used in Quick Code applications.
 - POSIT Displays the position of the machine axes. Pressing PAGE UP and PAGE DOWN will show operator, machine, work, and distance-to-go formats in large letter format.
 - OFSET Displays the tool length ,radius offsets, and cooant position. PAGE UP will display the values of the axes' work offsets. If the ORIGIN button is pressed while the offsets are displayed, the control will prompt the user: ZERO ALL (Y/N)? Entering Y will zero all the offsets and coolant positions in the section displayed.
 - CURNT COMDS Displays the current program, modal program values, and position during run time. Succeeding presses of the PAGE DOWN key will display modal values, system timers, macro variables, tool life and tool load information.
 - ALARM / MESGS Shows the full text of an alarm when the alarm message is flashing. Pressing the left or right arrow keys will display an alarm history. Pressing PAGE DOWN will display a page for user messages and notes.
 - PARAM / DGNOS Displays and allows changing of parameters that define machine character. Pressing PAGE UP will display lead screw compensation values. Successive PAGE DOWN presses will display general parameters as well as the X, Y, Z, A and B parameters. A second press of the PARAM key will display the first page of diagnostic data. The first page of diagnostic data is discrete inputs and outputs. Pressing PAGE DOWN will display the second page of diagnostic data that consists of additional inputs and analog data.
 - SETNG / GRAPH Displays and allows changing of user settings. Pressing the SETNG key twice enables graphics mode, where the user can debug the current program and view the program's generated tool path.
 - HELP / CALC Displays a brief, on-line manual. Pressing HELP a second time will display the help calculator. There are three pages of calculator help. Pressing the PAGE DOWN key will display milling and tapping help, trigonometry help, or circle help.
- **CURSOR KEYS:** The cursor keys are in the center of the control panel. They give the user the ability to move to various screens and fields in the control. They are used extensively for editing of CNC programs.
 - HOME Context-sensitive key that generally moves the cursor to the top-most item on the screen. In editing, this is the top block of the program. In graphics zoom, it will select full view.





(UPARROW) The up arrow moves up one item, block, or field. In graphics, the zoom window is moved up.

- PAGE UP Used to change displays, move up one page in the editor, or zoom out when in graphics.
- (LEFTARROW) Used to select individually editable items within the editor; moves cursor to the left. It selects optional data in fields of the settings page and moves the zoom window left when in graphics.
- (RIGHTARROW) Used to select individually editable items within the editor; moves cursor to the right. It selects optional data in fields of the settings page and moves the zoom window right when in graphics.
 - END Context-sensitive key that generally moves the cursor to the bottom-most item on the screen. In editing, this is the last block of the program.
- (DOWN ARROW) The down arrow moves down one item, block, or field. In graphics, the zoom window is moved down.
 - PAGE DOWN Used to change displays, move down one page in the editor, or zoom closer when in graphics.
- **ALPHA KEYS:** The alpha keys allow the user to enter the 26 letters of the alphabet along with some special characters.
 - SHIFT The shift key provides access to the white characters on the keyboard. Pressing SHIFT and then the white character will cause that character to be sent to the control. When entering text, UPPER CASE is the default. To access lower case characters, press and hold the SHIFT key while pressing the appropriate characters. The SHIFT key can also be continuously held down while a number of other keys are pressed.

When a control has a fifth axis installed, the B axis is selected for jogging by pressing SHIFT and then the +,-A keys.

- EOB This is the END-OF-BLOCK character. It is displayed as a semicolon on the screen and it signifies the end of a programming block. It is the same as a carriage return and then a line feed.
- () The parenthetical brackets are used to separate CNC program commands from user comments. They must always be entered as a pair and may or may not have additional characters separating them. Any time an invalid line of code is received through the RS-232 port while receiving a program, it is added to the program between these two brackets.
- *I* The right slash is used as a block delete flag. If this symbol is the first symbol in a block and a BLOCK DELETE is enabled, then that block is ignored at run time. The symbol is also used for division in macro expressions.



In some FANUC-compatible controls, the block delete symbol can be used to choose between two options when the "/" symbol is not at the beginning of the line. For instance, in the following line, T2 is executed when the block delete option is off, and when the block delete option is on, T1 is executed.

```
T1 / T2;
N1 G54
```

This cannot be done on a HAAS control.

A coding method for acheiving the same results on a HAAS control is given below:

/ T2 M99	(T2 executed when block delete is off)
T1	(T1 executed when block delete is on)
N1 G54	

NOTE: Machines equipped with a side mount tool changer (SMTC) move the tool carousel to the programmed tool pocket at look ahead time. It is important to note that BLOCK DELETE must be enabled prior to running a program tagged with the BLOCK DELETE "/" character.

For example:

If BLOCK DELETE is ON and the T-code block has been BLOCK-DELETED, the T-code will be skipped.

If BLOCK DELETE is <u>not</u> ON at the time the T-code BLOCK is being processed, and subsequently BLOCK DELETE is selected, then the BLOCK will be processed regardless of whether the block is tagged with the BLOCK DELETE "/" character.

- [] Square brackets are used in macro expressions and functions.
- **MODE KEYS:** The mode keys are in the upper right part of the control panel. These keys change the operational state of the CNC machine tool. There are six major operation modes. The user can enter a specific mode by pressing the desired "arrow" shaped key on the left. The keys in the same row as the pressed mode key are then made available to the user. Otherwise, these keys are not available. The current mode is always displayed on the top line just to the right of the current display on the video screen.

EDIT Selects edit mode.

- INSERT Inserts the text in the input buffer after the current cursor location. Also used to copy blocks of code in a program.
- ALTER Changes the item that the cursor is on to the text in the input buffer. Places an MDI program in the program list.
- DELETE Deletes the item that the cursor is on.
- UNDO Backs out or undoes up to the last 9 edit changes.

MEM Selects MEM mode.

SINGLE BLOCK	Turns single block on so that when the cycle start button is pressed, only one block of the program running is executed.
DRYRUN	Used to check actual machine movement without cutting a part. Programmed feeds are replaced by the speed keys in the handle jog row.




	OPT STOP	 Turns on optional stops. If an M01 code is encountered in the program and OPT STOP is on, a stop is executed. Depending on the look-ahead function, it may not stop immediately. If the program has been interpreted many blocks ahead, and OPT STOP is pressed, then the nearest M01 may not be commanded. See G103. OPT STOP will take effect on the line after the highlighted line when OPT STOP is pressed. M01 is not allowed during cutter compensation. Alarm 349 will be generated in this case, as for M02, M30, and M00.
	BLOCK DELETE	 Blocks with a slash ("/") as the first item are ignored or not executed when this option is enabled. If a slash is within a block, address codes after the slash will be ignored until after the block, if this option is enabled. 1. When not in cutter compensation, block delete will take effect two lines after BLOCK DELETE is pressed. 2 When in cutter compensation, blocks must be processed earlier. Therefore, block delete will not take effect until at least four lines after the highlighted line when BLOCK DELETE is pressed. 3 If BLOCK DELETE changes state during the processing of the first block of a chamfering/rounding pair, and at least one of the pair is block-deleted, the behavior is undefined. 4 Processing will slow down for paths containing block deletes during high-speed machining, because the look-ahead queue will be emptied as processing approaches the block-deleted line(s). This limits the speed at which the previous blocks can run.
MDI/DNC	Select	s MDI or DNC mode.
	COOLNT	Turns the coolant on and off.
	ORIENT SPINDLE	Rotates the spindle to a known position and then locks the spindle. Can be used during setup to indicate parts.
	ATC FWD	Rotates the tool turret forward to the next sequential tool. If Tnn is in the input buffer, the turret will advance to tool nn . Except on CE machines.
	ATC REV	Rotates the tool turret backwards to the previous tool. If Tnn is in the input buffer, the turret will advance to tool nn . Except on CE machines.
HANDLE	JOG Select	s Jogging mode.
	.0001, .1	0.0001 inches or 0.001 mm for each division on the jog handle. For dry run, .1 inches/min.
	.001, 1.	0.001 inches or 0.01 mm for each division on the jog handle. For dry run, 1. inches/min.
	.01, 10.	0.01 inches or 0.1 mm for each division on the jog handle. For dry run, 10. inches/min.
	.1, 100.	0.1 inches or 1.0 mm for each division on the jog handle. For dry run, 100. inches/min.

ZERO RET Selects Zero Return mode.

- AUTO ALL AXES Searches for all axes' machine zero.
 - ORIGIN Zeros out various displays and timers.

SERIES Operator's Manual

ē I

-

ZERO SINGLAXIS		Searches for machine zero on the axis that is specified in the input buffer.			
HOME G28		Returns all axes to machine zero in rapid motion. Does not search.			
SINGLE AXIS HOME G28		Either the X, Y, Z, A, or B axis can be returned to zero alone. The operator enters X,Y,Z,A or 'B', then presses the HOME G28 key.			
		Pressing HOME G28 without first entering an axis letter will cause all enabled axes to be returned to zero.			
		If the chosen axis is disabled, the message DISABLED AXIS will be generated.			
CAU	J TION ! Ther For e Y is :	e is no warning message to alert the operator of any possible collision. xample, if the Z axis is down in amongst parts on the table when X or zeroed, a crash can result.			
SECOND HOME		This is an optional feature. When this button is pressed, the control will rapid all axes (which have the 2ND HOME BTN bit =1) to the coordinates specified in Work Offset G129. The sequence is as follows: First, assuming the X or Y axis need to be moved, the Z axis is returned to zero, then the X and Y axes are moved to their final positions, then the Z axis is moved to its final position. G129 Work Offsets must be set to the desired values for this feature to work correctly. This feature will work in any mode except DNC, just like the HOME G28 button.			
LIST PROG	Select contro	s Program List mode and displays a list of the programs in the ol.			
LIST PROG SELECT PR	Select contro	s Program List mode and displays a list of the programs in the ol. Makes the highlighted program on the program list the current program. The current program will have an asterisk preceding it in the program list.			
LIST PROG SELECT PR SEND RS23	Select contro ROG	s Program List mode and displays a list of the programs in the bl. Makes the highlighted program on the program list the current program. The current program will have an asterisk preceding it in the program list. Transmits programs out the RS-232 serial port. If ALL is highlighted, all the programs will be sent, with one "%" at the beginning and one at the end of the stream.			
LIST PROG SELECT PR SEND RS23 RECV RS23	Select contro ROG 32	 S Program List mode and displays a list of the programs in the Makes the highlighted program on the program list the current program. The current program will have an asterisk preceding it in the program list. Transmits programs out the RS-232 serial port. If ALL is highlighted, all the programs will be sent, with one "%" at the beginning and one at the end of the stream. Receives programs from the RS-232 serial port. Unless ALL is highlighted, enter a valid program name in the form Onnnn before pressing RECV RS232. If ALL is highlighted, do not enter a program name. The program names will be entered automatically from the input stream data. 			
LIST PROG SELECT PR SEND RS23 RECV RS23 ERASE PRO	Select contro 32 32 32	 S Program List mode and displays a list of the programs in the Makes the highlighted program on the program list the current program. The current program will have an asterisk preceding it in the program list. Transmits programs out the RS-232 serial port. If ALL is highlighted, all the programs will be sent, with one "%" at the beginning and one at the end of the stream. Receives programs from the RS-232 serial port. Unless ALL is highlighted, enter a valid program name in the form Onnnn before pressing RECV RS232. If ALL is highlighted, do not enter a program name. The program names will be entered automatically from the input stream data. Erases the highlighted program or the program specified in the input buffer. 			
LIST PROG SELECT PR SEND RS23 RECV RS23 ERASE PRO NUMERIC KEYS	Select contro ROG 32 32 32 32 32 32 32 32 32 32 32 32 32	 S Program List mode and displays a list of the programs in the bl. Makes the highlighted program on the program list the current program. The current program will have an asterisk preceding it in the program list. Transmits programs out the RS-232 serial port. If ALL is highlighted, all the programs will be sent, with one "%" at the beginning and one at the end of the stream. Receives programs from the RS-232 serial port. Unless ALL is highlighted, enter a valid program name in the form Onnnn before pressing RECV RS232. If ALL is highlighted, do not enter a program name. The program names will be entered automatically from the input stream data. Erases the highlighted program or the program specified in the input buffer. 			
LIST PROG SELECT PR SEND RS23 RECV RS23 ERASE PRO NUMERIC KEYS CANCEL	Select contro ROG 32 32 32 32 32 32 32 32 32 32 32 32 32	 S Program List mode and displays a list of the programs in the bl. Makes the highlighted program on the program list the current program. The current program will have an asterisk preceding it in the program list. Transmits programs out the RS-232 serial port. If ALL is highlighted, all the programs will be sent, with one "%" at the beginning and one at the end of the stream. Receives programs from the RS-232 serial port. Unless ALL is highlighted, enter a valid program name in the form Onnnnn before pressing RECV RS232. If ALL is highlighted, do not enter a program name. The program names will be entered automatically from the input stream data. Erases the highlighted program or the program specified in the input buffer. meric keys give the user the ability to enter numbers and a few special characters control. The CANCEL key is used to delete the last character entered during editing or field input. 			





- -, . Used to negate numbers, or provide decimal precision.
- +, =, These symbols are accessed by first pressing the SHIFT key and then the key with these #, and * symbols. They are used in macro expressions.
- **?**, %, \$, These are additional symbols, accessed by pressing the SHIFT key. They can be used in program comments.
- and:



2.12 Power On / Off

Power On

There is only one way to turn on this CNC. This is by pressing the green "On" button at the top left of the control panel. The main breaker at the rear of the mill must be on before this button will turn on the mill. Any interruption to power will turn the mill off and this button must be used to turn power back on again.

Upon power-up, the machine must find its fixed reference point before any operations can occur. After power on, pressing POWER UP/RESTART will establish this point. The ZERO RET mode and AUTO ALLAXES button may also be used to initialize the system after all alarms are cleared. A single axis can be selected by first pushing the **X**, **Y**, **Z**, **A**, or **B** key and then the ZERO SINGLAXIS key. The position thus found is used as machine zero. Note that the Z axis will shift downwards about five inches as the search for zero is finished; so, keep clear.

CAUTION !!!! After power-up, the machine does not know its home position or stored stroke limits until it has been zero returned by the POWER UP/RESTART key or the ZERO RET/AUTO ALL AXES key. It is possible to jog the machine with the handle or jog keys at the lower feeds. If it is jogged unchecked in either direction, you may damage the sheet metal covers or overload the ball screws. To avoid this, always properly ZERO RET the machine immediately after power-up before doing anything else.

The HOME G28 key should be used any time after the initial power-up. This will return the Z axis first and then the X, Y, A, and B axes all at rapid rate. If the Z axis is positioned above the machine zero, the X, Y, A, and B axes are moved first. This key will work in any of the operating modes. The manual G28 button does not use any intermediate return point the way the programmed G28 does. Any auxiliary axes (C, U, ...) are returned to home after X, Y, Z, A, and B.

NOTE: Repairs to the motor, ballscrew, or home switch will affect the zero return point and must be done only by a factory-trained technician. Serious damage to the ballscrew, way covers, linear guides, or tool changer may occur if the zero return point is not properly set.

Power Off

Pressing the red POWER OFF button will remove power to the machine instantly. The machine can also be programmed to turn off at an end of cycle (M30) or after a preset amount of time that the machine sees no activity. These are Settings 1 and 2.

A sustained overvoltage condition or sustained overheat condition will also shut this machine off automatically. If either of these conditions exists for 4.5 minutes, the machine will start the 30 second auto-shutdown. Alarm 176 is displayed when an overheat shutdown begins and Alarm 177 is displayed when an overvoltage shutdown begins.

Any power interruption, including the rear cabinet main circuit breaker, will also turn this machine off. Power must be restored and the POWER ON button pressed to restore operation.

NOTE: Tool changer goes to tool #1 first, then to tool designated in Setting 81. After initializing, all machine Position displays are reset to zero.



2.13 MANUAL OPERATION

MDI

Manual data input allows you to enter data that can be executed on a line-by-line basis instantly, without having to use the EDIT and MEM modes. In this control, MDI is actually a scratch pad memory that can execute many lines of instruction without having to disturb your main program in memory. The data in MDI will be retained even when switching modes or in power off.

Editing with MDI is the same as memory editing.

The MDI mode also allows for manual operation of the coolant, spindle, and tool changer.

A program in MDI can be saved as a normally named program in memory by placing the cursor at the beginning of the first line (HOME), typing **Onnnnn** (new program number), then pushing ALTER. This will add that name to the program list and clear MDI.

The entire MDI program may be cleared by pressing the ERASE PROG key while in MDI.

A fast way to select a tool is to type **Tnn** and, instead of INSERT, press either ATC FWD or ATC REV. This will directly select that tool.

When DNC is enabled with Setting 55, a second push of the MDI button will put the control into DNC mode.

When the Parameter 57 flag DOOR STOP SP is set to 1, the maximum spindle speed is 750 rpm with the doors open.

HANDLE JOG

Manually moving the axes is accomplished by pressing the mode button labeled HANDLE JOG and then by using the JOG keys or the Handle to move the axis. Both the JOG buttons and the Handle are enabled simultaneously without needing to select between them. The display is changed to the Position Display and the currently selected axis for jogging will blink.

Jog feedrate or handle resolution is selected by the four keys to the right of the HANDLE JOG key. Jog feeds from 0.1 inch per minute to 100 inches per minute or handle divisions from 0.0001 inch to 0.1 inch are selectable. Auxiliary axes can be manually jogged from the front panel.

During jogging, the FEEDRATE override buttons will adjust the rates selected from the keypad. This allows for very fine control of the jog speed. It does not change the handle step size.

In the center of the jog buttons is a key labeled JOG LOCK. This key will cause the axis you are jogging to continue jogging even after you release the key. Press this key and then press the selected axis motion key to start. Motion will stop as soon as the JOG LOCK button is pressed again, or RESET is pressed.

NOTE: Selecting another axis will cause that axis to move.

This feature is handy, for example, when you are slow milling the soft jaws of a vise.

In order to select another axis for jogging while using the handle, use $\pm X$, Y, Z, or A buttons. When one of these buttons is pressed, that axis is selected for HANDLE JOG but does not move unless the button is held down for more than $\frac{1}{2}$ second. After $\frac{1}{2}$ second, that axis is moved in the selected direction and at the selected feedrate.

-/////5--



All aspects of handle jogging for the fifth axis work as they do for the other axes. The exception is the method of selecting jog between axis **A** and axis **B**. By default the '+A' and '-A' keys will select the **A** axis for jogging. The display will show "JOGGING AAXIS HANDLE .01" while you are jogging the **A** axis. The **B** axis can be selected by pressing the SHIFT key, and then either the '+A' or '-A' key. When this is done the control will switch to jogging the **B** axis and the display will change to "JOGGING BAXIS HANDLE .01".

The axis assigned to the '+A' and '-A' keys will remain selected for jogging even if the operating mode is changed or if the machine is turned off. The selected axis for '+A' and '-A' can be toggled by pressing the SHIFT key prior to pressing the '+A' or '-A' keys.

2.14 AUTOMATIC OPERATION

OPERATION MODE

There are six modes of operation of the VF Series CNC Mill. They are:

EDIT	Used to make manual changes to a part program.
MEM	Used to run a user's part program stored in memory.
MDI/DNC	Used to quickly manually enter and run a program.
HANDLE/JOG	Used to move the axes with the jog handle or JOG buttons.
ZERO RET	Used to search for machine zero and to return to machine zero automatically.
LIST PROG	Used to list, send, receive and delete programs.

Changes to the mode are made by pressing the buttons on the top right quadrant of the keypad that have the above labels. If an operation is started, such as running a program, you cannot change modes until the operation is stopped (Motion is stopped by pressing Feed hold or Reset). The six mode-selection buttons are arranged vertically and, generally, the keys to their right apply only in that selected mode.

PROGRAM SELECTION

Program selection is done from the LIST PROG mode. This mode will list all of the programs stored in memory and allow you to select one as the current program. This is the program that will be run when you press START in MEM mode. It is the program with the " * " on the LIST PROG display. It is also the one that you will see on the EDIT display.

To select an existing program, press the CURSOR **up** or **down** buttons until the program you want is highlighted and then press the SELECT PROG button. The "*" will move to that program.

To select a new program (create a new program) or to select an existing program, you may also enter **Onnnnn** from the keyboard and then press the SELECT PROG button.





Starting Automatic Operation

Before you can run a program, it must be loaded in the current memory. To select a program, push the LIST PROG mode key. Use the cursor to find the desired program and then push SELECT PROG. The program list includes the program name and the first comment. If the control was turned off while running, that program will automatically be in current memory and selected.

If the machine has just powered up, you need to first push the POWER UP / RESTART key. This will initialize all axes and the tool changer, display the Current Commands, and go to MEM mode with the control ready to run. Pushing the CYCLE START button in the lower left of the control panel will begin execution.

To start a program other than at the beginning, scan to the block number using the **down** arrow or PAGE DOWN until you reach the desired starting place. Push the MEM key and CYCLE START to begin. The Program Restart function, selected from Setting 36, will change the way a program operates if you start from other than the first block. The setting called Program restart "ON" will ensure that the correct tool and axis positions are selected when you start from partway through a program.

Any errors in your program will cause an alarm and stop the running of the program. Typical alarms are travel limits and missing **I**, **J**, and **Q** codes. Attempts to move outside of the limits of travel will also cause an alarm.

At any time that a program is running, the bottom left corner of the CRT will show RUNNING. If it does not show this, the program has completed, has been stopped by the operator, or has been stopped by a fault condition.

Program Restart

Program Restart is designed to help the operator start a program from the middle while still properly interpreting all of the preceding lines of the program. To use program restart, turn on setting 36, move the cursor pointer to where you want to start (the restart point), and press Cycle Start. You do this by using the CURSOR up and down keys in MEM mode. The control will begin "invisible" interpretation of the program from the beginning and you will see the cursor move through the program. When it gets to the line you wanted to start on, the control will establish all of the conditions that would normally have been true at the end of the previous line and then execute the highlighted line and the rest of your program. Most program interpretation alarms which you might have gotten in the invisible phase will not occur until after the line at your restart point is complete.

As an example, if the following program were to restart at the T2 line, the control would change to T1 and then change to T2 before start axes motion. If the H and T agreement setting (15) was on, you would still not get an alarm. The double tool change is probably the most difficult to understand. The control does that because it ensures that everything that must be true on the previous line is established and that means go to tool 1. It then executes the restart line, which says go to tool 2.

O0123 ; T1 M06 : G00 G90 G54 X0 Y0 : G01 F20. Z-2. ; T2 M06 H03 ; (RESTART HERE) G00 G90 G54 X0 Y0 ; G01 F20. Z-2 ; G28 ; M30 ;

Stopping Automatic Operation

There are several ways a program can be stopped. They include both normal stops and abnormal, or alarm caused, stops. The normal stops are:

- 1. Normal completion at M00, M01, M02, or M30.
- 2. A FEED HOLD stop by the operator. The program is continued by pressing CYCLE START again.
- 3. A SINGLE BLOCK stop when operator selected. The program is continued by pressing CYCLE START again.
- 4. A Door Hold stop caused by the operator opening the enclosure doors. The program continues when the doors are closed.

The abnormal stops are:

- 1. **Operator Reset** This stops all axes' motion, stops the tool changer, turns off the spindle, and turns off the coolant pump. Program operation cannot be continued from the stopping point. If Setting 31 is **On**, the program pointer is reset to the beginning.
- 2. **Emergency Stop** This stops all axes' motion, disables the servos, stops the tool changer, turns off the spindle, and turns off the coolant pump. Program operation cannot be continued from the stopping point. This will also stop any auxiliary axes' motion. RESET must be used at least twice to remove the alarms and start again.
- 3. Alarm Condition This can occur any time an alarm comes on during program operation. Since a program cannot be restarted until RESET is pressed, a program execution cannot be continued from the stopping point. Alarms can be caused by programming errors or machine faults. Use the Graphics simulation mode to test your program first for errors.
- 4. **Power-off** This will stop all motors within one second but does not guarantee any conditions when the machine is powered-on again.

Emergency Stop Switch

The EMERGENCY STOP switch is normally closed. If the switch opens or is broken, power to the servos will be removed instantly. This will also shut off the tool changer, spindle drive, and coolant pump. The EMER-GENCY STOP switch will shut down motion even if the switch opens for as little 0.005 seconds.

Be careful of the fact that Parameter 57 contains a status switch that, if set, will cause the control to be powered down when EMERGENCY STOP is pressed.

You should not normally stop a tool change with EMERGENCY STOP as this will leave the tool changer in an abnormal position that takes special action to correct.

Note that the tool changer alarms can be easily corrected by first correcting any mechanical problem, pressing RESET until the alarms are clear, selecting ZERO RETURN mode, and selecting AUTO ALLAXES.

If the shuttle should become jammed, the control will automatically come to an alarm state. To correct this, push the EMERGENCY STOP button and remove the cause of the jam. Push the RESET key to clear any alarms. Push the ZERO RETURN and the AUTO ALLAXES keys to reset the Z-axis and tool changer. Never put your hands near the tool changer when powered unless the EMERGENCY STOP button is pressed.





Work Beacons

The red and green work beacons located directly on top of the control arm allow the operator to monitor the machine status.

While a program is running normally, the GREEN beacon will be on.

The beacon will flash GREEN if:	-	the operator selects FEEDHOLD or SINGLE BLOCK stop.
	-	the control is in M00, M01, M02, or M30. It will stop flashing when RESET is pressed. If the control is in M02 or M30, and door hold override is not on, the beacon will stop flashing when the door is opened.
The beacon will <i>flash</i> RED if:	-	the control encounters an alarm, such as when EMERGENCY STOP is pressed. It will stop flashing when RESET is pressed to clear all alarms.

2.15 Part Program Storage and Edit

When using anything other than HELP or Messages functions, alphanumeric key entries are displayed along the bottom line of the CRT. This is called the data entry line. When the line contains what you want to enter, press the WRITE, ALTER, or INSERT key as appropriate.

When the HELP display is selected, the alphanumeric keys are used to select one of the topics, so they are not displayed on the data entry line of the CRT.

When the Message function is selected, the cursor is positioned on the screen and you type directly into the display.

CREATING PROGRAMS

To create a new program, you must be in the PRGRM/CONVRS display and LIST PROG mode. Enter **O** (letter, not number) and a five-digit program number and press SELECT PROG key or ENTER. The selected program is the "Main" program and is the one you will see in the MEM and EDIT modes. Press EDIT to show the new program. A new program will begin and consist of only the **Onnnnn** and an EOB (;). All further entries are made by typing a letter followed by a numeric value and pressing INSERT, ALTER, or WRITE. All items entered into a program are either addressed data (a letter of the alphabet followed by a number), or a comment (text surrounded by parentheses), or the End-of-Block command (EOB or ;).

The CURSOR **up** and **down** keys can be used to search for the entered value. Simply enter the value to search for on the bottom line and press the CURSOR **up** or **down** keys. The CURSOR **up** key will search for the entered item backwards to the start of the program. The CURSOR **down** key will search forward to the end of the program. Searching also works in MEM mode. If you enter a letter without a number, the search will stop on the first use of that letter with any value.

-111415-

NOTE: When INSERT is pressed, the new data is put in after the highlighted data. The CURSOR **up**, **down**, **left**, and **right** keys are used to select the item to search for. The PAGE UP and PAGE DOWN keys move farther distances and the HOME and END keys go to the start or end of the program. All of these keys work in EDIT, MEM, and MDI modes.

Operator's Manual

A comment can be edited without entering the entire comment again. Simply highlight the characters (by cursoring into the text) you wish to change, enter the new characters, and press ALTER. To add characters, move the cursor to where text is to be added, enter the new characters, and press INSERT. To remove characters, highlight the characters and press DELETE. Use the UNDO button to reverse any changes. The UNDO button will work for the last nine entries.

After creating a program, the program number can be very easily changed by simply altering the **Onnnnn** on the first line. If the maximum number of programs is already present, the message "DIR FULL" will be displayed and the program cannot be created.

Editing Programs

The EDIT mode is used to make changes to a program already in memory, or use the LIST PROG mode to create a new one. A newly created program contains only the program **Onnnnn** name and an EOB.

To enter the EDIT mode, press the EDIT mode key. The screen will display the current program. If no program file exists, program 00000 will be displayed. To change a program name, move the cursor to the existing **Onnnnn**, type in the letter "**O**" followed by a five-digit number, such as O12345, and press the ALTER key. The upper right hand screen will display the new program number. Your data will first appear in the lower left screen and will be input to the upper screen upon pressing INSERT, ALTER, or WRITE.

To enter a program from the keypad, type in the data you wish and press the INSERT key. More than one code, such as **X**, **Y**, and **Z**, can be entered before you press INSERT. After a program is entered, you may wish to change the data. Highlight the characters you wish to change, enter the new characters, and press ALTER. To add characters, move the cursor to where text is to be added, enter the new characters, and press INSERT. To remove characters, highlight the characters and press DELETE. Use the UNDO button to reverse any changes. The UNDO button will work for the last nine entries.

The CURSOR **up** and **down** keys can be used to search for the entered value. Simply enter the value being searched for on the bottom line and press the CURSOR **up** or **down** keys. The CURSOR **up** key will search for the entered item backwards to the start of the program. The CURSOR **down** key will search forward to the end of the program. Searching also works in MEM mode. If you enter a letter without a number, the search will stop on the first use of that letter with any value.

You can change to a different program while in the EDIT or MEM mode by using the CURSOR **up** and **down** keys; enter **Onnnnn** on the input line and then press the CURSOR **up** and **down** keys or the **F4** key. **Onnnnn** is the program you wish to change to.

The jog handle can be used to move the cursor during editing. Parameter 57 is used to enable this function. If enabled, the handle will act like the CURSOR **left** and **right** buttons.

Background editing is also possible; all of the above editing functions can be used while a program is running in MEM.

Editing error messages:

Guarded Code	You tried to remove the Onnnnn from the start of a program.
Bad Code	A line contained invalid data or comment over 80 characters.
Editing Error	Some previous edit was not completed; fix the problem or press UNDO.
Bad Name	Program name Onnnnn is invalid or missing.
Invalid Number	The number with an alphabet code was invalid.
Block Too Long	A block may only be 256 characters.
No Code	An insert was done without any data to insert.
Can't Undo	May only use undo for previous nine changes.
End Of Prg	End of program EOB cannot be deleted.







BACKGROUND EDIT

With BACKGROUND EDIT, you may edit a program in memory while any other program is being run. BACK-GROUND EDIT can be enabled and disabled by Parameter 57.

BACKGROUND EDIT is selected from MEM mode when in PROGRAM DISPLAY by typing **Onnnnn** for the program you want to edit and pressing F4. If you do not enter the **Onnnnn**, you will instead get the PROGRAM REVIEW display.

While in BACKGROUND EDIT, you may perform any of the operations available in the EDIT mode. The last five lines of the CRT will, however, display the status of the running program and the top line will show the name and line number of the running program.

Selecting any other display or pressing F4 will exit from BACKGROUND EDIT. In order to list the programs that are in memory, a display function is available to view the program memory list while a program is running. This display is called LIST. It is selected by pressing the LIST PROG button while a program is running. The display is just like the LIST PROG mode display but it does not allow any send, receive, copy, select, or erase functions.

The CYCLE START button may not be used while in BACKGROUND EDIT. If the program contains an M00 stop, you must exit BACKGROUND EDIT and then press CYCLE START to resume the program.

All of the changes made during BACKGROUND EDIT are saved in a different memory area until the running program stops. This means that you can even edit the program that is running, or any of its subprograms, and those changes will not affect the running program.

The first time you select a program for BACKGROUND EDIT, you will get the message PROG EXISTS if the program is already in memory or NEW PROG if it is not. The NEW PROG message means that the program is being created and will be initially empty. In either case, you will then be able to edit that program. The second time you select a program for BACKGROUND EDIT without stopping the running program, you will get the message SECOND EDIT.

When you are in BACKGROUND EDIT and the running program finishes, the display will automatically change to the PROGRAM DISPLAY and will show the program that just finished running. To continue editing your program, you must select it with LIST PROG and then display it in EDIT mode.

BACKGROUND EDIT is not available from MDI or from DNC operating modes.

Deleting Programs

To delete an existing program, you must be in LIST PROG mode. The programs will be listed here by program number. Use the CURSOR **up** or **down** keys to highlight the program number, or type in the program number at the blinking cursor, then press the ERASE PROG key.

All the programs in the list may be deleted by selecting ALL at the end of the list and pressing the ERASE PROG key. Use caution when deleting single programs, and read all prompts, to ensure that ALL programs are not selected. The UNDO key will not recover programs that are deleted.

38

SPECIAL FUNCTION KEYS

The F1, F2, F3, and F4 buttons perform different functions depending on what display and mode are selected. The following is a quick summary of the **Fn** buttons:

- F1 In EDIT mode and PROGRAM DISPLAY, this will start a block definition. In LIST PROG mode, F1 will duplicate a program already stored and give it a new name from the command line. In OFSET display, F1 will set the entered value into the offsets.
- F2 In EDIT mode and PROGRAM DISPLAY, this will end a block definition. In OFSET display, F2 will set the negative of the entered value into the offsets.
- F3 In EDIT and MDI modes, the F3 key will copy the highlighted circular help line into the data entry line at the bottom of the screen. This is useful when you want to use the solution developed for a circular motion. Push INSERT to add that circular motion command line to your program. In the calculator HELP function, this button copies the value in the calculator window to the highlighted data entry for Trig or Circular Help.
- F4 When in EDIT mode with no program running, entering **Onnnnn** in the input line and pressing F4 will change the program being edited to **Onnnnn**.

When in MEM mode and PROGRAM DISPLAY, F4 can be pressed to select either BACKGROUND EDIT or PROGRAM REVIEW. BACKGROUND EDIT is selected by entering the program number at the input line and pressing F4. BACKGROUND EDIT can only be selected when a program is running. PROGRAM REVIEW can be selected whether or not a program is running, simply by pressing F4. If a program is running, PROGRAM REVIEW will show the running program on the left half of the screen, and allows the operator to review the program on the right half of the screen.

In the calculator HELP function, F4 uses the highlighted Trig, Circular, or Milling data value to load, add, subtract, multiply or divide with the calculator.

THE UNDO KEY

A very powerful keyboard button available in this control is the UNDO button. When editing, this button will allow you to basically undo any changes or edits you have made but wish you had not. Any time you use the INSERT, ALTER, or DELETE buttons, the condition of the original block is saved and can be restored with the UNDO button. In fact, the previous nine changes can be undone in the opposite order that they were entered by pressing the UNDO button for each change that is to be backed out.

The UNDO button can be used in EDIT, BACKGROUND EDIT, and MDI. However, if you change operating modes between EDIT and MDI, you cannot use the UNDO button because the list of saved data is cleared.

BLOCK OPERATIONS

Block operations can be performed on a group of one or more blocks of the program. These operations include BLOCK DUPLICATE, BLOCK MOVE, and BLOCK DELETE. Prior to a block being defined, the bottom right of the screen shows how to define a block; the F1 key is pressed when the cursor is on the first line of the block and the F2 key is pressed when the cursor is on the last line of the block.

Once a block is defined, the lower right of the screen shows how to manipulate the block; the INSERT key is used to duplicate the defined block wherever the cursor is positioned, the DELETE key is used to delete the block, the ALTER key is used to move the block, and the UNDO key cancels the block definition.





When a block is defined, the cursor is indicated by the " > " symbol and is always at the beginning of a line. When a block is copied or moved, the lines are added after the block with the cursor. Only whole command lines may be moved with the block functions.

Parts of programs can be copied from one program to another with the block copy feature. This is done by highlighting the section of code that is to be copied using the F1 and F2 keys. Once a section of code is highlighted, you then change to another program by selecting an existing program or creating a new one. Cursor to the location where the previously defined block is to be inserted and press the INSERT or WRITE key. A copy of the defined block will be inserted into the current program and the copied code segment becomes the currently-defined block. Press the UNDO key to exit the BLOCK COPY mode.

Blocks of code can be copied into an MDI program, but blocks of code cannot be copied from an MDI program into another program. You can always rename the MDI program and then copy its text to any other program in the manner described above.

2.16 Part Program Input / Output

RS-232 DATA INPUT / OUTPUT

Programs are sent or received through the first RS-232 port located on the rear control box pendant side. All data sent or received is ASCII. In order to use this port, you will need to obtain a cable and connectors with the following wiring:

pin #1Shield Groundpin #2 TXD-Transmit Datapin #3RXD-Receive Datapin #4 RTS (optional)pin #5CTS (optional)pin #7 Signal GroundCables for the RS- 232 must be shielded.

The following lists baud rate and the respective maximum cable length. This list assumes proper cable shielding and no signal boost.

9,600 baud rate: 100 feet (30 m) RS-232 38,400 baud rate: 25 feet (8 m) RS-232 115,200 baud rate: 6 feet (2 m) RS-232

It is possible to use RS-232 to RS-422 converters on each end of the cable to accomodate longer cables at up to 115,200 baud. Proper twisted pair wire greatly improves reliability and increases maximum distance. A pentium processor should be used for a baud speed of 115,200.

25-25 Pin Cable



F Operator's Manual

9-25 Pin Cable



All other pins are optional and are not usually used. The RS-232 connector is a DB-25 and is wired as a DTE. This means that we send data on the TXD wire and receive data on the RXD wire. If you do not understand this, your dealer will be glad to help. The simplest connection would be to an IBM PC, which can be done with a standard cable made up of a DB-25 male on one end and a DB-25 female on the other. Pin 2 at one end is wired to pin 3 at the other end, pin 3 is wired to pin 2, and pin 7 is wired to pin 7.

All RS-232 data is ASCII but the number of bits, parity and speed can be changed from settings. The number of data bits is selected with Setting 37 for either 7 or 8. Parity is selected with Setting 12 and is none, even, odd, or zero. Zero parity will always set the parity bit to 0. The data speed is selected with Setting 11.

Once the connection to your computer has been made and verified, go to the Setting page and set the baud rate, parity, number of stop bits, end of block (EOB) format, and leader parameters to match your requirements.

All programs sent to the control must begin with a line containing a single % and must end with a line containing a single %. All programs sent by the control will have these % symbols.

To receive a program, push the LIST PROG key. Move the cursor to the word ALL and push the RECV RS-232 key and the control will receive all main and sub programs until it receives a % sign indicating end of input. Please note that when using "ALL", all your programs must have an address **Oxxxxx** to be filed. If you do not have a program number, type in a program number before you push RECV RS-232 and the program will be stored under that number. You can also select an existing program for input and it will be replaced. An ASCII EOF character (code 04) will also terminate input. The colon character (:) may be used in place of the **O** for a program name, but it is always displayed as **O**.

When receiving RS-232 data, there is a status message at the bottom of the screen. It will update as follows:

WAITING	When you first press RECV RS-232.
LOADING XXX	When first % is received; if in XMODEM, XXX is the current block being loaded.
LOADING Onnnnn	When program name is received.
RS232 DONE	When complete and last % is received.
RS232 ABORT	When anything causes an abnormal stop.





To send a program, use the cursor as above to select the program and push the SEND RS-232 key. You can select "ALL" to send all of the programs in memory. A setting can be turned on to add spaces to the RS-232 output and improve the readability of your programs.

The synchronization protocol used to send data to slower computers is selected from the Setting 14. Setting 14 may be set to XON/XOFF, RTS/CTS, DC CODES, or XMODEM. Transmission can be stopped with either the XON/XOFF characters or the RTS/CTS wires.

Parameters, settings, offsets, and macro variables pages may also be sent individually via RS-232 by selecting the "LIST PROG" mode, selecting the desired display screen, and pushing the SEND key. They can be received by pushing the RECV key.

The settings that control RS-232 are:

- 11 BAUD RATE
- 12 PARITY
- 13 STOP BITS
- 14 SYNCHRONIZATION
- 24 LEADER TO PUNCH
- 25 EOB PATTERN
- 37 NUMBER DATA BITS

The EOB (semicolon) character is not normally sent by the RS-232 port. If it is received by the input port, it will cause a blank line in the program.

The format of data sent and received for parameters, settings, and offsets is the following:

% N0 Vnnnnn N1 Vnnnnn N2 Vnnnnn

:

%

The following table shows the use of the N numbers in the output file when offsets are saved to RS-232 or disk.

Tool length:

0				
Tool/function	length	wear	diameter	wear
1	001	201	401	601
2	002	202	402	602
3	003	203	403	603
:	:	:	:	:
200	200	400	600	800

G Operator's Manual

The nnn numbers for work offsets are as follows:

Offset/axis	Х	Y	Z	А	В
G52	801	802	803	804	805
G54	806	807	808	809	810
G55	811	812	813	814	815
:	:	:	:	:	:
G59	831	832	833	834	835
G110	836	837	838	839	840
G111	841	842	843	844	845
:	:	:	:	:	:
G128	926	927	928	929	930
G129	931	932	933	934	935

The nnnn numbers for coolant spigot positions are as follows:

1	936
2	937
3	938
:	:
200	1135

The format of data sent and received for macro variables is the same as above, except there is a line N9999 and no line N0. The **N** number is the data number and **V** is the value. N0 is a CRC code that is computed by the control prior to sending the data. The N0 value is mandatory with parameters but is optional with settings and offsets. If you make a change to some saved data value and leave the old CRC, you will get an alarm when you try to load that data. With settings and offsets, you should delete the N0 line if you make changes to the saved data.

NOTE: Data will be loaded even though an alarm has been generated.

Data that is received garbled is usually converted into a comment and stored your program while an alarm is generated. In addition, any parity errors or framing errors will generate an alarm and they will also stop the receive operation.

At the end of a send or receive function, the bottom left corner of the display will show either "RS232 DONE" for normal completion or "RS232 ABORT" if any errors cause it to stop. The actual errors are listed in the ALARM display.

The Haas CNC serial ports optionally support the full DC1, DC2, DC3, DC4 code sequence that is compatible with paper tape readers and punches. Setting 14 is used to select this mode of operation. Setting 14 can be set to "DC CODES". When this setting is selected, the following occurs:

- 1. When sending out of the serial port, a DC2 (0x12) will precede all other data. This code is used to turn on a paper punch.
- 2. When sending out of the serial port, a DC4 (0x14) will follow all other data. This code is used to turn off a paper tape punch.
- 3. When receiving from the serial port, a DC1 (0x11 Xon) is sent first. This code is used to turn on a paper reader.
- 4. When receiving from the serial port, a DC3 (0x13 Xoff) is sent after the last % is received. This code is used to turn off a paper tape reader.

-111415-



Note that the Setting 14 selection XON/XOFF is similar to the "DC CODES" selection. Both of these settings use the DC1/DC3 XON/XOFF codes to start/stop the sender when data is received too fast. When DC CODES is selected for Setting 14 (synchronization), serial port #1 will transmit an XON (DC1) if a character has not been received for five (5) seconds.

XMODEM may also be selected in setting 14. It is a receiver-driven communications protocol that sends data in blocks of 128 bytes. Setting **synchronization** to XMODEM gives your RS-232 communication an added level of reliability because each block is checked for integrity. If the receiver determines that the most recently sent block is in error, it will request that the sender try to send the block again.

In order to use XMODEM, parity must be none, and RS-232 data bits must be set to 8. Also, the computer that is sending the data must be equipped with a communications package that supports the XMODEM protocol. It must be set to XMODEM to operate.

This version of XMODEM supports **checksum** verification only. Also, 512 bytes of memory must be available before using XMODEM with DNC. XMODEM must use 8 data bits and no parity.

WARNING!

One of the biggest causes of electronic damage is a lack of a good earth ground on both the CNC <u>and</u> the computer that are connected by RS-232. A ground fault condition (i.e., a lack of good ground on both) will damage the CNC or the computer, or both.

Port #2 on the side cabinet is dedicated to auxiliary axes communication.

DIRECT NUMERICAL CONTROL (DNC)

As a standard feature, this machine is shipped with a DNC capability. With DNC, there is no limit to the size of your CNC programs. The programs are directly executed by the control as they are sent over the RS-232 interface. Note that this is the first serial port or the top connector. Do not confuse DNC with RS-232 uploading and downloading.

If you wish to use DNC, it is enabled by Parameter 57 and Setting 55.

When enabled, DNC is selected by pressing MDI a second time when already in MDI. DNC mode will not be enabled unless there is a minimum of 512 bytes of user memory available. When DNC is selected, the PROGRAM DISPLAY will show:

WAITING FOR DNC...

This means that no DNC data has been received yet and you may begin sending data. You must start sending the program to the control before the CYCLE START button can be pushed. After the beginning of the program is seen by the control, the display will show part of the program and a message at the bottom, left of the CRT will show DNC PROG FOUND. After the program is found, you may push CYCLE START just like running any other program from Memory.

If you try to press CYCLE START before receiving a program, you will get the message: NO DNC PROG YET. The reason for not allowing CYCLE START command before receiving the DNC program is safety. If the operation is allowed to start from a remote location, the operator may not be present to ensure that the machine is operating safely.

NOTE: Floppy disk DNC is selected by entering the floppy disk file name and pressing MDI a second time when already in MDI mode. Do not press MDI **three** consecutive times or a "DISK ABORT" will result.

While a DNC program is executing, you are not allowed to change modes. You must first press RESET to stop the program.

When the end of the DNC program is received, the message DNC END FOUND is displayed. When the DNC program is finished running, the PROGRAM DISPLAY will show the last few lines of the program. You must press RESET or exit the DNC mode before you can run any other programs. If you try to press CYCLE START before RESET of the previous DNC, you will get the message: RESET FIRST.

DNC supports Dripmode. The control will execute one block at a time from the RS-232 port. Each block entered will be executed immediately with no block look-ahead buffering. The exception is that Cutter Compensation requires three blocks of motion commands to be buffered prior to a compensated block being executed.

There are several restrictions on what can be in a DNC program. An M30 is not allowed as it is not possible to start over at the beginning. Canned cycles G70, G71, G72, and G73 cannot be programmed while in DNC, since they require the control to look ahead.

The program must begin with a %, just like any other program sent over RS-232, and the program must end with a %. The data rate selected for the RS-232 port by Settings must be fast enough to keep up with the rate of block execution of your program. If the data rate is too slow, the tool may be stopped in a cut when you might otherwise expect continuous cutter motion. The highest standard RS-232 data rate available is 115,200 bits per second.

It is recommended that DNC be run with Xmodem or parity selected because an error in transmission will then be detected and will stop operation of the DNC program without crashing. The settings page is used to select parity. The recommended RS-232 settings for DNC are:

9600 or 19200 BITS PER SECOND EVEN PARITY 1 STOP BIT XON/XOFF

Full duplex communication during DNC is possible by using the G102 command or DPRNT to output axes coordinates back to the controlling computer. When DNC is running, BACKGROUND EDIT is not available.

To run DNC in graphics, you must select DNC first , then go to graphics display and send your program to the CNC.

FLOPPY DISK OPERATION

All files must be on MS-DOS formatted 1.44M floppy disks and must reside in the root directory. Parameter 209 DISK ENABLE must be 1.

NOTE: In order to enable the floppy disk drive, an unlock code must be entered. If necessary contact the Service Department for more information.

NOTE: Use an empty (containing no other files) floppy disk for faster operation.

All programs must begin with a line containing a single % and must end with a line containing a single %. All programs saved by the control will have these % symbols.





Programs may be loaded and saved from the floppy disk. To **LOAD** a program, press the LIST PROG key with PRGM selected. Enter the floppy disk file name and press F3 and the control will receive all main and sub programs until it receives a % sign indicating end of input. Please note that when using "ALL", all your programs must have an address **Oxxxx** to be filed. An ASCII EOF character (code 04) will also terminate input. The colon character (:) may be used in place of the **O** for a program name, but it is always displayed as **O**.

When loading floppy disk data, there is a status message at the bottom of the screen. It will update as follows:

LOADING Onnnnn	When program name is received.
DISK DONE	When complete and last % is received.
DISKABORT	When anything causes abnormal stop.

To **SAVE** a program to floppy disk, press the LIST PROG key with PRGM selected. Enter the floppy disk file name, use the cursor as above to select the program, and press the F2 key. You can select "ALL" to send all of the programs in memory.

NOTE: Setting 23 must be off.

Parameters, *Settings*, *Macro Variables*, and *Offsets* may also be sent individually to the floppy disk by selecting the "LIST PROG" mode, entering the floppy file name, selecting the desired display screen (PARAM, SETNG, OFSET, or the Macro Variables page of CRNT CMDS), and pressing the F2 key. They can be received by pressing the F3 key.

If an EOB (semicolon) is loaded, it will cause a blank line in the program.

The format of data sent and received for settings, offsets, and parameters is the following:

% N0 Vnnnnn N1 Vnnnnn N2 Vnnnnn .

%

The following table shows the use of the N numbers in the output file when offsets are saved to RS-232 or disk.

Tool length:

Tool/function	length	wear	diameter	wear
1	001	201	401	601
2	002	202	402	602
3	003	203	403	603
:	:	:	:	:
200	200	400	600	800

G Operator's Manual



The nnn numbers for work offsets are as follows:

Offset/axis	Х	Y	Z	А	В
G52	801	802	803	804	805
G54	806	807	808	809	810
G55	811	812	813	814	815
:	:	:	:	:	:
G59	831	832	833	834	835
G110	836	837	838	839	840
G111	841	842	843	844	845
:	:	:	:	:	
G128	926	927	928	929	930
G129	931	932	933	934	935

The nnnn numbers for coolant spigot positions are as follows:

1	936
2	937
3	938
:	:
200	1135

The **N** number is the data number and **V** is the value. N0 is a CRC code that is computed by the control prior to sending the data. The N0 value is mandatory with parameters but is optional with settings and offsets. If you make a change to some saved data value and leave the old CRC, you will get an alarm when you load that data. With settings and offsets, you should delete the N0 line if you make changes to the saved data.

Data that is received garbled is usually converted into a comment and stored into your program while an alarm is generated. Errors generating an alarm may also stop the receive operation.

To get a **DIRECTORY LISTING**, select the PRGM/LIST PROG mode, and press F4. This will generate a Disk Directory Listing that will be saved in program 0xxxx where xxxx is defined in parameter 227. The default value is 8999.

On the List Prog page, type "DEL <filename>" where <filename> is the name of a file on the floppy disk. Press WRITE. The message "DISK DELETE" will appear, and the file will be deleted from the floppy disk.

At the end of a save or load function, the bottom left corner of the display will show either: "DISK DONE" for normal completion or "DISK ABORT" if any errors cause it to stop. The actual errors are listed in the ALARM display.





Printing from Haas Machines

Important! You must have a serial cable and serial printer that is compatible with the Haas controller.

Setting up the Printer

- Plug in the printer power cord.
- Plug the printer into the control in the RS232 port.
- Turn on the printer.
- Make sure the following settings are correct.

Note: Write down the old settings in case you to need change them back later.

The Machine Settings for Printing

- Setting #11 9600 (Baud)
- Setting #12
 None (Parity)
- Setting #13 1 (Stop Bit)
- Setting #14 Xon/Xoff (synch)
- Setting #37 8 (Data Bits)

Printing Rules

- The program must be in memory. A program cannot be printed in MDI.
- A program cannot be printed while it is running.

Printing a Program

- Make sure the printer is turned on.
- Make sure there is paper in the printer.
- Go to "List Programs".
- Highlight the program to be printed.
- Push "Send RS232.
- To get the last page of the program out, push the paper feed button on the printer.

2.17 DRY RUN OPERATION

The DRY RUN function is used to check a program quickly without actually cutting parts. DRY RUN is selected by pressing the DRY RUN button while in MEM or MDI mode. When in DRY RUN, all rapids and feeds are run at the DRY RUN speed selected from the JOG speed buttons. The bottom of the screen will display the rate as 100, 10, 1.0 or 0.1 inches per minute.

DRY RUN cannot be turned on while a program is running. It can only be turned on or off when a program has completely finished or is reset. The first push of the DRY RUN button turns on this function and the second push will turn it off again. DRY RUN will still make all of the requested tool changes. The speed used in DRY RUN can be changed at any time and the operator can then check that the motions that are programmed are exactly what were intended. Note that Graphics mode is just as useful and may be even safer since it does not begin moving the machine before the program is checked.

2.18 DISPLAYS

You can select any of the following displays using the eight DISPLAY select buttons:

PRGRM / CONVRS	To show or edit the program selected OR to select conversational mode (Quick Code)
POSIT	To show the axes' positions.
OFSET	To show or enter working offsets.
CURNT COMDS	To show current commands and times.
ALARM / MESGS	To show alarms and user messages.
PARAM / DGNOS	To show parameters and diagnostic data.
SETNG/GRAPH	To show or enter settings OR to select graphics simulation mode.
HELP / CALC	To show the help data and calculator.

In addition, when a program is running, you may press LIST PROG to select a list of the programs in memory. This is helpful in determining which programs can be edited in BACKGROUND EDIT, which is selected from the PROGRAM display.





- 96-8000 rev E

Messages

The screen will ALWAYS show some of the current conditions selected in the control. These are fixed status displays that describe the condition of the machine. The following conditions are displayed on the screen:

The selected display in the top left corner; The selected mode in parentheses;			
The selected pro	ogram in the top right corner;		
The most recent line number in the top right corner;			
Up to 18 lines of variable display data;			
Any of the follow	ving conditions that apply:		
ALARM	Blinking in lower right corner when alarm occurs.		
BLKDEL	BLOCK DELETE is turned on.		
BUF	When next block is ready in continuous path.		
CS TO CONTINUE	Indicates program will continue after pressing CYCLE START.		
DRYRUN	DRY RUN is selected.		
DWELL	When a G04 is being performed.		
FEED	When a feed motion is in progress.		
FEED %	Feed rate override is active.		
FEED HOLD	FEED HOLD is active.		
INDEXING	In index mode with X,Y or Z axis in motion.		
INSERT TOOL <nn></nn>	Tool change is commanded by M06.		
JOG INDEX ON	When in INDEX JOG mode		
OPTSTP	OPTIONAL STOP is turned on.		
PRESS +a OR -a	(a = X,Y or Z) Jog key for another axis has been pressed.		
RAPID %	Rapid override is active.		
RUNNING	When a program is running.		
SAFETY HOLD	An open door has stopped the program.		
SETTING 104 ON	SETTING 104 and HANDLE CONTROL FEED RATE or HANDLE		
	CONTROL SPINDLE pressed.		
SINGBK	SINGLE BLOCK is turned on.		
SINGBK STOP	When a program is stopped in SINGLE BLOCK.		
SPIND %	Spindle speed override is active.		
TOOL UNCLP	Reverse video when the tool is unclamped.		
XY-MANJOG	Displays appropriate axis.		
XYZA-MIR	These axes are set to mirror image.		

The following error messages are received when the wrong button is pressed.

ALARM ON ALTER ARM NOT LEVEL	Cannot start an operation until alarms are reset. The selected text can now be altered. During a manual tool change recovery the operator attempted to rotate the arm and the tool arm was not extended out, or retract the tool arm in and the arm was not rotated all the way clockwise or counter-clockwise.
AUX AXIS BUSY	One or more auxiliary axes are busy in an operation.
BAD CODE	Code entered is not understood.
BAD FILE NAME	Not a valid file name.
BAD NAME	Name entered is not Onnnnn.
BLOCK TOO LONG	Block being edited would be too long.
CAN NOT COPY	The selected program cannot be copied.
CAN'T RENAME	The selected program cannot be renamed.
CAN'T UNDO!	The last function cannot be undone.
CNVEYR DISABLED COOLANT OFF COOLANT ON	Chip conveyor has been disabled by parameters. Coolant pump is off. Coolant pump is on.



Operator's Manual



DEL ALL (Y/N) ?	Delete all, yes or no ?
DELETE	Deleting text as requested.
DIR FULL	Maximum number of programs exceeded.
DIR NOT FOUND	Directory of floppy disk not found.
DISKABORT	Something caused an abnormal stop.
DISK DIR	The directory of files on the floppy disk.
DISK DONE	When complete, and last % is received.
DISK FOUND	Floppy drive is present.
DISK NAME REQ	Floppy disk file must be named.
DISK NOT ENBLED	Floppy disk drive has not been enabled by parameters.
DISK NOT IN DRV	No disk in floppy disk drive.
DISK NOT RDABLE	Floppy disk cannot be read by control.
DISK READ	Reading from floppy drive.
DISK WRITE	Writing to floppy drive.
DISK WRT PROTECT	Cannot save to floppy disk, it is write protected.
DISPLAYS OFF	Indicates that M76 was used to turn off displays.
DIVIDE BY ZERO	An attempt was made to divide by zero in calculator mode, or system error exists.
DNC END FOUND	The end of a DNC program has been found.
DNC PROG READY	The DNC program is ready to run.
EMPTY PROG	No program found between the % and %.
END FOUND	End of program has been received.
END OF PROG	The program being run has completed.
EOF FOUND	End of file is found.
EXIT BG EDIT	Must exit Background Edit mode to perform this function.
FILE NOT FOUND	The file was not found.
FUNCTION ABORT	Requested function has been aborted.
FUNCTION LOCKED	Function attempted is locked from settings.
GUARDED CODE	Cannot remove Onnnnn at start of program.
INSERT	Selected text now being inserted
INSUE DSK SPACE	Insufficient disk space to save the selected file
INVALIDAXIS	Selected axis is invalid.
INVALID NUMBER	Number entered is invalid.
JOGCOMD	An axis log has been commanded
LOADING	Reading programs or data from RS-232
LOW AIR PR	Air pressure is low
LOW COOLANT	Low level in coolant tank
	Front panel has been locked by setting
MACROLOCKED	Macros 9000 to 9099 are locked by setting
MEMORY FULL	Memory space is full
MEMORYLOCKED	Memory lock is set in settings
NEW PROGRAM	A new programa may be entered
	Cannot find the floppy disk drive
NO DNC PROG YET	Attempted to start program before it was completely received
	Cannot alter until something has been entered
	No file name has been entered
	Cannot press Cycle Start until a program is received
	Cannot run machine until search for zero is complete on A axis
	Cannot run machine until search for zero is complete on X axis.
	Cannot run machine until search for zero is complete on V axis.
	Cannot run machine until search for zero is complete on 7 axis.
	Function requested is not available at this time
	r unclion requested is not available at this time. Itom not found during sourch in aditor
	item not round during search in editor.



NOT IN DRYRUN The function requested applies to DRY RUN, but control is not presently in that mode. ONE BIT ONLY Only 0 or 1 is accepted to alter a parameter switch. Program name being selected cannot be ALL. ONE PROG ONLY **OPTION DISABLED** Requested axis has been disabled, and cannot be jogged. OVERWRITE (Y/N) Do you want to overwrite the file, yes or no? PLEASE WAIT Wait until spindle is stopped. **PROG EXISTS** Cannot rename to an existing program. PROG NOT FOUND Requested program not in memory. Program has been received and is ready to run. PROG READY PROGRAM END Cannot remove last EOB in program. **PROGRAM IN USE** Program is already in use. Data being entered is outside of the valid range. RANGE ERROR RESET FIRST Must press RESET before performing this function. Rigid tapping is being performed. **RIGID TAP** RS-232 ABORT RS-232 was aborted by operator action. **RS-232 DONE** RS-232 operation is complete. RS-232 error (shown in alarms). **RS-232 ERROR** SAFETY SW OPEN The door is open; some functions not allowed. SEARCHING ... Searching program for requested text or G code. High gear selected in program. SEL HI GEAR SEL LOW GEAR Low gear selected in program. SENDING OFFSET Sending offsets via RS-232. SENDING PARS Sending parameters via RS-232. SENDING SETTING Sending settings via RS-232. Sending variables via RS-232. SENDING VARS SENDING ... RS-232 output is in process. SERVO IS OFF When servos are off, you cannot start a program. SERVO IS ON! Parameter change was attempted with servo on. This is dangerous! Tool changer is in position for a tool change. SHUTTLE IN SHUTTLE NOT HOME The control is preventing the operator from zeroing the machine. Move the tool shuttle to the "Standby Position"; this is the only safe place for the shuttle to be when zeroing the machine. SPEED COMD A spindle speed must be commanded. SPINDLE CCW Spindle is turning counterclockwise. SPINDLE CW Spindle is turning clockwise. Spindle is in high gear. SPINDLE HIGH SPINDLE IN USE Spindle is being controlled by program - manual controls not available at this time. SPINDLE LOCKED Spindle is locked in place. SPINDLE LOW Spindle is in low gear. SPINDLE ORI Spindle is being oriented. SPINDLE STOP Spindle is not turning. STRING TOO LONG The text being entered is too long. SYSTEM ERROR Call your dealer. **TC MOTION** This message is intended to let the operator know that the tool changer arm or chain is in motion. TOOL CH LOCKED Tool changer has been disabled by parameter 57 bit 1. TOOL CLAMP The tool is in the spindle. TOOL OVERLOAD Cutting tool is overloaded. The tool has been unclamped. TOOL UNCLAMP The tool changer is in position for a tool change. TURRET IN The tool changer is out of position for a tool change. TURRET OUT

111115-

VF Operator's Manual



is

WAIT OR RESET	Cannot perform requested function until program finishes or RESET pressed.
WAIT	Requested function is being performed.
WAITING	Waiting for RS-232 input.
WRONG MODE	Function requested is available only in another mode.

And the following responses are received only in graphics mode:

CIRCULAR	A circular motion is being performed.
LINEAR	A linear motion is being performed.
M30 FOUND	End of program found and execution stopped.
M00 AFTER M06	Cannot have an M00 after M06.
NO ZOOM IN 3D	Zoom is not allowed in 3D graphics mode.
RAPID	A rapid motion is being performed.

In addition, the screen display can show one of the following eight types of data in the 18 lines of variable display

Program Displays:

The PROGRAM DISPLAY is used to show your program in either MEM, EDIT, or MDI modes.

Position Display:

The POSITION DISPLAY is used to select the **X**, **Y**, **Z**, or **A** axis positions in any of several coordinate systems. The PAGE UP and PAGE DOWN keys select between these.

Offsets Display:

The OFFSETS DISPLAY is used to enter and display tool length offsets, tool radius offsets, coolant positions, and work offsets. The PAGE UP and PAGE DOWN keys will scroll between these.

Current Commands Display:

The CURRENT COMMANDS DISPLAY is used to display the Program Command Check, the Current Commands, Running Timers, Tool Life Timers, Tool Load Monitor, and Axis Load Monitor. The PAGE UP and PAGE DOWN keys select between these.

Alarms / Messages Displays:

The ALARMS/MESSAGES DISPLAY is used to display alarms and to enter and display user messages. The second push of the ALARM button will select messages display. The CURSOR **up** and **down** buttons will display additional alarms if there is more than will fit on one page. The Left or Right arrow key will display the alarm history.

Parameters / Diagnostics Displays:

The PARAMETERS DISPLAY shows all of the machine-dependent control parameters and the diagnostic data. The second push of the PARAM / DGNOS button will select the diagnostic display. The PAGE UP, PAGE DOWN, up and down cursor keys, and the jog handle can be used to scroll through the parameter display screens in the control. The left and right cursor keys are used to scroll through the bits in a single parameter.

Settings / Graphics Displays:

The SETTINGS DISPLAY is used to display and change user-controlled parameters. The second push of the SETNG / GRAPH button will select the Graphics display.

Help / Calculator Displays:

The HELP DISPLAY shows a mini-manual on the CRT along with a directory of available help information. Each alphabet button will select a different topic within the HELP display. The second push of the HELP button will select the Calculator display. The PAGE UP and PAGE DOWN buttons will select different calculator functions.

96-8000 rev E

-1.11.145-





PROGRAM **D**ISPLAYS

The PROGRAM DISPLAY is used to show a program being edited in EDIT mode or a program being run in MEM. In MEM mode, there is also a PROGRAM REVIEW display available.

The PROGRAM DISPLAY uses 18 lines of the text display area of the CRT to show the command blocks of a CNC program. The display is 40 positions wide and blocks that are longer than 40 positions are continued on the next line of the display.

The PROGRAM REVIEW function is available whenever a program is being run. This allows you to review the program that is running. This is selected by pressing F4 while in MEM mode and PROGRAM DISPLAY. The screen is changed to an 80-column display with the normal MEM display on the left and PROGRAM REVIEW on the right. The CURSOR and PAGE UP and PAGE DOWN keys can be used to change the display on the right to a different part of the program. The display on the left will show the progress of the running program. To exit PROGRAM REVIEW, select any other display.

While you are running a program, the BACKGROUND EDIT function is available as a standard feature. BACK-GROUND EDIT allows you to edit any named program in memory while any program is being run in memory. BACKGROUND EDIT is selected from MEM mode in PROG display by entering **Onnnn** with the program number and pressing F4. The display will change to the selected program while still running the first program. BACKGROUND EDIT is enabled by parameters in your machine.

POSITION **D**ISPLAYS

The following are the five position displays in this control:

Home Page

This display shows the four displays simultaneously in small characters. The other displays are shown in large characters. The PAGE UP and PAGE DOWN keys will change displays. The coordinates displayed (operator, work, machine, or distance to go) are selected using the cursor **up** and **down** keys. The last display selected will be shown in CURNT COMDS and SETNG / GRAPH displays when they are selected. In this display, any axis that is at the zero position will be highlighted. In the other four displays, the selected axis will be blinking.

Operator Display

This display is for the operator/setup person to use as desired, and is not used by the control for any positioning functions. In JOG mode, and with this display selected, the ORIGIN button can be used to set the zero position. This display will then show position relative to the selected zero position.

Work Display

This display shows how far away the tool is from the **X**, **Y** and **Z** zeros of the programmed part. On power-up, it will display the value in work offset G54 automatically. It can only be changed by G54 through G59, G110 through G129, or by a G92 command. The machine uses this coordinate system to run the part.

Machine Display

This display is the machine coordinate system that is automatically set on power-up and the first ZERO RET. It cannot be changed by the operator or any work coordinate systems, and will always show the distance from machine zero. It can be used by a non-modal G53 command.

Distance To Go

This display is an incremental display that shows the travel distance remaining before the axes stop. When in the ZERO RET mode, this display shows a diagnostic value. When in JOG mode, this display shows the total distance jogged. In rigid tapping, this number decreases to zero at the bottom of the hole and then increases again as the reverse stroke occurs.

54



OFFSETS DISPLAY

Tool length and part zero offsets are displayed and can be entered in the Tool Offsets display. The same offset number for both the Z axis offset (H1) and tool diameter compensation (D1) can be used, because the offset contains separate values for each. Work offsets can also be specified for the fifth-axis **B** address, in the work offset display. If the fifth axis is enabled (Setting 78), then additional data fields are made available for the fifth axis.

PAGE DOWN in the OFSET display will go through all possible tool offsets and then change to the work zero offsets. PAGE UP will go directly to work zero offsets. The jog handle can also be used to scroll through the offsets. Work zero offsets may be entered and displayed from this page or using the PART ZERO SET key. Refer to the "Setup Procedures" section for more information on using this key.

When entering offsets, pressing F1 will set the value of your entry. Pressing WRITE will cause the new value to be added to the old value. This allows small adjustments to be made to the offsets. Note that entering a negative entry and pressing WRITE will decrease the value of the offset. F2 will set the negative of the entered value into the offsets.

There is a geometry value and a wear value with each offset and these are added together by the control during operation. The initial value is entered into the geometry column by the setup person. During operation, the operator makes minor wear changes in the wear column. This method allows the operator to see actual tool wear by limiting it to the wear column. The geometry values can also be entered automatically by using the TOOL OFSET MESUR key during setup procedures. Note that this automatic offset measurement works with G43 only. Refer to the "Setup Procedures" section for more information on using the TOOL OFSET MESUR key.

The function of the offset display page has been modified slightly to accommodate multiple axes. Only the axes that are enabled are displayed on the work offset display. For example, if the fourth axis is enabled (Setting 30), and the fifth axis is not, then the display will show X,Y,Z,A. In this case, all axes can be displayed on the entire display. If only the fifth axis is enabled, then the display will show X,Y,Z,B. Since the fourth axis is disabled, there is no need to display it.

If both the **A** and **B** axes are enabled, then the last column of the offsets display serves a dual purpose. Either **A** or **B** can be accessed in the last column. By using the **left** or **right** arrow keys, the screen cursor can be moved into the axis field that is to be set. When the rightmost field is highlighted by the cursor and the top of the column indicates **A**, then the values in this column represent **A** axis offsets. If you press the **right** arrow key once, the cursor stays in the same place, but the column and its values will change to **B** axis parameters. You can view and modify work offsets in this manner using the **left** and **right** arrow keys when both axes are enabled.

Setting 15, "H & T Code Agreement," may be used to force the spindle tool number and offset number to be equal; otherwise an alarm will occur. This is the preferred setting, as it avoids crashes.

Tool diameter may be entered as either radius or diameter. Setting 40 is used to select between these. The value used for cutter compensation is the sum of the geometry and wear values. The number of flutes on each tool can be entered. This is used in the calculation of Chip Load. The default is two, the number of flutes for each tool will also be set to two when the ORIGIN key is pressed while this screen is displayed.

Cutter compensation is controlled by G41 and G42 and the selected tool diameter (D value). Positive values for cutter compensation work normally. Negative values for cutter compensation cause the opposite side cutter compensation to be used. This means that G41 with a negative number will be the same as G42 with the same, but positive, number.

Offsets may be sent and received with the RS-232 port. Refer to the "Data Input / Output" section for a description of how to do this.





When the COOLANT SPGT of Parameter 57 is enabled, the CLNT POS column of the offset display is accessible. The spigot can be positioned when an M08 is encountered in a program. The current **H** code is used by the M08 to determine where to position the coolant spigot. If offset #5 (H05) has **10** entered under the CLNT POS column, the spigot will be moved to position 10. When the cursor is positioned on the CLNT POS column, the current spigot position will be shown at the bottom of the display. If the spigot has not been zeroed, the position will be blank.

The permissible values that can be entered into this column are controlled by Parameter 206, SPIGOT POSI-TIONS. Entering a value of zero (0) indicates that the spigot will not be moved when an M08 code sequence is encountered.

The following code sequence demonstrates how the spigot can be commanded:

NOTE: The tool length number.	and radius offset numbers usually are the same as the tool
O0001 T1 M06	(Sample coolant positioning)
G43 H01 Z_M08	(Moves spigot to H1 position)
T2 M06	
G90 G54 X_Y_S900 M03 G43 H02 Z_M08	(Moves spigot to H2 position)
G43 H42 Z.1M08	(Position to new location with a second offset H42)
	(More than one offset number can be used for a tool if needed)
M30	

CURRENT COMMANDS DISPLAY

The following are the seven current command displays in this control:

Program Command Check (Home Page) Current Display Command Operation Timers Macro Variables Tool Life Timers Tool Load Monitor and Axis Load Monitor.

The PAGE UP and PAGE DOWN keys are used to select among these displays.

Program Command Check Display

This display, which is the Home Page for the Current Commands Display, shows a current overview of the important commands. It shows the programmed spindle speed (**Snnnn**), the spindle speed commanded to the spindle drive (**CMDnnnn**), and if Parameter 278 bit ACT DISPLAY is set to 1, the actual encoder spindle speed (**ACTnnnnn**). In addition, this display shows the CW, CCW, or stopped command being sent to the spindle and the current gear position.

This display also shows the position of the axes. The coordinates displayed (operator, work, machine, or distance to go) are selected using the cursor up and down keys.

If the spigot is enabled, the current spigot position will be displayed.

Current display command

This display shows all of the alphabetical address codes (i.e., G, M, S, H, D) and their current value. These values may not be changed in this display. The default value is shown for the address codes that are not being used in the current program.

Macro Variables Display

This display shows a list of the macro variables and their present values. As the control interprets a program, the variable changes are displayed on this page and the results can be viewed. The variables may be modified in this display. For more information on this display, refer to the "Macros" section of this manual.

Operation Timers Display

This display shows the current power-on time, cycle start time, and the feed time. These times may be reset to zero by using the cursor **up** and **down** keys to highlight the desired title and pressing the ORIGIN button.

Listed below these times are two M30 counters that are used for counting completed parts. They may be set to zero independently to provide for the number of parts per shift and total parts. Both counters are increased when an M30 is operated.

Tool Life Display

This display shows the time the tool is in feed (Feed-Time), the time the tool is in the spindle (Total-Time), and the number of times the tool has been selected (Usage). This information can be used to assist in predicting tool life. The values in this display can be reset to zero using the Cursor and ORIGIN buttons. This is done by putting the cursor on the title line, and pressing ORIGIN to zero all of the data in that column.

This display may also be used to generate an alarm when a tool has been used a specific number of times. The last column is labeled "Alarm," and if the number for a tool is not zero, an alarm will be generated when that count is reached. This number can be changed by the operator. Alarm 362 is generated when the count is reached, and may be cleared with RESET.

The tool that is currently in the spindle is highlighted.

Tool Load Monitor and Display

With the tool load display, the operator can enter the maximum load that is expected for each tool, and when this load is exceeded in a feed, a certain action will be taken. This display provides for the entry of this alarm point and also displays the largest load that tool has seen in any previous feed.

NOTE: Surface Feet per Minute (SFM) and Chip Load are displayed on the Current Commands page. Note that Setting 40 selects radius or diameter for the tool geometry. SFM is displayed as fpm (feet per minute) or mpm (meters per minute), depending on setting 9. This is displayed in inches (typically a few thousandths) or millimeters (typically a few hundredths).





The tool load monitor function operates whenever the machine is in a feed operation (G01, G02, or G03). The values entered into the tool load display are checked against the actual spindle motor load. If the limit is exceeded, the tool overload action specified in Setting 84 (Alarm, Feedhold, beep, or Autofeed) will be taken. If "alarm" is selected and the limit is exceeded, Alarm 174, "Tool Load Exceeded," will be generated. This alarm will stop the axis motors and the spindle motor, turn off the coolant, and disable the servos.

If, during a feed, the load exceeds the tool limit and the AUTOFEED feature is selected, it will automatically override the feed rate (reduce it) down to the percentage specified by parameter 301 (i.e., 1%) at the rate specified by parameter 300 (i.e., 20% per second). If the tool load later falls below 95% of the tool load limit percentage, the AUTOFEED feature will automatically override the feed rate (increase it) back to the feed rate that was in effect at the start of the feed at the rate specified by parameter 299 (i.e., 10% per second). These adjustments will be made in 0.1-second increments.

Axis Load Monitor

Axis load is 100% to represent the maximum continuous load. Up to 250% can be shown, and above 100%, for an extended period of time, can lead to an axis overload alarm.

Periodic Maintenance

Titled "Scheduled Maintenance" and accessed by pressing PAGE UP or PAGE DOWN which allows the operator to activate and deactivate a series of checks (see Maintenance section).

Vibration Sensor

This feature allows the control to record the output from an accelerometer attached to the spindle head. The current and maximum vibration for each tool in units of Gravity is displayed on the Current Commands Spindle Load screen. The user can specify a vibration limit and clear the maximum recorded vibration for each tool just like the spindle load. If during a feed, the vibration exceeds the limit for the tool, the warning message VIBRA-TION LIMIT is displayed. The maximum vibration limit is 5Gs. Typically, with no load, the vibration has been found to be approximately 0.04Gs. If the vibration limit for a tool is set to zero then no warning will be issued. Note that the feature is activated by parameter 315 VIBRN SENSOR.

Alarms / Messages Display

The **ALARMS DISPLAY** can be selected at any time by pressing the ALARM / MESGS button. When there are no alarms, the display will show NO ALARM. If there are any alarms, they will be listed with the most recent alarm at the bottom of the list. The CURSOR and PAGE UP and PAGE DOWN buttons can be used to move through a large number of alarms. The CURSOR **right** and **left** buttons can be used to turn on and off the ALARM history display.

The **MESSAGE DISPLAY** can be selected at any time by pressing the ALARM / MESGS button a second time. This is an operator message display and has no other effect on operation of the control. Any message can be typed into the message display and called up later.

You may leave an electronic note to yourself or anyone else by using this feature. The note may be for the operator to change tools after running a number of parts or it may be a diary for machine maintenance intervals. Data is automatically stored and maintained even in a power-off state. The message display page will come up during power-up if there are no alarms present.

To enter messages, press the ALARM / MESGS button twice. You may now enter data by simply typing directly onto the screen. The cancel and space keys can be used to remove existing messages. The DELETE button can be used to remove an entire line.

PARAMETER / DIAGNOSTIC DISPLAY

The **PARAMETER DISPLAY** can be selected at any time by pressing the PARAM DGNOS button. Changes to parameters can be made when in any mode except when running a program. The CURSOR **up** and **down** buttons move to different parameters and the PAGE UP and PAGE DOWN buttons move through groups of parameters. Parameters 1, 15, 29, 43, and 57 are displayed as a single page of discrete flags. Selecting among the flags is done with the CURSOR **left** and **right** buttons. Parameters cannot be changed with the servos on. The EMERGENCY STOP button can be used to turn off the servos.

For machines with the fifth axis option, the parameter display organization has been modified to accommodate the extra axis parameters. Parameter numbers have remained the same as in a four-axis control. Additional parameters have been added for the fifth axis.

The parameters have been reorganized so that logically-associated parameters are grouped together. These logical groupings are placed together into contiguous screens called pages. The most commonly changed parameters have been placed at the beginning of the page list. The following is a list of the parameter pages and the order of succession in the control:

PAGE TITLE

DATA DESCRIPTION

COMMON SWTCH	Non-axis bit switches.
COMMON PAGE1	First page of non-axis parameters.
COMMON PAGE2	Second page of non-axis parameters.
COMMON PAGE3	Third page of non-axis parameters.
MACRO M CALL	Parameters that alias M codes to subroutines.
MACRO G CALL	Parameters that alias G codes to macros.
X BIT SWITCH	Bit switches for the X axis.
X PARAMETERA	First page of X axis parameters.
X PARAMETERB	Second page of X axis parameters.
Y BIT SWITCH	Bit switches for the Y axis.
Y PARAMETERA	First page of Y axis parameters.
Y PARAMETERB	Second page of Y axis parameters.
Z BIT SWITCH	Bit switches for the Z axis.
Z PARAMETERA	First page of Z axis parameters.
Z PARAMETERB	Second page of Z axis parameters.
A BIT SWITCH	Bit switches for the A axis.
APARAMETERA	First page of A axis parameters.
B BIT SWITCH	Bit switches for the B axis.
B PARAMETERA	First page of B axis parameters.
B PARAMETERB	Second page of B axis parameters.
X SCREW COMP	X axis screw compensation value.
Y SCREW COMP	Y axis screw compensation value.
Z SCREW COMP	Z axis screw compensation value.

The HOME key displays the first parameter page "COMMON SWTCH." Pressing the PAGE DOWN key will display the next page of parameters in the above list. The END key displays the last parameter page "B PARAMETERB." Pressing the PAGE UP key will display the preceding page of parameters in the above list. All other features on the parameters display have remained the same. So, if you are unfamiliar with the new format of the parameters, you can still search by parameter number. Enter the number of the parameter you want to see or view and press the **up** or **down** arrow key. The page that the parameter is on will be displayed and the parameter being searched for will be highlighted.

The **DIAGNOSTIC DATA DISPLAY** can be selected at any time by pressing the PARAM DGNOS button a second time. There are two pages of diagnostic data and the PAGE UP and PAGE DOWN buttons are used to select between them. After this, the current run time and the number of tool changes are displayed.

-1.11.1.1.5-





A five-axis control has additional diagnostic data to be aware of: The first page of diagnostic data shows two discrete outputs that control the rotary axes brakes; they are labeled "Brake 4th Axis" and "Brake 5th Axis". The 4th axis is synonymous with the A axis, and the 5th axis is synonymous with the B axis. If the Air Brake Parameter for the axis is set to 1, the HAAS control unclamps the brake whenever motion is commanded to the rotary axis and sets the brake back to its previous state as soon as the motion stops. The brake is activated by a relay. The two discrete outputs show the state of the brake relays. If the output is high (1) the brake is unclamped. When the machine is first powered up the brake will be unclamped, so the output will be low (0). When the brake is unclamped the message A UNCLMP or B UNCLMP is displayed in the message area near the bottom of the display.

The M11 and M13 codes command the brake to be unclamped. When these codes are in effect, the axis brake will remain unclamped even after motion has stopped.

The second page of diagnostic data shows the status of inputs from the motor interface board. Additional inputs for the expanded motor interface board are listed under "INPUTS4." These bits are monitored by the control to determine if the interface for the **B** axis is working correctly.

SETTING / GRAPHIC DISPLAY FUNCTION

The **SETTINGS DISPLAY** can be selected at any time by pressing the SETNG / GRAPH button. When the settings are displayed, changes can be made to any of the settings. There are some special functions in the settings; refer to the "Settings" section for a more detailed description.

The **GRAPHICS FUNCTION** is a visual dry run of your part program without the need to move the axes and risk tool damage from programming errors. This function is far more powerful than using the DRY RUN mode because all of your work offsets, tool offsets, and travel limits can be checked before any attempt is made to move the machine. The risk of a crash during setup is greatly reduced.

To run a program in Graphics, you must be in either MEM or MDI mode.

After loading the program into memory, select MEM (or MDI) and press the SETNG/GRAPH key twice to select the Graphics Simulation mode. This function operates as if running a program on the machine, except no physical machine action occurs.

The graphics screen is composed of the following areas:

DISPLAY TITLE AREA

The title area is on the top left line of the screen and indicates the display (GRAPHICS), the mode you are in (MEM or MDI), the program number, and the current program line being executed. It is the same as the top line of all displays.

KEY HELP AREA

The right side of the top line is the function key help area. Function keys that are currently available are displayed here with a brief description of their usage.

LOCATOR WINDOW

The lower right part of the screen has two functions: it can display the whole table area and indicate where the tool is currently located during simulation, or it can be used to display four lines of the program that is being executed. The F4 key can be used to toggle between these two modes.

TOOL PATH WINDOW

In the center of the display is a large window that represents a look-down perspective of the X-Y axes. It displays tool paths during a graphics simulation of a CNC program. Rapid moves are displayed as coarse dotted lines, while feed motion is displayed as fine continuous lines. The rapid path can be disabled by Setting 4. The places where a drill can or canned cycle can be executed are marked with an X. The drill mark can be disabled by Setting 5.

-///	44	5	_



The tool path window can be scaled. After running a program, you can scale any portion of the tool path by pressing F2 and then using the PAGE DOWN key and the ARROW keys to select the portion of the tool path that you want to see enlarged. During this process, a rectangle will appear within the TOOL PATH window and the Locator window indicating what the TOOL PATH window will represent when the zoom process is complete. The KEY HELP AREA will flash, indicating that the user is rescaling the view. The locator window always portrays the entire table with an outline of where the TOOL PATH window is zoomed to. The PAGE UP key unzooms the rectangle one step. After sizing or moving the rectangle, pressing the WRITE key will complete the zoom process and re-scale the TOOL PATH window. Pressing F2 and then the HOME key will expand the TOOL PATH window to cover the entire table. After the TOOL PATH window is re-scaled, the TOOL PATH window is cleared and you must rerun the program, or a portion of it, to see the tool path. The tool path is not retained in the control.

The scale and position of the TOOL PATH window is saved in Settings 65 through 68. Any scaling performed on the TOOL PATH window is retained. You can leave graphics to edit your program and when you return, your previous scaling is still in effect.

Z AXIS WINDOW

A long window on the rightmost part of the screen shows the location of the Z axis and indicates spindle movement. A horizontal line in the top part of this window represents the tool change position.

ZAXIS PART ZERO LINE

This feature consists of a horizontal line displayed on the Z axis bar at the top-right corner of the graphics screen to indicate the position of the current Z axis work offset plus the length of the current tool. While a program is running, the shaded portion of the bar indicates the depth of Z axis motion. The user will now be able to watch the position of the tool tip relative to the Z axis part zero position as the program runs.

CONTROL STATUS

The lower left portion of the screen displays control status. It is the same as the last four lines of all other displays.

POSITION WINDOW

The location of all enabled axes can be viewed in this window. By default it is OFF. This window can be opened by pressing the F3 key. Additional presses of the F3 key or the up and down arrows will display the various position formats that the control keeps track of. This window also displays the current scale of the tool path window and the current simulated tool number. The value represented by the vertical dimension of the tool path window is labeled Y-SIZE. At power-on, this will be the full Y-axis table travel. When you zoom into a table area, this value will become smaller, indicating that you are viewing a smaller portion of the table.

To exit the Graphic mode, select any other display or mode. When you exit Graphics, the graphics image is lost and must be built again by running the program.





Help / Calculator Function

The HELP FUNCTION is selected by pressing the HELP display button. This will bring a mini-manual up on the CRT. There are 26 topic areas selectable with the A-Z keys. This also includes a directory of the topics. The areas covered are:

А	START UP AND RUNNING	Ν	SET UP PROCEDURES
В	PROG. REVIEW / DNC / BGEDIT / POWER DOWN	0	OVERRIDES: FEED/SPIN/COOLANT
С	G/M/S/T COMMAND CODES	Р	PARAMETERS / DIAGNOSTICS
D	RETURN TO THIS DIRECTORY	Q	POSITION DISPLAYS
Е	EDITING PROGRAMS	R	RECV / SEND PROGRAMS
F	SETTING PAGE	S	SAMPLE PROGRAM
G	SPECIAL G CODES	Т	TOOL OFS/TOOL LIFE/LOAD
Н	TROUBLE SHOOTING	U	GRAPHIC FUNCTION
I	MDI / MANUAL DATA INPUT	V	TOOL CHANGER
J	JOGGING / HANDLE FUNCTION	W	WORK COORDINATES
Κ	CRT DISPLAY / KEYBOARD	Х	CREATING PROGRAMS
L	ALARMS / MESSAGES	Y	SPECIAL FUNCTIONS
N/I		7	

MAIN LENANCE REQUIREMENTS

ZERO RETURN

When the HELP display is selected, the alphanumeric keys are used to select one of the above topics; they are not displayed on the data entry line of the screen.

The CALCULATOR FUNCTION is selected by pressing the HELP key a second time. There are three calculator pages: Trig Help, Circular Interpolation Help, and Milling/Tapping Help. All of these have a simple calculator and an equation solver. Trig, Circular, and Milling Help are selected using the PAGE UP and PAGE DOWN keys. The **Fn** keys also allow data to be moved from other displays to/from the calculator.

All of the Calculator Help functions have a calculator for simple add, subtract, multiply, and divide operations. When one of these functions (Trig, Circular, or Milling) is selected, a calculator window appears in the upper left corner of the screen, and below it the possible operations (LOAD + - * and I). LOAD is initially highlighted, and the other options can be selected with the left and right cursor arrows. Numbers are entered by typing them in at the cursor in the lower left corner of the screen and pressing the WRITE key. When a number is entered and LOAD is selected, that number will be entered into the calculator window directly. When a number is entered when one of the other functions (+ - * I) is selected, that calculation will be performed with the number just entered and any number that was already in the calculator window. The calculator will also accept a mathematical expression such as 23*4-5.2+6/2. It will evaluate it (doing multiplication and division first) and place the result, 89.8 in this case, in the register (the window).

F3 In EDIT and MDI modes the F3 key will copy the highlighted triangle/circular/milling/tapping value into the data entry line at the bottom of the screen. This is useful when you want to use a solution developed for a program input.

In the Calculator Help function, this button copies the value in the calculator window to the highlighted data entry for Trig, Circular or Milling/Tapping calculations.

F4 In the Calculator Help function, this button uses the highlighted Trig, Circular or Milling/Tapping data value to load, add, subtract, multiply, or divide with the calculator.

Trigonometry Help Function

The Trig Help page will help you solve a triangular problem. You enter the lengths and the angles of a triangle and when enough data has been entered, the control will solve for the triangle and display the rest of the values. Use the CURSOR up and down buttons to select the value to be entered with WRITE. For inputs that have more than one solution, entering the last data value a second time will cause the next possible solution to be displayed.





Circular Interpolation Help

The Circular Help page will help you solve a circle problem. You enter the center, radius, angles, start and end points and when enough data has been entered, the control will solve for the circular motion and display the rest of the values. Use the CURSOR up and down buttons to select the value to be entered with WRITE. In addition, it will list the four ways that such a move could be programmed with a G02 or G03. Those four lines can be selected using the CURSOR up or down buttons, and the F3 button will import the highlighted line into a program you are editing.

For inputs that have more than one solution, entering the last data value a second time will cause the next possible solution to be displayed. The CW/CCW entry is changed to the other value by pressing WRITE.

Milling/Tapping Help

The Milling/Tapping Help page will help you solve three equations relating to milling and tapping. They are:

- 1. SFM = (CUTTER DIAMETER IN.) * RPM * 3.14159 / 12
- 2. (CHIP LOAD IN.) = (FEED IN./MIN.) / RPM / #FLUTES
- 3. (FEED IN./MIN.) = RPM / (THREAD PITCH)

With all three equations, you may enter all but one of the values and the control will compute the remaining value and display it. Note that the RPM value for equations 1 and 2 are the same entry.

When metric units are selected, the units displayed change to millimeters, mm per minute, threads per mm, and meters, respectively.

Materials

The Milling calculator includes a field called MATERIAL, which, when highlighted, allows the operator to select a type of material from the list below using the **left** and **right** arrow keys. Note that one of the materials is always selected (the first in the list is the default) and the list wraps around at the end.

LOW CARBON UNALLOYED STEEL MEDIUM CARBON UNALLOYED STEEL HIGH CARBON UNALLOYED STEEL NORMAL CONDITION LOW ALLOY STEEL HEAT TREATED TO 32 Rc LOW ALLOY STEEL NORMAL CONDITION HIGH ALLOY STEEL HEAT TREATED TO 32 Rc HIGH ALLOY STEEL FERRITIC/MARTENSITIC STAINLESS STEEL AUSTENITIC STAINLESS STEEL I AUSTENITIC STAINLESS STEEL II AUSTENITIC PRECIP. HARDENED STAINLESS IRON BASED HEAT RESISTANT ALLOY NICKEL BASED HEAT RESISTANT ALLOY COBALT BASED HEAT RESISTANT ALLOY TITANIUM HEAT RESISTANT ALLOY GRAY CLASS 20 CAST IRON GRAY CLASS 30, CLASS 40 CAST IRON NODULAR CAST IRON ALUMINUMALLOY BRASS - BRONZE ALLOY HI-VELOCITY MACHINING ALUMINUM ALLOY

A recommended surface speed and chip load will be displayed based on the material chosen, as shown below on the right.




SURFACE SPEED * *** FT/MIN RECOMMENDED **** TO ***** CHIP LOAD * *** IN RECOMMENDED * *** TO * ***

Also, the required horsepower will be calculated and displayed as shown below on the right.

CUT DEPTH *.*** IN REQUIRED POWER *.* HP

When in metric mode, the required power is displayed as KW. The remaining calculator functions are unchanged.

Unspecified Material

The material type displayed when the calculator is first accessed is "PRESS < or > FOR MATERIALS" and no recommendations are displayed. The user can select any material from the list and the recommended data will be displayed as before, or return to the unspecified material.

2.19 TRAVEL LIMITS

Travel limits in this machine are defined by a limit switch in the positive direction and by stroke limits set by parameter in the negative direction. Prior to establishing the home positions with the POWER UP/RESTART or AUTO ALL AXES buttons, there are no travel limits and the user must be careful not to run the table into the stops and damage the screws or way covers.

Prior to establishing the home positions (POWER UP/RESTART or AUTO ALLAXES), jogging is normally not allowed. Setting 53 can be turned on to allow jogging prior to zero return but this defeats the travel limits and you may damage the machine running the axes into the stops.

Note that all motion is in a negative direction from machine zero except for the Z axis, which can move about 4.5 inches up from machine zero. There are no travel limits for the fourth, **A**, axis. Travel limits for any auxiliary axes are set into those single axis controls.

When jogging, an attempt to move past the travel limits will not cause an alarm, but the axis will stop at the limit. The JOG handle inputs may be ignored in this case.

When running a program, an attempt to move outside of the travel limits will cause an alarm prior to starting the motion and the program will stop. An exception is a circular motion which starts and ends inside of the travel limits but moves outside of the limits during the motion. This will cause an alarm to occur part way through the motion.

Travel limits apply even when running a program in Graphics mode. An alarm is generated and the program will stop.

2.20 Feed/Rapid/Spindle Overrides

The feedrate can be varied from 10% to 200% of the programmed value while in operation. This is done with the feedrate +10%, -10% and 100% buttons. The FEEDRATE override is ineffective during G74 and G84 tapping cycles. FEEDRATE override does not change the speed of any auxilliary axes. During manual jogging, the feedrate override will adjust the rates selected from the keypad. This allows for fine control of the jog speed.

The spindle speed can also be varied, from 10% to 150%, using the SPINDLE overrides as above. It is also ineffective for G74 and G84. In the SINGLE BLOCK mode, the spindle may be stopped. It will automatically start up upon continuing the program.

By pressing the HANDLE CONTROL FEEDRATE key, the jog handle can be used to control feedrate from 0% to 999% in \pm 1% increments. By pressing the HANDLE CONTROL SPINDLE key, the jog handle can be used to control spindle speed in \pm 1% increments (from 0% to 999%).

Rapid moves (G00) may be limited to 5%, 25%, or 50% of maximum using the keypad. If the 100% rapid is too fast, it may be set to 50% of maximum by Setting 10.

In the Settings page, it is possible to disable the override keys so that the operator cannot select them. These are Settings 19, 20 and 21.

The FEED HOLD button acts as an override button as it sets the rapid and feed rates to zero when it is pressed. The CYCLE START button must be pressed to proceed after a FEED HOLD. When in a FEED HOLD, the bottom left of the screen will indicate this. The door switch on the enclosure also has a similar result but will display "Door Hold" when the door is opened. When the door is closed, machine operation will continue normally. Door Hold can be prevented with Setting 51. Door Hold and FEED HOLD do not stop any auxiliary axes.



When Parameter 57 flag DOOR STOP SP is set to 1, the door switch will stop the servos and the spindle. In addition, the maximum spindle speed is 750 rpm with the doors open.

There is also an override function for the coolant supply. This is done from the Setting 32. The **NORMAL** setting checks the low coolant alarm and turns the pump on and off with M-codes. The **OFF** setting ignores the coolant alarm, but will alarm if an attempt is made to turn the coolant on. The **IGNORE** setting is used to ignore all coolant commands and the low coolant alarm.

At any time a program is running, the operator may override the coolant setting by pressing the MDI Coolant button. The pump will remain either on or off until the next M-code or operator action.

Overrides can be reset through to defaults upon processing M30 and/or RESET. This feature is selected by Setting 83.

2.21 RUN-STOP-JOG-CONTINUE

This feature allows the operator to interrupt program execution, jog away from the part, return to the interruption point, and then resume program execution. The following is an operation procedure:

- 1. While a program is running, press FEED HOLD. This will stop all motion (after any canned cycle in process has been completed.)
- 2. Press X, Y or Z followed by HANDLE JOG. The control will store the current XYZ positions. Note that axes other than X, Y, and Z cannot be jogged.
- 3. The control will display JOG AWAY. The operator can jog (using the jog handle, remote jog handle, jog and jog-lock buttons) to move the tool away from part, press AUX CLNT to cycle the Through Spindle Coolant (TSC), press COOLNT to cycle the coolant stream, press CW, CCW, STOP, TOOL RELEASE, the jog increment buttons and use the increment switch on the remote jog handle. Note that AUX CLNT requires that the spindle be rotated and that the door be closed. Tools can be swapped out and the associated length and diameter offsets adjusted, however, when the program is continued, the old offsets will still be used for the return position and any motion commands already in the queue. It is therefore unsafe to swap out tools and adjust offsets when the program was interrupted during a cut.
- 4. Jog to a position as close as possible to the stored position, or to a position where there will be an unobstructed rapid path back to the stored position.
- 5. Return to the previous mode by pressing MEM, MDI, or DNC. The control will only continue normally if the mode that was in effect at the time of the interrupt is re-entered.
- 6. Press CYCLE START. The control will display the message JOG RETURN and rapid X and Y at 5% to the position when FEED HOLD was pressed, then the same for Z. The rapid rate override keys have no effect during JOG RETURN. Caution: The control will not follow the path the operator used to jog away. Instead, it will perform simple moves without regard for obstacles. Therefore, a crash is possible. If FEED HOLD is pressed during this motion, the control will go into a feed hold state and display the message JOG RETURN HOLD. Pressing CYCLE START will cause the control to resume the JOG RETURN motion. When the motion is completed, the control will again go into a feed hold state.
- 7. Press CYCLE START again and the program will resume normal operation.

2.22 HIGH SPEED MACHINING

High speed machining makes it possible for an increase in the removal rate of material, improve surface finish, and reduce cutting forces. This will reduce machining costs and extend the life of the tools. An additional advantage to using high speed machining is to utilize the more current tool cutting edge materials and tool coatings that are available. The only limitation to high speed machining is the need for rigid, powerful machines capable of the required speeds and feeds, and having a fixture strong enough to hold the workpiece.

Recommended Tooling

Balanced tools and tool holders are a must to maintain excellent machining conditions. Vibrations during chip cuttings relate directly to early tool failure, poor part finish and even possible spindle damage. Therefore the design of the tool holder increases in importance as the speed increases.

The items necessary for proper high speed machining are toolholder taper cone accuracy, concentric relationship of the cutting tool pocket to the tool holder cone, and actual size tolerance of the tool pocket. The fit between the tool holder and the spindle is the starting point for the machining center. An improved fit for these two items is essential for hi-speed machining success. Size and tolerance of toolholding features such as bore or pilot size should not exceed two or three ten-thousandths of an inch. Concentricity of the toolholding feature (bore or pilot) relative to the tapered shank this should also be within two or three thousandths of an inch.

Where possible use the minimum collet envelope relative to bore size. In other words use the largest bore size for the smallest collet envelope to achieve high grip force with reduced tool holder mass. This also helps in keeping the amount of centrifugal force low and will allow the highest speed possible in relation to the balance specification limitations.

The tool assembly must be balanced to a degree of accuracy that matches the machine spindle requirement. This means a balancing operation will have to be performed, or check the balanced condition of the assembly, each time there is a new tool assembly created or a significant change is made to the existing tool assembly. A significant change could be adjusting cutting tools, changing any part of the tool holder, regrinding or altering a cutting tool, or changing to a new cutting tool or a new tool holder. In order to thoroughly balance the tool holder the retention knob and cutting tool must be in place. Commercial balancing machines give accurate measurement regarding the balance of the tool assembly. Such equipment would be necessary for the initial balancing and eventual rebalancing operations.

The tool holders should be an AT-3 or better with a nylon back-up screw. The tolerances maintained in the AT-3 design are the minimum that would be recommended for a high speed process. The nylon back-up screw increases collet grip on the tool and creates a better seal to aid in coolant transfer.

Use single angle collet chucks and collets for best grip and concentricity. These collet systems are made up of a long single angle located in the holder. The angle per side should be eight degrees or less for best results. Avoid double angle collet systems when maximum rigidity and close tolerance are dictated. It is recommended that minimum engagement of 2/3 of the full length of the bore in the double split single angle collet. However for better results 3/4 to full engagement is preferred if possible.

Collet envelope is the combination of the maximum bore size and the outside shape designation.

Consult the tool holder manufacturer for the current specifications and capabilities of their tool holders. This would include the AT rating and maximum RPM that the tool holder is rated for.



2.23 200 Hour Try-Out

Options that normally require a unlock code to activate (Rigid Tap, Macros, etc.) can now be activated and deactivated as desired simply by entering the letter **1** instead of the unlock code to turn it on. Enter a **0** to turn off the option. An option activated in this manner will be automatically deactivated after a total of 200 power-on hours. Note that the deactivation only occurs when power to the machine is turned off, not while it is running. An option can be activated permanently by entering the unlock code. Note that the letter **T** will be displayed to the right of the option on the parameter screen during the 200 hour period. Note that the safety circuit option is an exception; it can be turned on and off only by unlock codes.

2.24 HIGH INTENSITY LIGHTING (OPTIONAL)

The High-Intensity Lighting system is operated automatically. When the doors are fully opened, a switch turns on the lights.

In addition, the lighting system can be turned on manually using a switch located on the side of the light brackets.

2.25 CHIP SWEEP (OPTIONAL)

Overview

The Haas Chip Sweep keeps the inside of the VF-Series mill neat. Chips and grime are washed down into the auger trough. The dual rotating sprayer heads turns 360 degrees to continually wash the inside. The Coolant Sweep works with the standard Haas coolant pump, with no pressure loss to the Through the Spindle Coolant or standard coolant nozzles.

The chip sweep option is activated by the same command that powers the coolant pump (M8). The coolant system will activate and the nozzles will rotate.



For dry cutting operations, shut off the P-Cool nozzle valve (behind the P-cool). This enables the operator to activate the chip sweep only.

The pressure at the nozzle is regulated by adjusting the valve on the Y-junction.







If there is a pressure drop at the nozzles; stop the coolant and clean the filter (see the previous figure). To do so simply remove the filter, clean and replace. The chip sweep filter is mounted on the back of the machine.







3. PROGRAMMING

3.1 Work Coordinate System

These machines have three linear axes named **X**, **Y**, and **Z**. The X axis moves the table left and right, the Y axis moves it to and from the operator and the **Z** axis moves the milling head up and down. The machine zero position is the upper right corner of the mill table. All moves from this point are in a negative machine direction. If a rotary table is connected, an additional A-axis work offset is provided.

Work offsets are found in the offset display by pushing the PAGE UP key. You can display and manually enter work offsets from here. The work coordinate systems on a control with a fifth axis have all been expanded to accommodate **B**, the fifth axis. Work coordinate offsets can be set for the **B** axis in the offset display. Note that the auxiliary axes **C**, **U**, **V**, and **W** do not have any offsets; they are always programmed in machine coordinates.

The Home or machine zero position is X0, Y0, Z0. Travel of these axes from machine zero is limited in the negative direction by stored stroke limits defined in the parameters. The X and Y axes can only move in the negative direction from machine zero, so travel in the positive direction for X and Y is limited simply to values less than zero — that is, the coordinates at any point will always be negative. Positive travel for the Z axis is limited to about 3 inches above the tool change position with umbrella-type tool changers. With side-mount tool changers, the tool change position is the Z-axis limit. In addition, positive travel for all axes is limited by the home switch, which acts as a limit switch.

Before a tool can machine your part, the control must know where your part is. The work coordinate system tells the control the distance from the work zero point of your part to the machine zero position. The work zero point of the part is decided by the programmer and usually is the common point from which all print dimensions are referenced. The machine zero position is fixed by the machine on power-up and does not change. The operator must determine this distance and enter the work offset value.

This control automatically chooses the G54 offset values on power-up. If you do not wish to use these values, zero out the values in the G54 **X**, **Y**, and **Z** columns or select another work offset.

The G54 through G59 or G110 through G129 offsets can be set by using the PART ZERO SET key. Position the axes to the work zero point of your part. Using the cursor, select the proper axis and work offset number. Press the PART ZERO SET key and the current machine position will be automatically stored in that address. This will work only with the work zero offset display selected. Note that entering a nonzero **Z** work offset will interfere with the operation of an automatically entered tool length offset.

Work coordinates are usually entered as positive numbers, except when Parameter 57, bit "Neg. Work Offset" is set to 1. In this case, the work coordinates are entered as negative numbers.

Work coordinates are entered into the display using numbers only. To enter an X value of X2.00 into G54, you would cursor over to the X column and enter the number 2.0 only.

See the sections on G52, G92, and Setting 33 for more on work coordinate systems.

Offsets can be sent and received with the RS-232 port. See the "Data Input / Output" section for information on how to do this.



3.2 PROGRAM STRUCTURE

A CNC part program consists of one or more blocks of commands. When viewing the program, a block is the same as a line of text. Blocks shown on the CRT are always terminated by the ";" symbol, which defines an EOB. Blocks are made up of alphabetical address codes and the "*I*" symbol. Address codes are always an alphabetical character followed by a numeric value. For instance, to specify the position to move the X axis to, you would be a number preceded by the **X** symbol.

The "*I*" symbol, or slash, is used to define an optional block. A block that contains this symbol can be optionally deleted with the BLKDEL button when running a program.

There is no positional requirement for the address codes. They may be placed in any order within the block. The following is a sample program as it would appear on the CRT. **The words following the ":" are not part of the program but are put here as further explanation.**

This program will drill four holes and mill a two-inch hole in a four-inch square plate with **X** and **Y** zero at the center. The program with comment statements would appear like this.

% O1234 (OP1 SAMPLE MILL PART) N1 (TOOL 1 IS A 1/2 INCH STUB DRILL) N5 G40 G49 T1 M06 N100 G00 X0 Y0 Z.5 G43 H1 M3 S1400 T2 N101 G01 Z.2 F30. N102 G83 G98 Z-.625 R.03 Q.2 F5. N103 X1.5 Y1.5 N104 Y-1.5 N105 X-1.5 N106 Y1.5 N107 G00 G80 Z.5 N108 T2 M06 N2 (T 2 IS 5/8 90 DEG. COUNTERSINK) N200 G00 X0 Y0 Z.5 G43 H2 M3 S500 N201 G01 Z.2 F30. N202 G82 G98 Z-.27 R.0 F5. N203 X1.5 Y1.5 N204 Y-1.5 N205 X-1.5 N206 Y1.5 N207 G00 G80 Z.5 N208 G28 X0 Y0 Z2.0 N209 T3 M06 N3 (TOOL 3 IS A 1/2 END MILL) (SET DIAMETER VALUE TOOL 3) N300 G00 X0 Y0 Z.5 G43 H3 M3 S1000 N301 G01 Z.2 F30. N302 Z-.625 F5. N303 G01 G41 X-1.00 N304 G03 I1.0 D1 N305 G00 G40 X00 N306 G00 Z.5 N307 G28 M30 %

:PROGRAM MUST BEGIN AND END WITH % :PROGRAM # AND COMMENT STATEMENT :(*****) NOTES TO OPERATOR :RAPID TO POS, OFFSET 1, SPIN FWD :FEED 30 INCH/MINUTE TO Z DEPTH :PECK TO Z-.625 START .03 ABOVE :DRILL ANOTHER HOLE AT NEW X,Y :DRILL 3RD HOLE, PECK DEPTH IS .20 :DRILL FOURTH HOLE :DRILL FIFTH HOLE :CANCEL CANNED CYCLE :TOOL CHANGE TO TOOL #2 :N### ARE LINE NUMBERS :OFFSET 2, SPINDLE SPEED 500 RPM :FEED TO Z AT 30 INCH PER MINUTE :SPOT DRILL CYCLE, DRILL AT X0 Y0 :SEC HOLE R=START PLANE ABOVE ZERO :3RD HOLE G98=RETURN TO INIT POINT :FOURTH HOLE :FIFTH HOLE :RAPID TO Z.5 :ZERO RETURN AFTER MOVE TO X0, Y0 :TOOL CHANGE :N #'S ARE FOR YOUR CONVENIENCE :COMMENTS ARE IGNORED BY CONTROL :G43 = OFFSET Z IN MINUS DIRECTION :G01 CAN BE SPECIFIED AS G1 :FEED TO DEPTH :COMPENSATE CUTTER LEFT OF LINE :CUT CIRCLE CCW WITH TOOL DIA D1 :RAPID TO CENTER, G40 CANCELS COMP :RAPID OUT OF PART :ZERO RETURN, Z GOES FIRST THAN X,Y :RESET PROGRAM TO BEGINNING :END OF TAPE

111415-

G Operator's Manual

Please note that each tool is different, which shows the flexibility of the control. For example, to change tools, all that is needed is an M06 command, even without a G28 in the previous line. Also, a G28 command can be specified as G28 X0 Y0 Z0 or simply as G28. A "T" command can be put in with the M06 or it can be specified earlier in the program. This gives maximum compatibility with other controls.

More than one program can be stored in the memory of the CNC. Every program stored has an **Onnnnn** program name or address code. These numbers are used to identify the program for selection as the main program being run or as a subprogram called from a main program.

3.3 Alphabetical Address Codes

The following is a list of the address codes used in programming the CNC.

A Fourth axis rotary motion

The **A** address character is used to specify motion for the optional fourth, **A**, axis. It specifies an angle in degrees for the rotary axis. It is always followed by a signed number and up to three decimal positions. If no decimal point is entered, the last digit is assumed to be 1/1000 degree. The smallest magnitude is 0.001 degree, the most negative value is -99999.000 degrees, and the largest number is 99999.000 degrees.

B Fifth axis rotary motion

The **B** address character is used to specify motion for the optional fifth, **B**, axis. It specifies an angle in degrees for the rotary axis. It is always followed by a signed number and up to three decimal positions. If no decimal point is entered, the last digit is assumed to be 1/1000 degree. The smallest magnitude is 0.001 degree, the most negative value is -8380.000 degrees, and the largest number is 8380.000 degrees.

C Auxiliary external rotary axis

The **C** address character is used to specify motion for the optional external sixth, **C**, axis. It specifies an angle in degrees for the rotary axis. It is always followed by a signed number and up to three decimal positions. If no decimal point is entered, the last digit is assumed to be 1/1000 degree. The smallest magnitude is 0.001 degree, the most negative value is -8380.000 degrees, and the largest number is 8380.000 degrees.

D Tool diameter selection

The **D** address character is used to select the tool diameter or radius used for cutter compensation. The number following must be between 0 and 200. D0 specifies that the tool size is zero and serves to cancel a previous **Dn**. Any other value of **D** selects the numbered entry from the tool diameter/radius list in the Offsets display.

E Contouring accuracy

The **E** address character is used, with G187, to select the accuracy required when cutting a corner during highspeed machining operations. The range of values possible for the E code is 0.0001 to 0.25. Refer to the "Contouring Accuracy" section for more information.

F Feed rate

The **F** address character is used to select the feed rate applied to any interpolation functions, including pocket milling and canned cycles. It is either in inches per minute with four fractional positions or mm per minute with three fractional positions. When G93 (Inverse Time) is programmed, F is in blocks per minute, up to a maximum of 15400.0000 inches per minute (39300.000 millimeters per minute).





G Preparatory functions (G codes)

The **G** address character is used to specify the type of operation to occur in a block. The **G** is followed by a two- or three-digit number between 00 and 187. Each **G** code is part of a numbered group. The Group 0 codes are non-modal; that is, they specify a function applicable to this block only and do not affect other blocks. The other groups are modal and the specification of one code in the group cancels the previous code applicable from that group. A modal **G** code applies to all subsequent blocks so those blocks do not need to re-specify the same **G** code. Multiple **G** codes can be placed in a block in order to specify all of the setup conditions for an operation, provided no two are from the same numbered group. See the "G Codes" section for a detailed list of **G** codes.

H Tool length offset selection

The **H** address character is used to select the tool length offset entry from the offsets memory. The **H** is followed by a number between 0 and 200. H0 will cause no offset to be used and **Hn** will use the tool length entry **n** from the Offsets display. Note that G49 is the default condition and will clear the tool length offsets, so you must select either G43 or G44 to activate tool length offsets. The TOOL OFSET MESUR button will enter a value into the offsets to correspond to the use of G43.

I Canned cycle and circular optional data

The I address character is used to specify data for some canned cycles and circular motions. It is either in inches with four fractional positions or mm with three fractional positions. I is followed by a signed number between -15400.0000 and 15400.0000 in inches or between -39300.000 and 39300.000mm for metric.

J Canned cycle and circular optional data

The J address character is used to specify data for some canned cycles and circular motions. It is formatted just like the I data. J is followed by a signed number between -15400.0000 and 15400.0000 in inches or between -39300.000 and 39300.000 mm for metric.

K Canned cycle and circular optional data

The **K** address character is used to specify data for some canned cycles and circular motions. It is formatted just like the I data. **K** is followed by a signed number between -15400.0000 and 15400.0000 in inches or between -39300.000 and 39300.000 mm for metric.

L Loop count for repeated cycles

The L address character is used to specify a repetition count for some canned cycles and auxiliary functions. It is followed by an unsigned number between 0 and 32767.

M M Code miscellaneous functions

The **M** address character is used to specify an **M** code for a block. These codes are used to control miscellaneous machine functions. Note that only one **M** code is allowed per block of the CNC program and all **M** codes are performed at the end of the block. See the "M Codes" section for a detailed list of **M** codes.

N Number of block

The **N** address character is entirely optional. It can be used to identify or number each block of a program. It is followed by a number between 0 and 99999. The M97 function must reference an **N** line number.

O Program number/name

The **O** address character is used to identify a program. It is followed by a number between 0 and 99999. A program saved in memory always has an **Onnnnn** identification in the first block; it cannot be deleted. Altering the **O** in the first block causes the program to be renamed. An **Onnnnn** can be placed in other blocks of a program but will have no effect and can be confusing to the reader. A colon (:) may be used in the place of **O** in a program, but is always displayed as "**O**".

74



P Delay time or program number

The **P** address character is used to enter either a time in seconds or a program number for a subroutine call. If it is used as a time (for a G04 dwell), it may be a positive decimal between 0.001 and 1000.0. If it is used as a program name (for an M98) or a line number (for an M97), the value may be a positive number without a decimal point, up to 9999.

Q Canned cycle optional data

The **Q** address character is used in canned cycles and is followed by a signed number, between 0 and 8380.000 for inches or between 0 and 83800.00 for metric.

R Canned cycle and circular optional data

The **R** address character is used in canned cycles and circular interpolation. It is either in **inches** with four fractional positions or **mm** with three fractional positions. **R** is followed by a signed number between -15400.0000 and 15400.0000 for inches or between -39300.000 and 39300.000 for millimeters. It is usually used to define the reference plane for canned cycles.

S Spindle speed command

The **S** address character is used to specify the spindle speed in conjunction with M41 and M42. The **S** is followed by an unsigned number between 1 and 99999. The **S** command does not turn the spindle on or off; it only sets the desired speed. If a gear change is required in order to set the commanded speed, this command will cause a gear change to occur even if the spindle is stopped. If the spindle is running, a gear change operation will occur and the spindle will continue running at the new speed.

T Tool selection code

The **T** address character is used to select the tool for the next tool change. The number following **T** must be a positive number between 1 and the number in Parameter 65. It does not cause the tool change operation to occur. The **Tn** may be placed in the same block that starts the tool change (M6 or M16) or in any previous block.

U Auxiliary external linear axis

The **U** address character is used to specify motion for the optional external linear, **U**, axis. It specifies a position or distance along the **U** axis. It is either in inches with three or four fractional positions or millimeters with three fractional positions. It is followed by a signed number between -838.0000 and 838.0000 in inches or -8380.000 and 8380.000 in millimeters. If no decimal point is entered, the last digit is assumed to be 0.0001 inch or 0.001 mm.

V Auxiliary external linear axis

The **V** address character is used to specify motion for the optional external linear, **V**, axis. It specifies a position or distance along the **V** axis. It is either in inches with three or four fractional positions or millimeters with three fractional positions. **V** is followed by a signed number between -838.0000 and 838.0000 in inches or -8380.000 and 8380.000 in millimeters. If no decimal point is entered, the last digit is assumed to be 0.0001 inch or 0.001 mm.

W Auxiliary external linear axis

The **W** address character is used to specify motion for the optional external linear, **W**, axis. It specifies a position or distance along the **W** axis. It is either in inches with three or four fractional positions or millimeters with three fractional positions. **W** is followed by a signed number between -838.0000 and 838.0000 in inches or -8380.000 and 8380.000 in millimeters. If no decimal point is entered, the last digit is assumed to be 0.0001 inch or 0.001 mm.

X Linear X-axis motion

The **X** address character is used to specify motion for the X axis. It specifies a position or distance along the X axis. It is either in **inches** with four fractional positions or **mm** with three fractional positions. **X** is followed by a signed number between -15400.0000 and 15400.0000 for inches or between -39300.000 and 39300.000 for millimeters. If no decimal point is entered, the last digit is assumed to be 0.0001 inch or 0.001 mm.





Y Linear Y-axis motion

The **Y** address character is used to specify motion for the Y axis. It specifies a position or distance along the Y axis. It is either in **inches** with four fractional positions or **mm** with three fractional positions. **Y** is followed by a signed number between -15400.0000 and 15400.0000 for inches or between -39300.000 and 39300.000 for millimeters. If no decimal point is entered, the last digit is assumed to be 0.0001 inch or 0.001 mm.

Z Linear Z-axis motion

The **Z** address character is used to specify motion for the Z axis. It specifies a position or distance along the Z axis. It is either in **inches** with four fractional positions or **mm** with three fractional positions. It is followed by a signed number between -15400.0000 and 15400.0000 for inches or between -39300.000 and 39300.000 for millimeters. If no decimal point is entered, the last digit is assumed to be 0.0001 inch or 0.001 mm.

3.4 TIPS AND TRICKS

General Tips

 Δ Cursor Searching for a Program. When in EDIT or MEM mode, you can select and display another program quickly by entering the program number (Onnnnn) you want and pressing either the up or down cursor arrow or F4.

 Δ Searching for a Program Command. Searching for a specific command in a program can be done in either MEM or EDIT mode. Enter the address letter code (A, B, C, etc.) or address letter code with the value (A1.23), and press the up or down cursor arrow. If you enter just the address code and no value, the search will stop at the next use of that letter, regardless of the value

 Δ **Spindle Command**. You can stop or start the spindle with **CW** or **CCW** any time you're at a Single Block stop or a Feed Hold. When you restart the program with **CYCLE START**, the spindle will be turned back on to the previously defined speed.

 Δ **Coolant Pump**. The coolant pump can be turned on or off manually while a program is running, by pressing the **COOLNT** button. This will override what the program is doing until another M08 or M09 coolant command is executed. This also applies to the chip conveyor.

 Δ **Coolant Spigot Position**. The coolant spigot position can be changed manually when a program is running, with the **CLNT UP** or **CLNT DOWN** key. This will override what the program commands until another spigot position is commanded with an Hnn or M08 command.

 Δ **Optional Stop**. Takes effect on the line after the highlighted line when pressed.

 Δ **Block Delete**. Takes effect four lines after that key is pressed when Cutter Compensation is in use, or two lines later when Cutter Compensation is not in use.

 Δ **Block Look-Ahead**. This control actually does look ahead for block interpretation, up to 20 blocks. This is not needed for high-speed operation. It is instead used to ensure that DNC program input is never starved, and to allow Cutter Compensation to have non-XY moves inserted while Cutter Compensation is On.

 Δ **Memory Lock Key Switch**. This is a machine option that prevents the operator from editing programs and from altering settings when in the locked position.

 Δ **Chip Conveyor**. The chip conveyor can be turned on or off when a program is running, either manually using the control keys or in the program using M codes. The M code equivalent to **CHIP FWD** is M31, **CHIP REV** is M32, and **CHIP STOP** is M33. You can set the Conveyor Cycle time (in minutes) with Setting 114, and the Conveyor On-Time (in minutes) with Setting 115.





△ **Transferring an MDI Program**. You can transfer and save a program in MDI to your list of programs. When in the MDI display, *make sure that the cursor is at the beginning* of the MDI program. Enter a program number (Onnnn) that's not being used. Then press **ALTER** and this will transfer the MDI data into your list of programs under that program number.

 Δ **To Rapid an Axis Home**. You can rapid *all* axes to machine zero by pressing the **HOME G28** key. You can also send just one axis (X, Y, Z, A or B) to machine zero in rapid motion. Enter the letter X, Y, Z, A or B, then press **HOME G28** and that axis alone will rapid home. *CAUTION*! There is no warning to alert you of any possible collision! For example, if the Z axis is down near the part or fixture on the table, and then the X or Y axis is sent home using HOME G28, a crash may result. Care must be exercised. (Any Mill Control ver. 9.49 and above; any Lathe Control ver. 2.24 and above.)

 Δ **Rotate Tool Carousel without Changing Tools (M39)**. You can rotate the tool carousel without changing tools by using M39 and Tnn. This can be used to recover from some unusual conditions. However, it will also tell the control you have a different tool in the spindle, which may not be the case. (Any Mill Control ver. 2.3 and above.)

PRGRM /CONVRS

 Δ **Program Review**. In the PRGRM display, Program Review allows you to cursor through and review the active program on the right side of the display screen, while also viewing the same program as it's running on the left side of the screen. To bring up Program Review, press **F4** while running a program in MEM mode and PRGRM display.

 Δ **Background Edit**. This feature allows you to edit a program in MEM mode and PRGRM display while a program is running. Type in the program number you want to edit (**Onnnn**) and press **F4**. You can then do simple edits (**INSERT**, **ALTER**, **DELETE** and **UNDO**) either to an existing program, a new program or even the program that is presently running. However, edits to the program that is running will not take effect until that program cycle ends with an M30 or **RESET**.

POSIT

△ Quick Zero on DIST-TO-GO Display. To clear out and get a quick zero position display, for a distance reference move, use the DIST-TO-GO position display. When you're in the POSIT display and in HANDLE JOG mode, press any other operation mode (EDIT, MEM, MDI, etc.) and then go back to HANDLE JOG. This will zero out all axes on the DIST-TO-GO display and begin showing the distance moved.

 Δ **To Origin the POS-OPER Display**. This display is used for reference only. Each axis can be zeroed out independently, to then show its position relative to where you selected to zero that axis. To zero out a specific axis, **PAGE UP** or PAGE DOWN in the POSIT display to the POS-OPER large-digit display page. When you Handle Jog the X, Y or Z axis and then press **ORIGIN**, the axis that is selected will be zeroed. Or, you can press an X, Y or Z letter key and then **ORIGIN** to zero that axis display. You can also press the X, Y or Z key and enter a number (X2.125), then press **ORIGIN** to enter the number in that axis display.

 Δ Jog Keys. The JOG keys (+X, -X, +Y, -Y, +Z, -Z, +A, -A, +B, -B) use the jog speeds of 100., 10., 1. and .1 inches per minute listed next to the **HANDLE JOG** key (jogging with the handwheel uses the .1, .01, .001 and .0001 inch increments). You can also adjust feedrate using the **FEED RATE OVERRIDE** buttons, which allow you to increase or decrease feedrate in 10% increments, up to 200%.

 Δ Jog Keys. You can also select an axis for jogging by entering the axis letter on the input line and then pressing the HANDLE JOG button. This works for the X, Y, Z, and A axes as well as the B, C, U, and V auxiliary axes.

OFSET

 Δ Entering Offsets. Pressing WRITE/ENTER will *add* the number in the input buffer to the cursor-selected offset value. Pressing **F1** will *replace* the selected offset with the number in the input buffer.

 Δ Entering Offsets. Pressing OFSET again will toggle back and forth between the Tool Length Offsets and Work Zero Offsets pages.

 Δ Entering Offsets. In the OFSET display, F1 will set the entered value into the offsets. F2 will set the negative of the entered value into the offsets.

△ **Coolant Spigot Position**. The coolant spigot can be programmed to move to the location entered in the OFSET display, on the Tool Geometery Offset page under CLNT POS. You can adjust the coolant nozzle up to 10 different positions for a tool. Position 1 is the farthest up and 10 is the farthest down. The nozzle will shift to that position whenever an M08 or Hnn code is executed in the program. When you cursor onto the CLNT POS column, the coolant nozzle location is displayed in the lower left corner.

 Δ **Clearing All Offsets and Macro Variables**. When you're in the Tool Length Offset display, you can clear all the offsets by pressing the **ORIGIN** key. The control will prompt: "ZERO ALL (Y/N)?" to make sure this is what you really want to do. If **Y** is entered, all the offsets in the area being displayed will be zeroed. The Work Zero Offset page and the Macro Variables page in the CURNT COMDS display will do the same thing. (Any Mill Control ver. 10.02 and above; any Lathe Control ver. 3.00 and above.)

 Δ The Mill Offers up to 200 Tool Offsets. Mills now offer up to 200 tool offsets. In all previous versions, the maximum number available was 100 tool offsets. (Any Mill Control ver. 10.22 and above.)

CURNT COMDS

△ **Current Commands**. You can see the programmed spindle speed and feedrate on the first page of the CURNT COMDS display, by looking at PGM Fnnnn and PGM Snnnn in the column on the far right. You can verify the actual feedrate and commanded spindle speed in the same column, with ACT Fnnnn and CMD Snnnn. The actual speed and feed are what the spindle speed and feedrate are really operating at with any adjustments to the **OVERRIDE** keys.

 Δ **Tool Life Management**. In the CURNT COMDS display, you can **PAGE DOWN** to the Tool Life management page. On this page the tool Usage register is added to every time that tool is called up in the spindle. You enter the number of times you want that tool to be used in the Alarm column. When the Usage number for that tool reaches the number of uses in the Alarm column, it will stop the machine with an alarm. This will help you monitor tools to prevent them from breaking and parts being scrapped.

△ **Tool Load Management**. The next **PAGE DOWN** in CURNT COMDS will bring you to the Tool Load page. Spindle load condition can be defined for a particular tool, and the machine will stop if it reaches the spindle load limit defined for that tool. A tool overload condition can result in one of four actions by the control. The action is determined by Setting 84. ALARM will generate an alarm when overload occurs; FEEDHOLD will stop with a Feed Hold when overload occurs; BEEP will sound an audible alarm when overload occurs; or AUTOFEED will automatically decrease the feedrate. This will also help you monitor tools.

 Δ **Clearing Current Commands Values**. The values in the CURNT COMDS display pages for Tool Life, Tool Load and Timer registers can be cleared by cursor-selecting the one you wish to clear and pressing **ORIGIN**. To clear everything in a column, cursor to the top of that column (onto the title) and press **ORIGIN**.

HELP

 Δ **Helpful Information**. The HELP display has a list of all the G and M codes available. To see them, press the **HELP** display key and then the letter **C**. For a listing of all the different subjects available in the Help directory, press the letter **D**, then press the letter that's next to the subject area you wish to see.



CALC

 Δ **Transferring Simple Calculations**. While in the Trigonometry, Circular or Milling and Tapping calculator, the number in the simple calculator box (in the upper left corner) can be transferred down to any cursor-selected data line. Cursor to the register you wish to transfer the calculator number to and press **F3**.

 Δ **Transferring Calculated Values**. You can transfer the highlighted value in a Trig, Circular, or Milling data register into the calculator box by pressing F4. Use the up and down arrow keys to select the data registers, including the calculator box, and the left and right arrows to select LOAD + - * /. To enter a highlighted data value into the calculator box, LOAD must be selected when you press F4. If one of the operations is selected, pressing F4 will perform that operation using the number in the highlighted data register and the number in the calculator box.

 Δ **Transferring to EDIT or MDI**. In either EDIT or MDI mode, pressing **F3** will transfer the number in the calculator box (when the cursor is on the number in the box) to either the EDIT or MDI input buffer. You will need to enter the letter (X, Y or Z) you wish to use with the number from the calculator.

 Δ **Circular Calculator**. The Circular Calculator will list four different ways that a circular move can be programmed using the values entered for a calculated solution. Four different program lines for executing the circular move will be listed at the bottom of the display. One of the four program lines can be transferred to either EDIT or MDI.

- 1. In the circular calculator, cursor onto the program line you wish to use.
- 2. Press either **EDIT** or **MDI**, where you wish to insert the circular move.
- 3. Press the **F3** key, which will transfer the circular move that you highlighted into the input buffer line at the bottom of the EDIT or MDI display.
- 4. Press **INSERT** to add that circular command line into your program.

 Δ **One-Line Expressions**. The CALC display will now accept and evaluate a simple expression. This is a new feature; previously it was only possible to enter a number into the input line of the calculator. Now, the calculator allows you to enter a simple, one-line expression without parentheses, such as 23*4–5.2+6/2. It will be evaluated when the **WRITE/ENTER** key is pressed and the result (89.8 in this case) displayed in the calculator box. Multiplication and division are performed before addition and subtraction. (Any Mill Control ver. 9.49 and above; any Lathe Control ver. 2.24 and above.)

SETNG

 Δ Scrolling through Settings with Jog Handle. The jog handle can now be used to scroll through the settings. (Any Mill Control ver. 10.15 and above; any Lathe Control ver. 3.05 and above.)

 Δ There are so many settings which give the user powerful and helpful command over the control that you should read the entire Settings section of the operator's manual. Here are some of the useful settings, to give you an idea of what is possible.

Setting 1 AUTO POWER OFF TIMER. This turns the machine off after it is idle for the number of minutes defined in this setting.

Setting 2 POWER OFF AT M30. This will power off the machine when an M30 command is executed. In addition, for safety reasons, the control will turn itself off if an over-voltage or overheat condition is detected for longer than four minutes.



Setting 8 PROG MEMORY LOCK. When this is Off, control program memory can be modified. When this setting is turned On, memory edits cannot be done and programs cannot be erased.

Setting 9 DIMENSIONING. This changes the machine control from inch to metric, which will change all offset values and position displays accordingly. This setting *will not* change your program to either inch or metric.

Setting 31 RESET PROGRAM POINTER. When this is On, the **RESET** key will send the cursor (program pointer) back to the beginning of the program.

Setting 77 SCALE INTEGER F. This can be used to change how the control interprets a feedrate. A feedrate that is entered in your program can be misinterpreted if you do not enter a decimal point in the Fnn command. The selections for this setting are Default, which assumes a 4-place decimal if no decimal point is entered (i.e., if you enter a 1, it assumes you mean 0.0001); Integer, which assumes a whole number (enter a 1, it assumes 0.1), .01 or .001 (you get the idea), or .0001, which is the same as the Default setting.

Setting 84 TOOL OVERLOAD ACTION. This is used to determine tool overload conditions as defined by the Tool Load monitor page in the CURNT COMDS display (use **PAGE DOWN** to get there). A tool overload condition can result in one of four actions by the control, depending on Setting 84. ALARM will generate an alarm when overload occurs; FEEDHOLD will stop with a Feed Hold when overload occurs; BEEP will sound an audible alarm when overload occurs; or AUTOFEED will automatically decrease the feedrate.

Setting 85 MAX CORNER ROUNDING. On a Haas control, this setting is used to set the corner rounding accuracy required by the user. The accuracy defined in Setting 85 will be maintained even at maximum feedrate. The control will only slow at corners *when it is needed*. (This setting defeats all the years of discussion by competitors who say you need multiple blocks of look-ahead.)

Setting 88 RESET RESETS OVERRIDE. When this is On, the RESET key sets all overrides back to 100%.

Setting 103 CYC START / FH SAME KEY. This is really good to use when you're carefully running through a program. When this setting is On, the CYCLE START button functions as the Feed Hold key as well. When CYCLE START is pressed and held in, the machine will run through the program; when it's released, the machine will stop in a Feed Hold. This gives you much better control when setting up a new program. When you're done using this feature, turn it Off. This setting can be changed while running a program. It cannot be On when Setting 104 is On. (Any Mill Control ver. 9.06 and above.)

Setting 104 JOG HANDL TO SNGL BLK. When running a program in MEM mode in the Program or Graphics display, you can use the **SINGLE BLOCK** key to cycle through your program one line at a time, with each press of the **CYCLE START** button, whether the machine is in operation or you're in Graphics. If you turn Setting 104 On, then each counterclockwise click of the jog handle will step through a program line. Turning the handle clockwise will cause a Feed Hold. This setting can be changed while running a program. It cannot be On when Setting 103 is On. (Any Mill Control ver. 9.06 and above.)

Setting 114 CONVEYOR CYCLE (MIN). If this is set to zero, the conveyor will operate normally. If another number is entered, it defines how long (in minutes) each cycle will be when the chip conveyor is turned on. The chip conveyor cycle is started with either an M code (M31 or M32) or with the control **CHIP FWD/REV** keys. It will stay on for the time defined in Setting 115, then turn off and not restart until the cycle time in Setting 114 has elapsed.

Setting 115 CONVEYOR ON TIME (MIN). This setting works with Setting 114, which defines the conveyor cycle time. Setting 115 defines how long the chip conveyor will stay on during each cycle.

80



Setting 118 M99 BUMPS M30 CNTRS. When this setting is Off, the feature is disabled. When it is On, an M99 command that is used to run a program repeatedly will activate the M30 counters that are in the CURNT COMNDS display (**PAGE DOWN** twice). Note that an M99 will only activate the counters when it is used in a loop mode in a *main* program, not a subprogram. An M99 that's used as a subprogram return or with a P value to jump to another part of the program won't be counted. (Any Mill Control ver. 9.58 and above. Any Lathe Control ver. 3.00 and above.)

Setting 130 RIG. TAP RETRACT MULT. This feature augments one introduced in version 10.13, the quick reversal out of a G84 rigid-tapped hole. If it is set to 0 or 1, the machine behaves normally. Setting it to 2 is the equivalent of a G84 command with a J value of 2. That is, the spindle will retract twice as fast as it went in. If this setting is set to 3, the spindle will retract three times as fast. Note that specifying a J value in a G84 command for rigid tapping will override Setting 130. (Any Mill Control ver. 10.18 and above).

GRAPH

 Δ **Zooming in**. In Graphics display, use **F2** to zoom in on the graphic. After pressing F2, press **PAGE DOWN** to zoom in further and **PAGE UP** to expand the view. Use the cursor arrows to position the zoom window over the section of the part that you wish to view in close-up. Press **WRITE/ENTER** to save the new zoom window, and **CYCLE START** to see the close-up graphic run. Press **F2** and then **HOME** to get back to the original full table view.

PARAM

△ **Changing Parameters**. Parameters are seldom-modified values that change the operation of the machine. These include servo motor types, gear ratios, speeds, stored stroke limits, lead screw compensations, motor control delays and macro call selections. *Modifying some of these functions will void the warranty on the machine*. If you need to change parameters, contact Haas Automation or your dealer. Parameters are protected from being changed by Setting 7. Be sure to *download and save* a copy of your machine parameters so you'll have a back-up if needed (refer to the LIST PROG section to see how to save your offsets, settings and parameters to a floppy disk).

DGNOS

This display is used to show the status of the machine for diagnostics and servicing.

ALARM

 Δ **Alarm History Display**. There is an alarm history that displays the previous 100 alarms. Pressing the right or left cursor arrow while in the Alarm display will list the last 100 alarms, with their date and time. You will need to use the cursor up arrow to see the alarms previous to the last one. Pressing either the left or right arrow again will bring you back to the normal Alarm display.

 Δ Alarm History Saved to Disk or RS232. The last 100 alarms can be saved to a floppy disk by entering a file name and pressing F2 while on the Alarm history page. Alternately, the alarm history can be sent to a PC using RS232 by pressing SEND RS232.

MESGS

△ **Leaving Messages**. You can enter a message in the MESGS display for the next person, or for yourself. It will be the first display shown when you power up the machine, *if there are no alarms* other than the usual 102 SERVOS OFF alarm. If the machine was powered down using **EMERGENCY STOP**, the MESGS display will not show up when you turn the machine on again. Instead, the control will display the active alarm generated by the emergency stop. In this case, you would have to press the **ALARM/MESGS** key to view a message.





EDIT

 Δ **The Edit Display**. When you press **EDIT**, the first display you see is the Advanced Editor display. This display has menus in the upper left that allow the user to access features of the Advanced Editor; the menus are activated by pressing **F1**. Pressing the **PRGRM/CONVRS** key will bring up the (visually) larger Edit display. Pressing **PRGRM/CONVRS** a second time will get you into the Quick Code editor, which can also be accessed from the Advanced Editor within the F1: HELP pull-down menu.

 Δ **Advanced Editor Menus**. Pressing **F1** in the Advanced Editor will activate the menus. The menu selections are made with the jog handle, turning it either clockwise or counterclockwise, or with the cursor arrow keys. Press the **WRITE/ENTER** key to activate the cursor-selected menu item.

 Δ Advanced Editor On-line Help. In the Advanced Editor, after pressing F1 to access the menus, on-line Help is displayed in the lower right corner of the screen. To scroll through the Help text, use the PAGE UP, PAGE DOWN, HOME, and END keys (remember, the cursor arrows move you through the menu items, not the Help text). In addition, if the F1 key is pressed during the use of a menu option, the Help text is likewise displayed. Pressing F1 again will exit the Help display.

 Δ **Lower-Case Text**. In the Editor, you can enter lower-case text if it's between parentheses (that is, for comments only). Press the **SHIFT** key first (or hold it in) and then the letter you want in lower case (remember, this works for parenthetical comments only). When lower-case text is selected (highlighted), it will appear in caps; deselected, it returns to lower case. To type the white symbol in the upper left corner of the numeric keys, press **SHIFT** and then the key. These symbols are used for parenthetical comments or for macros.

 Δ Editing in the Advanced Editor. In the 80-column Advanced Editor you can select a program block and copy it to another location, move it from one location to another, or delete it. To start the block definition, press F1 to get into the menus, use the jog handle or the cursor arrows to select to select the EDIT menu and the SELECT TEXT menu item, then press WRITE/ENTER. Another way to begin text selection is to put the cursor on the program line where you want the selection to begin and press F2. In either case, once you've defined the beginning, you then use the cursor arrows to go to the line where the selection should end, and press F2 or WRITE/ENTER. This will highlight the section you want to copy, move or delete. Then, use the EDIT menu (or the EDIT keys) to copy (INSERT), move (ALTER) or delete (DELETE) the selected block.

△ **To Undo an Edit**. Pressing **UNDO** will change back as many as the last ten simple edits (INSERT, ALTER, DELETE) that were done. Sometimes you can even edit some code, run the program, and then if you need to change it back after running it, it may let you do that using the **UNDO** key. **UNDO** *does not undo program edits in Block Edit*. In Block Edit, it only deselects text.

 Δ **Block Editing in the Advanced Editor**. You can copy a line or a block of lines from one program into another. Select the program block you wish to transfer to another program using the method outlined above (in the "Editing in the Advanced Editor" paragraph). Then press **SELECT PROG** (or use the PROGRAM menu), scroll to the program you want to copy to, and press **WRITE/ENTER** to select it. It will open up on the right side of the screen. Cursor to where you want the selected text to be placed and press **INSERT** (to deselect text after it's been moved, press **UNDO**). Use the **EDIT** key to go back and forth between two open programs on the screen.

 Δ **Block Editing in the Larger Editor Display**. You can move a block of lines from one program to another in the (visually) larger Editor display (press **EDIT** and then **PRGRM/CONVRS** once to get to the larger editor). In this Editor, define the first block by pressing **F1**, and then cursor to the last line you want in the selection and press **F2**. This will highlight that section of the program. Then select another program using **LIST PROG** and copy the selection into the new program by pressing **INSERT**.



 Δ **Exiting Block Edit.** You can turn off Block Edit highlighting by pressing the **UNDO** key; the cursor will remain where you're at in the program. **UNDO** *will not* change back an edit done in Block Edit. **RESET** will also turn off the block highlight, but the cursor will go back to the beginning of the program.

△ Advanced Editor Searching. When the SEARCH menu FIND TEXT item is used and the text is found, the next press of F1 to activate the menus will automatically select the FIND AGAIN option. Likewise, when the SELECT TEXT function on the EDIT menu is used, the next activation of the menus will cause the COPY SELECTED TEXT option to be highlighted.

 Δ Editing Two Versions of the Same Program. In Edit mode, F4 is the hot key that displays another version of the active program for editing. The same program will be displayed on both halves of the screen, and each program can be edited alternately by using the EDIT key to switch from one side to the other. Both programs will be updated with the edits done while you're switching back and forth. This is useful for editing a long program; you can view and edit one section of the program on one side of the screen and another section on the other side.

 \triangle **A Quick Cursor Arrow in the Advanced Editor**. You can call up a cursor arrow with which to scroll through your program quickly, line by line, when you're in the Advanced Editor. For the quick cursor arrow, press **F2** once; then you can use the jog handle to scroll line by line through the program. To get out of this quick-cursor mode and remain where you are in the program, just press the **UNDO** key. (Any Mill Control ver. 9.49 and above; any Lathe Control ver. 2.24 and above.)

PROGRAMMING

 Δ **Program Format at the Beginning and End.** Programs written on a PC and sent to the control from a floppy disk or through the RS-232 port must start and end with a % sign, on a line by itself. The second line in a program received via floppy or RS-232 (which will be the first line the operator sees) must be Onnnnn, a six-character program number that starts with the letter **O** followed by five digits. When you create a program on the Haas control the percent (%) signs will be entered automatically, though you won't see them displayed.

 Δ **Program Format with M06**. It is not necessary to turn off the coolant (M09), stop the spindle (M05), or move the Z axis home (G28) prior to a tool change. The control will do these tasks for you during a tool change M06 command. However, you may decide to program these commands anyway for convenience and timely execution of a tool change sequence. If you're using Single Block to step through a program you will be able to see the commands when you stop on that line.

 Δ **Tapping with G84 or G74**. When tapping, you don't need to start the spindle with an M03 or M04 command. The control starts the spindle for you automatically with each G84 or G74 cycle, and it will in fact be faster if you don't turn on the spindle with an M03 or M04. The control stops the spindle and turns it back on again in the G84 or G74 tapping cycle to get the feed and speed in sync. The operator just needs to define the spindle speed.

 Δ **Quick Reverse Out of a G84 Rigid Tapping Cycle**. This feature for rigid tapping has the spindle back out faster than it went into a tapped hole. The way to specify this is with a J code on the G84 command line. J2 retracts twice as fast as the entry motion; J3 retracts three times as fast, and so on, up to J9. A J code of zero will be ignored. If a J code less than 0 or greater than 9 is specified, Alarm 306 — "INVALID I, J, K or Q" — is generated. The J code is not modal and must be specified in each block where this effect is wanted. The J value should not contain a decimal point. (Any Mill Control ver. 10.13 and above.)

 Δ **M19 (Orient Spindle) with a P Value**. This feature works on any vector drive mill. Previously, the M19 command would simply orient the spindle to only one position — that suitable for a tool change. Now, a P value can be added that will cause the spindle to be oriented to a particular position (in degrees). If a whole number is used for the P value, no decimal point is needed. For example, M19 P270 will orient the spindle to 270 degrees. Note that P270.001 (or any other fraction) will be truncated to P270, and P365 will be treated as P5. (Any Mill Control ver. 9.49 and above. Any Lathe Control ver. 2.21 and above.)





△ **M19 (Orient Spindle) with a Fractional R Value**. This feature works on any vector drive mill. An M19 R123.4567 command will position the spindle to the angle specified by the R fractional value; up to 4 decimal places will be recognized. This R command now *needs a decimal point*: if you program M19 R60, the spindle will orient to 0.060 of a degree. Previously, R commands were not used for this purpose and only integer P values could be used. (Any Mill Control ver. 9.49 and above; any Lathe Control ver. 2.29 and above.)

△ **Duplicating a Program in LIST PROG**. In the LIST PROG mode, you can duplicate an existing program by cursor-selecting the program number you wish to duplicate, typing in a new program number (**O**nnnn), and then pressing **F1**. You can also go to the Advanced Editor menu to duplicate a program, using the PROGRAM menu and the DUPLICATE ACTIVE PROGRAM item.

COMMUNICATIONS

 Δ **Program Format to Receive.** You can receive program files from a floppy disk or the RS-232 port into the Haas control. Each program must begin and end with a % sign on a line with nothing else on that line. There also must be an **O**nnnnn program number on the line after the % sign in each program. If there is a (Program Name), it should be entered between parentheses, either after the program number on the same line or on the next line. The program name will appear in the program list.

A **Receiving Program Files from a Floppy Disk**. You can load program files from a floppy disc using the I/O menu and the FLOPPY DIRECTORY item of the Advanced Editor. Pressing **WRITE/ENTER** when this menu item is selected will display a list of the programs on the floppy disk. Use the cursor arrow keys or the handwheel to select the file you need to load, and press **WRITE/ENTER**. After loading that file, the floppy directory will remain on display to allow more files to be selected and loaded into the control. **RESET** or **UNDO** will exit this display.

△ **I/O Menu SEND RS232 or SEND FLOPPY Commands**. You can send programs to the RS232 port or a floppy disk from the Advanced Editor. After selecting the menu item you want (SEND RS232 or SEND FLOPPY), a program list will appear. Select the program you want to save, or "ALL" (at the end of the list) if you wish to send all programs under one file name. You can also select any number of programs using the up and down cursor arrow keys or the handwheel and the **INSERT** key to mark the specific programs to send. If no programs are selected from the list using the **INSERT** key, the currently highlighted program will be sent.

 Δ Sending Multiple Programs Under One File Name. In the Advanced Editor, you can send multiple program files via the RS232 port or a floppy disk, using the SEND 4S232 or SEND FLOPPY commands under the I/O menu (see the previous paragraph for how to do this). The Advanced Editor allows you to choose several programs (select them using the cursor and the INSERT key) and save them under one file name that you type in; then press WRITE/ENTER to save and send it.

(Any Mill Control ver. 9.49 and above; any Lathe Control ver. 3.00 and above.)

A Sending Multiple Programs Using Program Numbers. The SEND FLOPPY item from the I/O menu of the Advanced Editor allows the operator to select one or more programs to be saved to floppy disk. It will prompt you to "ENTER FLOPPY FILENAME." In previous versions, the control would insist on a file name. Now, however, if you do not enter a file name, but simply press WRITE/ENTER, the control will save each program (the ones you selected using the cursor and the INSERT key) to a separate file on the floppy and use the five-digit program number as the file name. For example, if programs O00123 and O45678 are selected, the new file names created will be O00123 and O45678. (Any Mill Control ver. 9.49 and above; any Lathe Control ver. 3.00 and above.)

 Δ Sending a Program File from LIST PROG Display. You can send a file or files to a floppy disk or through the RS-232 port from the LIST PROG display. Use the cursor arrows and the **INSERT** key to select the program(s) you want, or "ALL" if you want to send all of them under one file name. When you press **F2** to send the selected program(s), the control will ask for a floppy file name, which can be up to eight characters long with a three-letter extension (8CHRCTRS.3XT). Then press **F2** again to send it. You can also use the I/O menu in the Advanced Editor to send and receive program files.



 Δ Sending Multiple Programs from LIST PROG Using SEND RS232. Several programs can be sent to the serial port by typing all the program names together on the input line without spaces (e.g., O12345O98765O45678) and pressing SEND RS232.

 Δ **RS-232 Communications Using X-Modem**. If you are seeing occasional errors when using RS-232 communications, X-Modem (Setting 14) is a standard communications mode which is very reliable when only a few errors occur. Our control supports this, as do almost all software communication packages for PCs.

 Δ Haas Rotary Table Using the Serial Port and Macros. It is possible to regulate a Haas rotary table using the serial port and macros from the Haas control, or *any* Fanuc-compatible control. There is a set of sample macros available from the Haas applications department.

△ Send and Receive Offsets, Settings, Parameters and Macro Variables to/from Disk. You can save offsets, settings, and parameters to a floppy disk. *Press* LIST PROG *first*, then select an OFSET, SETNG or PARAM display page. Type in a file name and then press F2 to write that display information to disk (or F3 to read that file from a disk). You can also do this with the macro variables by pressing LIST PROG *first*, then selecting the macro variable display page (PAGE DOWN from CURNT COMDS).

△ Send and Receive Offsets, Settings, Parameters and Macro Variables to/from RS232. You can also save offsets, settings, and parameters via the RS-232 port. *Press* LIST PROG *first*, and then select an OFSET, SETNG, or PARAM display page. Press SEND RS232 to send that display page to the RS-232 port under the file name that you enter. Press RECV RS232 to read the file via RS-232. You can also do this with the macro variables by pressing LIST PROG *first*, then selecting the macro variable display page (PAGE DOWN from CURNT COMDS).

△ **Deleting a Program File from a Floppy Disk.** A file can be erased from the floppy drive. On the LIST PROG display, type "DEL file name" where "file name" is the name of the file on the floppy disk. Do not use the program number, unless it's also the file name. Press **WRITE/ENTER**. The message "FLOPPY DELETE" will appear, and the file will be deleted from the floppy disk. Note that this feature requires the latest floppy driver EPROM chip version 2.11. (Any Mill Control ver. 10.02 and above; any Lathe Control ver. 3.00 and above.)





3.5 FOURTH AXIS (OPTIONAL)

The following table summarizes the fourth axis options:

*For options not on the list, see the supplied parameter sheet for proper parameter values; or call the Haas service department for assistance.

Product:	Comments:
HA5C	Quick and easy to use for light loads only.
HA5C2,HA5C3 HA5C4	HA5C2 fits along Y and X axes; HA5C3, HA5C4 only along X axis.
HRT 160 HRT 160 SP	Available with 5" spindle nose. For light loads.
HRT 210 HRT 210 SP	Available with 6" spindle nose and pneumatic drawbar.
HRT 310 HRT 310 SP	Large capacity. Well-suited to VF-3 and 4.
HRT 450 HRT 600	For very large or heavy parts. Large through-hole. Ideal for VF-6.8.

Full-fourth axis: When adding an indexer to the Haas mill the settings must be set for the specific table. You must set the mill setting for the indexer that you are using. This will automatically give you the parameters that you need for that series indexer. Turn the mill on, press the E-stop switch and leave it in. Go to the settings page by pressing the setting button once. Go to setting 30 by pressing the 3 and 0 keys and then the down arrow key. This is the setting for fourth axis. Use the right arrow key to scroll to the indexer that you have. (Note: "BL" is brushless. Brushless indexers have two cables from table and two connectors at the mill control.) Press the write key to save the new setting. Press the down arrow key, then input the approximate diameter of your part with decimal point and the write key. (This sets the feed rate at the diameter of your part.) The position page will now show the position of that axis in degrees. Do the same for the fifth axis if you have a TRT.

In rare cases you may be required to modify some parameters to get a specific performance out of your indexer. Do not do this without a list of parameters to change. (If you did not get a list of special parameters with your indexer, then you do not need to change the default parameters—DO NOT CHANGE THEM. This will void your warranty.)

To change parameters for a forth or fifth axis indexer, proceed as follows: Press the e-stop switch and leave it in. You must then turn off the parameter lock. Go to the settings page by pressing the setting button. Press the 7 button and push the down arrow. This will get you to setting 7. With the cursor on setting 7, press the right arrow key and press the write key. Setting 7 is now off. Go to the parameter page and press the digits for the parameter that you need to change and press the down arrow key. Press the digits for the new parameter and press the write button. Verify the parameter reads as it is printed on your list, with the same digits. If not, retype and write it. With all parameters changed and verified to be correct, rotate and release the e-stop switch. Press the reset switch 3 times. The "servos off" alarm will disappear from the screen. Go back to the Settings page and lock the parameters. Home the indexer and verify that it operates properly by pressing the A button on the alpha keypad and pressing the handle jog mode button. Jog the A axis. The indexer should move to position without any noise (other than the air brake if applicable). Check for proper ratio by marking the table, rotate 360degrees as viewed in the position page and check mark to be in the same location. If it is close (within 10 degrees) then the ratio is correct.

Turn on the mill (and servo control, if applicable) and home the indexer. All Haas indexers home in the clockwise direction as viewed from the platter. If the indexer homes counter-clockwise, press E-stop and call the Haas service department.

3.6 INSTALLING THE HAAS FIFTH AXIS (OPTIONAL)

This section describes the features of a HAAS five-axis control, and include the installation instructions for a Haas TRT table.

The following table summarizes the fifth axis options:

*For options not on the list, see the supplied parameter sheet for proper parameter values; or call the Haas service department for assistance.

Product:	Comments:
TRT 160	Convenient compact size fits VF-1,2.
TRT 210	Fits VF-3 and VF-4 with some restrictions in tool length.
T5C	Used for small, complex geometry parts.
TR 210 TR 310	deal for multiple axis machining of heavy parts.

Besides the five directly controlled axes in this control, up to four additional external positioning axes may be added. These axes may be commanded directly from the program using the C, U, V, and W axis codes. Commands to these axes are only allowed in a G00 or G01 block. Connection of these axes is done through the second RS-232 port to one or more HAAS single axis controls. In the Setting page, Setting 38 is used to select the number of auxiliary axes. The machine position display will show the present position of these axes.

Only one auxiliary axis is moved at a time. If a feed (G01) is programmed, the feed rate programmed in the CNC is sent to the auxiliary control without any changes. For a C-axis feed at F30.0, this means that the C-axis will move at 30 degrees per second. A G00 motion of an auxiliary axis will move at its maximum feed rate. The FEED HOLD and RESET buttons will not stop an auxiliary axis. EMERGENCY STOP and SINGLE BLOCK will stop an auxiliary axis. When the CNC control is waiting for an auxiliary axis motion to complete, the bottom of the screen will display "C FIN". A failure in RS-232 communication with the auxiliary axis motion is communication.

If you add one auxiliary axis, Setting 38, then the auxiliary axis will be designated C. If you add two auxiliary axes they will be designated C and U; etc.

When interfacing to an auxiliary axis the Haas single axis servo control must have Parameter 21 set according to the following table.

Name in CNC:	Parameter 21:	Axis select	
С	6	Z	
U	1	U	
V	2	V	
W	3	W	

Multiple auxiliary axes must be daisy chained through the second RS-232 port as described in the single axis control manual.

Auxiliary axes can be jogged from the CNC front panel using the jog handle. Each step must start and stop before another one can be commanded.



There are no work offsets for these axes so all commands are in the machine coordinate system. But if a displaced zero position has been entered into the HAAS servo control, that position will be used as zero. On power-up of the CNC, the auxiliary axes control will also be initialized and zero will be shifted by the value set into the single axis control. To set a displaced zero, you must jog the single axis control to a new zero position and then press and hold the CLEAR key on the single axis control. This must only be done when the single axis control is otherwise idle.

Auxiliary axes communication is always seven data bits, even parity, two stop bits. The data rate is CNC Setting 54 and should be set to 4800. CNC Setting 50 must be set to XON/XOFF. Parameter 26 in the single axis control must be set to 5 for 4800 bit per second and Parameter 33 must be set to 1 for XON/XOFF. Parameter 12 in the single axis control should always be set to 3 or 4 to prevent circular wraparound. The cable connecting the CNC to the single-axis control must be a DB-25 cable (male lead on both ends) and must wire at least pins 1, 2, 3, and 7 directly from the second (lower) serial port of the CNC to the upper connector of the servo control.

5-Axis Programming

The Coordinate System

The layout of the **A** and **B** axes on the HAAS five-axis control are depicted in the following figures. The **A** axis is rotary motion about the **X** axis, while the **B** axis determines rotary motion about the **Y** axis. The right hand rule can be used to determine axis rotation for the **A** and **B** axes. When placing the thumb of the right hand along the positive **X** axis, the fingers of the right hand will point in the direction of tool movement for a positive A axis command. Likewise, when placing the thumb of the right hand along the right hand rule determines direction of tool movement for a positive **B** axis command. It is important to remember that the right hand rule determines direction of tool movement and not the table movement direction. For the right hand rule, the fingers will point opposite of the positive rotary table movement. Refer to the Figures

NOTE: Home direction will always be clockwise as viewed from the platter side of the rotary table.

CAUTION: If the Tilt table moves in the counter clockwise direction press the E-Stop button, as damage may occur. Contact the Haas service department for assistance.



Work coordinates (Positive direction).

G Operator's Manual



Table movement (Positive command).



Alphabetical Address Codes

B Fifth axis rotary motion

The **B** address character is used to specify motion for the optional fifth, **B**, axis. It specifies an angle in degrees for the rotary axis. It is always followed by a signed number and up to three fractional decimal positions. If no decimal point is entered, the last digit is assumed to be 1/1000 degrees. The smallest magnitude is 0.001 degrees, the most negative value is -8380.000 degrees, and the largest number is 8380.000 degrees.

Preparatory Functions (G codes)

In a control configured with a fifth axis, all G codes that have an option for an **A** axis motion command can also simultaneously command fifth axis, **B**, motion. Of course, since address **B** is modal, it can be entered on any line. The following G codes are users of address B:

G00	G03	G29	G73	G77	G83	G86	G89	G101
G01	G10	G31	G74	G81	G84	G87	G92	G102
G02	G28	G36	G76	G82	G85	G88	G100	G136

Inch/Metric Selection (G20,G21)

Fifth-axis programming is not effected by the selection of metric. It is always programmed in degrees.

Work Coordinate Systems

The work coordinate systems on a control with a fifth axis accommodates **B**, the fifth axis. Work coordinate offsets can be set for the **B** axis in the offset display.

M Codes

M12 Engages the fifth axis brake.

This M code waits until the M-fin signal is received through the secondary RS-232 port. (Semi-fifth)





M13 Releases the fifth axis brake.

This code activates the fifth axis brake relay and waits for the M-fin signal, releases the relay upon receipt, and waits for the M-fin signal to cease. The RESET key will terminate any operation that is hung-up waiting for M-fin.

Both M12 and M13 are aliased by M10 and M11 on fourth-axis machines. (Semi-fifth)

Handle/Jog

All aspects of handle jogging for the fifth axis work as they do for the other axes. The exception is the method of selecting jog between axis **A** and axis **B**.

By default the '+A' and '-A' keys, when pressed, will select the **A** axis for jogging. The display will show "JOGGING AAXIS HANDLE .01" while you are jogging the **A** axis. The **B** axis can be selected for jogging by pressing the 'shift' key, and then pressing either the '+A' or '-A' key. When this is done the control will switch to jogging the **B** axis and the display will change to "JOGGING BAXIS HANDLE .01".

The axis assigned to the '+A' and '-A' keys will remain selected for jogging even if the operating mode is changed or if the machine is turned off. The selected axis for '+A' and '-A' can be toggled by pressing the shift key prior to pressing the '+A' or '-A' keys.

Settings

The fifth axis, or rotary table, may be disabled from the setting page and removed from the machine. Do not connect or disconnect any cables with the control on. If you do not disable the fifth axis when it is disconnected, you will get an alarm.

The settings listed here are settings that have been added to a fifth-axis control.

Number:	<u>Name:</u>	Range of value:
78	FIFTH-AXIS ENABLE	OFF,S5C,7RT,9RT,SRT,11RT, HA5C, HRT 160, HRT 210, HRT 310
79	FIFTH-AXIS DIAMETER	0 to 29.9999 inches
80	MIRROR IMAGE B AXIS	ON or OFF

The following is a detailed description of each of the settings.

78 FIFTH-AXIS ENABLE

This is an on/off setting. When it is off, the fifth axis is disabled and no commands can be sent to that axis. When it is on, the selected rotary table type parameters are called up. A change to rotary parameters is saved under the selected table type for later recall.

79 FIFTH-AXIS DIAMETER

This is a numeric entry. It is used to set the angular feed rate of the **B**-axis. It must be in the range of 0.0 to 29.9999 inches. Since the feed rate specified in a program is always inches per minute (or mm per minute), the control must know the diameter of the part being worked in the **B**-axis in order to compute the angular feed rate. When this setting is set correctly, the surface feed rate on a rotary cut will be exactly the feed rate programmed into the control. The feed rate will be correct only as long as the axis remains orthogonal (at right angles to) to the Y axis.

80 MIRROR IMAGE B-AXIS

This is an On/Off settings. When it is off, axes motions occur normally. When it is on, the B axis motion is mirrored (or reversed) around the work zero point.



Tool Offsets

Work offsets can be specified for the fifth axis B address.

The work offset display is found on the offset display page. If the fifth axis is enabled, setting 78, then additional data fields are made available for the fifth axis.

The function of the offset display page has been modified slightly to accommodate multiple axes. Only the axes that are enabled are displayed on the work offset display. For example, if the fourth axis is enabled, setting 30, and the fifth axis is not, then display will show X,Y,Z,A. In this case, all axes can be displayed on the entire display. If only the fifth axis is enabled, then the display will show X,Y,Z,B. Since the fourth axis is disabled, there is no need to display it.

If both **A** and **B** axes are enabled, then the last column of the offsets display serves a dual purpose. Either **A** or **B** can be accessed in the last column. By using the left or right arrow keys, the screen cursor can be moved into the axis field that is to be set. When the right most field is highlighted by the cursor and the top of the column indicates A, then the values in this column represent **A** axis offsets. If you press the right arrow key once, the cursor stays in the same place, but the column and its values will change to **B** axis parameters. You can view and modify work offsets in this manner using the left and right arrow keys when both axes are enabled.

Parameter Display

The Parameter Display organization has been modified to accommodate the extra axis parameters. Parameter numbers have remained the same as in a four-axis control. Additional parameters have been added for the fifth axis.

The parameters have been reorganized, so that logically-associated parameters are grouped together. These logical groupings are placed together into contiguous screens called pages. The most commonly changed parameters have been placed at the beginning of the page list.

PAGE TITLE

DATA DESCRIPTION

MACRO M CALLParameters that alias M codes to subroutineMACRO G CALLParameters that alias G codes to macros.X BIT SWITCHBit switches for the X axis.X PARAMETERAFirst page of X axis parameters.X PARAMETERBSecond page of X axis parameters.Y BIT SWITCHBit switches for the Y axis.Y PARAMETERAFirst page of Y axis parameters.Y PARAMETERBSecond page of Y axis parameters.Y PARAMETERBSecond page of Y axis parameters.Z PARAMETERBSecond page of Y axis parameters.Z PARAMETERAFirst page of Z axis parameters.Z PARAMETERAFirst page of Z axis parameters.Z PARAMETERBSecond page of Z axis parameters.A BIT SWITCHBit switches for the A axis.A PARAMETERAFirst page of A axis parameters.B BIT SWITCHBit switches for the B axis.B PARAMETERAFirst page of B axis parameters.B PARAMETERAFirst page of B axis parameters.S CREW COMPX axis screw compensation value.Y SCREW COMPY axis screw compensation value.



The HOME key displays the first parameter page "COMMON SWTCH". Pressing the PAGE DOWN key will display the next page of parameters in the above list. The END key displays the last parameter page "B PARAMETERB". Pressing the PAGE UP key will display the preceding page of parameters in the above list. All other features on the parameters display have remained the same. So, if you are unfamiliar with the new format of the parameters, you can still search by parameter number. Enter the number of the parameter you want to see or view and press the up or down arrow key. The page that the parameter is on will be displayed and the parameter being searched for will be highlighted.

Diagnostic Data Display

The first page of diagnostic data shows two discrete outputs that control the rotary axes brakes; they are labeled "Brake 4th Axis" and "Brake 5th Axis". The 4th axis is synonymous with the A-axis, and the 5th axis is synonymous with the B-axis. If the Air Brake Parameter for the axis is set to 1, the HAAS control unclamps the brake whenever motion is commanded to the rotary axis and sets the brake back to its previous state as soon as the motion stops. The brake is activated by a relay. The two discrete outputs show the state of the brake relays. If the output is high (1) the brake is unclamped. When the machine is first powered up the brake will be unclamped, so the output will be low (0). When the brake is unclamped the message A UNCLMP or B UNCLMP is displayed in the message area near the bottom of the display.

The M11 and M13 codes command the brake to be unclamped. When these codes are in effect, the axis brake will remain unclamped even after motion has stopped.

The second page of diagnostic data show the status of inputs from the motor interface board. Additional inputs for the expanded motor interface board are listed under "INPUTS4". These bits are monitored by the control to determine if the interface for the **B** axis is working correctly.

Parameters

Additional parameters specifying the fifth axis have been added to the parameter list **B** axis parameter numbers range from 151 through 175. The parameter descriptions and their number assignments are listed below in the order that they are arranged on the **B** parameter pages.

Parameters listed here in order of appearance on display pages.

B BIT SWITC	H					
Parameter	151	В	SWITCHES			
B PARAMETER A						
Parameter	152	В	P GAIN			
Parameter	153	В	DGAIN			
Parameter	154	В	I GAIN			
Parameter	155	В	RATIO (STEPS/INCH)			
Parameter	156	В	MAX TRAVEL (STEPS)			
Parameter	157	В	ACCELERATION			
Parameter	158	В	MAX SPEED			
Parameter	159	В	MAX ERROR			
Parameter	160	В	FUSE LEVEL			
Parameter	161	В	BACK EMF			
Parameter	162	В	STEPS/REVOLUTION			
Parameter	163	В	BACKLASH			
Parameter	164	В	DEAD ZONE			
Parameter	165	В	IN POSITION LIMIT B			
Parameter	166	В	MAX CURRENT			
Parameter	167	В	D*D GAIN FOR B			



B PARAMETER B

Parameter	168	В	ACC/DEC T CONST
Parameter	169	В	PHASE OFFSET
Parameter	170	В	GRID OFFSET
Parameter	171	В	EXACT STOP DIST
Parameter	172	В	FRICTION FACTOR
Parameter	173	В	ACCEL FEED FORWARD
Parameter	175	В	AIR BRAKE DELAY

3.7 HIGH SPEED MACHINING (OPTIONAL)

High Speed Machining is an option that can be added to any Haas mill. It is most often required for the machining of smoothly sculpted shapes as is typical of mold making.

High speed machining means many different things to different people. Sometimes it is taken to mean high speed spindle; the Haas control has 7500 RPM standard and up to 15000 RPM as an option. Sometimes it is taken to mean high feed rates; the Haas control has 500 inches per minute in G01 (linear motion) standard. Sometimes it is taken to mean high "blocks per second" rate; the Haas control has 1000 blocks per second standard. The most important feature, though, is "block lookahead".

The Haas option for "High Speed Machining" increases the amount of lookahead to 80 blocks and allows full speed (500 inches per minute) blending of feed strokes. Determining when you need the High Speed Machining option can be done with the following table of stroke lengths:

Machine Type	VF0VF2	VF3VF5	VF6VF9	HS,VB1 VF10,VR11
Feed in/min:		Stroke Leng	th in inches	
20	0.0039	0.0051	0.0077	0.0154
50	0.0241	0.0321	0.0482	0.0963
100	0.0963	0.1284	0.1927	0.3853
150	0.2167	0.2890	0.4335	0.8670
200	0.3853	0.5138	0.7707	1.5413
300	0.8670	1.1560	1.7340	3.4680
400	1.5413	2.0551	3.0826	6.1652
500	2.4083	3.2111	4.8166	9.6332

To use the above table starting with your machine and feed rate, find the listed stroke length. If you are using linear moves longer than the stroke length, you do not need high speed machining. If you are using linear moves shorter than the stroke length, you do need high speed machining.

It is important to understand that high speed machining works best with smoothly blended shapes where the feed rate can remain high through the blend of one stroke to the next. If there are sharp corners, the control will always need to slow down; even if you have the high speed machining option. Sharp corners can never occur at high speed; either rounding of the corners occurs or the control must slow the feed rate.

The affect that blending of strokes can have on feed rate is always to slow down motion. It can never speed up motion. The programmed feed rate (F) is thus a maximum and the control will sometimes go slower than that in order to achieve the required accuracy.

Remember that too short of a stroke length can result in too many data points and that can result in a "blocks per second" demand which is above what the control can do. Check how your CAD system generates data points to insure that you do not exceed 1000 blocks per second.

Also remember that too few data points can result in either "facetting" or blending angles which are so great that the control must slow down the feed rate. Facetting is where the desired smooth path is actually made up of short, flat, strokes that are not close enough to the desired smoothness of the path. When the angle of blending of strokes is too large, the control must reduce the feed rate in order to get that sharp angle.

3.8 Programmable Coolant Spigot (Optional *)

*This option is not field installable

The optional programmable coolant spigot allows the user to direct the coolant stream to the most optimum location in order to flush out chips from the cutting area. The direction of the coolant can be changed by the CNC program.

OPERATING THE COOLANT SPIGOT

When the spigot is enabled it will search for home if it ever loses position. If after 3 contiguous searches for home the spigot has not found home, then Alarm, 193 COOLANT SPIGOT FAILURE, is generated.

OFFSET DISPLAY WITH SPIGOT ENABLE

When the spigot is enabled, an additional field can be accessed on the tool offset display. The left column indicates CLNT POS for coolant position. By default this column has all zeros for the coolant position. If the position is zero, then the spigot will not be moved when the H code for that tool offset is in effect and an M08 is encountered in the program. If a value is placed into the field, then the spigot will be moved to that value if the corresponding H code is in effect and M08 is executed.

Spigot Program Commands

There are two ways that the spigot can be moved under program control. The first, as just discussed, is by entering positional values into the CLNT POS fields on the tool offset display page. Having positional values entered into the CLNT POS field does not mean that the spigot will move. Only when the M08 command is executed and the current H code has a value in its CLNT POS field, will the spigot move to the designated position.

The second method of moving the spigot is by programming M34 or M35.

M34 moves the spigot in a positive direction. If the spigot is at the end of travel then no spigot movement occurs. For example, if the current spigot position is at 8 and M34 is executed, then the spigot will move to position 9. On a vertical mill this would lower the coolant stream.

M35 moves the spigot in a negative direction. If the spigot is at home position then no spigot movement occurs. For example, if the current spigot position is at 8 and M35 is executed, then the spigot will move to position 7. On a vertical mill this would raise the coolant stream.

It is important to note that each programming method requires the operator to specifically program the spigot in reference to the particular tool being used, while also taking into consideration the tool length, width and size of the part.

Spigot Parameters

The parameters that control the spigot are below.

SPIGOT POSITIONS	Parameter	206
SPIGOT TIMEOUT (MS)	Parameter	207

Spigot M Codes

M34 Increment Coolant Spigot Position

M34 increments the current spigot position one place. Incrementing the spigot position causes the spigot to advance away from the spigot home position. The home position is designated as zero. If the current spigot position is 5 and M34 is executed, then the current spigot position will advance to position 6. The Spigot home position for a horizontal mill places the spigot at the most positive Z axis location that the spigot can attain. Incrementing the spigot then lowers the coolant stream direction.

M35 Decrement Coolant Spigot Position

M35 Decrements the current spigot position one place. Decrementing the spigot position causes the spigot to move toward the spigot home position. The home position is designated as zero. If the current spigot position is 5 and M35 is executed, then the current spigot position will move to 4. The Spigot home position for a horizontal mill places the spigot at the most positive Z axis location that the spigot can attain. Decrementing the spigot will raise the coolant stream direction.

3.9 AUTOMATIC CHIP AUGER (OPTIONAL)

The automatic chip auger assists the user in removal of chips for jobs with heavy material removal. When running, the chip auger will sense auger motor overcurrent and reverse direction momentarily, thus attempting to free up chip jams. This procedure will be repeated until chips are cleared or auger retry limit (Parameter 219) is reached. If the chip auger is running and the door is opened, the chip auger will stop, thus adding a degree of safety to auger operation. If there is no axis motion or keyboard action within the time set in Parameter 255, the auger will automatically shut off.

NOTE: It is recommended that the chip auger be used intermittently. Continuous operation will cause the motor to overheat.

Auger Keyboard Commands

The auger can be started at any time from the keyboard. The auger can be enabled in either direction by pressing the CHIP FWD or CHIP REV and stopped by pressing the CHIP STOP key. The auger will also stop by pressing the RESET key.

Auger Program Commands

Use M codes M31, M32 and M33 to control the auger from within a program or in MDI. M31 commands the auger forward, M32 commands the auger in reverse and M33 stops the auger. Refer to the "M Codes" section for a more detailed description.

NOTE: On a machine with a safety circuit, the chip auger will only run with the door closed regardless of the Conveyor Door Override bit.



Auger Parameters

The parameters that control the auger are below.

CNVYR RELAY DELAY	Parameter 216	CNVYR IGNORE OC TIM	Parameter 217
CNVYR RETRY REV TIM	Parameter 218	CNVYR RETRY LIMIT	Parameter 219
CNVYR RETRY TIMEOUT	Parameter 220	CNVYR TIMEOUT	Parameter 255

Auger M Codes

M31 **Chip Conveyor Forward**

M31 starts the chip auger motor in the forward direction. The forward direction is defined as the direction that the auger must move to transport chips out of the work cell. If the auger motor is on, then the auger will be stopped and restarted in the forward direction.

M32 Chip Conveyor Backward

M32 starts the chip auger motor in the reverse direction. The reverse direction is defined as the direction opposite of forward. If the auger motor is on, then the auger will be stopped and restarted in the reverse direction.

M33 **Chip Conveyor Stop**

M33 Stops Auger motion.

3.10 THROUGH THE SPINDLE COOLANT (TSC) (OPTIONAL*)

*This option is not field installable

OPERATION

The HAAS Through The Spindle Coolant (TSC) option includes an auxiliary coolant pump that is used to supply high pressure coolant to the cutting tool. The wear surfaces of the seal are engaged only when TSC is in use.

Maximum pressure is 300 psi when using small orifice tools. Pressure will be lower when using large orifice tools. Maximum flow is 5 gpm. The maximum spindle speed when using the TSC system is 10,000 RPM.

M88 and M89 control the TSC. M88 is used to turn the system on, and M89 is used to turn it off.

The AUX CLNT button on the control panel may also be used to control TSC. Pressing this button while in MDI mode will turn on the TSC system, and pressing it again will shut off the system.

> NOTE: Running an M04 (Spindle Reverse) command with TSC on is not recommended.

Coolant will flow from the drain line during normal TSC operation. Up to 2 cups per minute flow is normal.

When the coolant system is turned off (M89), the spindle is stopped, the pump is shut off, and air flows through the spindle and the TSC drain line for 2-1/2 seconds to purge leftover coolant.

If coolant pressure does not come on within 60 seconds, the system shuts down and gives Alarm 151 (Low Tool Coolant), check the coolant level in the coolant tank.

When TSC is on, and RESET or EMERGENCY STOP are pressed the control turns off the TSC coolant pump, turns on purge for the time in Parameter 237 and then turns off purge.

Refer to the "Maintenance" section for TSC system maintenance information.

SAMPLE PROGRAM

Note that the M88 command appears before the spindle speed command in this program. This is a good programming practice; otherwise, having the M88 after the spindle speed command will stop the spindle, start TSC, then restart the spindle, slowing the cycle time.

(TSC Coolant Through Drill)
(Turn TSC on)
(Turn TSC off)

General Warnings

The TSC pump is a precision gear pump and will wear out faster and lose pressure if abrasive particles are present in the coolant.

Shortened pump life, reduction of pressure and increased maintenance are normal and to be expected in abrasive environments and are not covered by warranty.

Use of coolants with extremely low lubricity can damage the TSC coolant tip and pump.

Running an M04 (Spindle Reverse) command with TSC on is not recommended.

When machining castings, sand from the casting process and the abrasive properties of cast aluminum and cast iron will shorten pump life unless a special filter is used in addition to the 100 mesh suction filter. Contact HAAS for recommendations.

Machining of ceramics and the like voids all warranty claims for wear and is done entirely at customer's risk. Increased maintenance schedules are absolutely required with abrasive swarf. The coolant must be changed more often and the tank thoroughly cleaned of sediment on the bottom. An auxiliary coolant filter is recommended.

• Proper tooling, with a through-hole, must be in place before using the TSC system. Failure to use proper tooling will flood the spindle head with coolant and void the warranty.

NOTE: When using small orifice tooling, increasing the value in parameter 237 will help purge left over coolant. For example, 1/4" twist drill - set parameter 237 to 5000 (units are in milliseconds). The minimum value is 2500.

- Use a pull stud with "45 Degree, P40T Type 1, inch threads" built to JMTBA standard "MAS 403-1982". If the machine is equipped with the optional BT tool changer, use BT tooling only. Contact the tool manufacturer for further information. Pull studs are available through HAAS. Refer to the Technical Reference section of the manual for the proper tool part numbers and identification.
- Coolant will be used more quickly when the TSC system is in use. Make sure to keep the coolant level up and to check the level more frequently (check after every eight hour shift). Premature wear of the pump can result from running with a low coolant level in the tank. The spindle will shut off automatically if the coolant level gets too low.

TSC PARAMETERS

The following parameters (and bits) apply only to the Through The Spindle Coolant system:

Parameter 237

TSC CLNT LINE PURGE

This can be increased by the machine user if desired to help purge coolant when using small orifice tooling. Use values from 2500 to 6000 milliseconds. Slower tool changes during TSC use will result from increasing the purge time.

WARNING!

These are factory preset parameters. Changing them may void the warranty.

Parameter 235	TSC PISTON SEAT
Parameter 236	TSC LOW PR FLT
Parameter 238	MAX TSC SPINDLE RPM
Parameter 209	COMMON SWITCH 2
THE REPORT OF THE	Ellis Deserve tes 000 is set to lid!

The bit, "TSC ENABLE" in Parameter 209, is set to "1".

Parameter 278 COMMON SWITCH 3 The bit, "TSC PRG ENBL" in Parameter 278, is set to "1".

TSC M Codes

The following M codes apply only to the Through The Spindle Coolant system:

M88 Thru Spindle Clnt ON

M88 performs the following operations:

- Stop the spindle
- Turn on the TSC pump
- Wait for coolant pressure
- Restart spindle

M89 Thru Spindle Clnt OFF

M89 performs the following operations:

- Stop the spindle
- Turn off the TSC pump
- Turn on purge
- Wait for [Parameter 237] for coolant to purge
- Turn off purge

VF Operator's Manual



M00 Stop Prog

M01 Optional Stop

When TSC is ON, M00 and M01 will shut it OFF, as in M89.

M06 Tool Change

When TSC is ON, M06 causes the following operations to be performed:

- Orient the spindle and move Z-axis to tool change position
- Turn OFF the TSC pump
- Turn on purge
- Wait for [Parameter 237] for coolant to purge
- Turn off purge
- Perform tool change

TSC then remains OFF until M88 is used.

M30 Prog End Rew

When TSC is ON, M30 will shut it OFF as in M89, then perform an M30 operation.

ALARM DESCRIPTION

151 Low Tool Coolant

This alarm will shut off the spindle, feed and pump all at once. It will turn on purge, wait for the time specified in parameter 237 for the coolant to purge, and then turn off the purge. If this alarm is received, check the coolant tank level, the filter and intake strainer for any clogging. If no problems are found with any of these, and none of the coolant lines are clogged or kinked, call you dealer.

198 Precharge Failure

This alarm is received if the precharge fails for greater than 0.1 seconds. It will shut off the feed, spindle and pump all at once. If received, check all air lines and the air supply pressure. **This alarm does not apply to 50 taper.**


3.11 8 "M" Functions (Optional)

This option adds 8 additional outputs for each 8M option. The machine can be fitted with two 8M options for a total of 16 additional outputs. These outputs can be used to activate probes, auxiliary pumps or clamping devices etc. The 8M relay board contains 8 relay outputs (M21- M28) and 2 terminal strips P4 and P5. Each terminal strip has 12 positions which are Normally Open, Normally Closed and Common.





A total of 4 banks of 8 relays are possible in the Haas system. Banks 0 and 1 are internal to the I/O PCB. Bank 1 includes the M21-25 relays at the top of the IOPCB. Bank 2 addresses the first 8M option PCB. Bank 3 addresses the second 8M option PCB.

Only one bank of outputs may be addressable with M-codes at a time. This is controlled by parameter 352 "Relay Bank Select". Relays in the non-activated banks are only accessible with macro variables. Parameter 352 is shipped set to "1" as standard. When either one or two 8M options are installed, the M-fin and probe cables are moved to the first 8M option PCB and parameter 352 is set to "2". With the 8M option, M-codes M21-28 correspond to relays labeled M21-28.

Bank addressing on the 8M PCB itself is done through selectable jumpers. Only one address should be selected at a time. The MCD jumper should be set to JP1 for bank 1 (first 8M option). The MCD jumper should be set to JP2 for bank 2 (second 8M option). The other positions are used by service only for installation in older controls. See the following figure.

M51-M58 will turn on the relays and M61-M68 will turn off the relays. M51 and M61 correspond to M21, etc. on the 8M relay board.

NOTE: Some or all of the M21-25 on the I/O PCB may be used for factory installed options. Inspect the relays for existing wires to determine which have been used. Contact the Haas factory for more details.

Terminals normally closed: 1, 4, 7, 10 Terminals normally open: 3, 6, 9, 12 Common Terminals: 2, 5, 8, 11

100 ·

NOTE: Bank 3 may be used for some Haas installed options and may not be available. Contact the Haas factory for more details.

SERIES Operator's Manual



- P4 Contains:
 - M21 M Function
 - M22 Probe Option
 - M23 Spare
 - M24 Spare

P5 Contains:

- M25 Spare
- M26 Spare
- M27 Spare
- M28 Spare
- P1 16-Pin Relay Drivers From IOPCB (M21-M28) (540) (INPUT)
- P3 Unused
- P2 12 VDC From Power Supply Board (860A)
- P6 16-Pin Relay Output to 2nd 8M Relay Baord



M-Code relay board.

NOTE: If the 8M option is installed, relays M21-28 become available on the secondary board. These relays will be controlled by ouputs M21-28.

3.12 Second Home (Optional)

An additional button on the side of the control commands the machine to rapid all axes to the coordinates specified in Work Offset G129. This is helpful for tool and fixture setups.



Fourth Axis Programming



Fourth axis programming exercise.

PROGRAM EXAMPLE

DESCRIPTION

% O1234 (Fourth axis program using a Haas Servo 5C) (Material is 1.0 Ø round stock x 3.0 L) (Set material in collet to protrude 2.25.) (Set fixture parallel with the table T-slots on the right side.) (X0 is the front of the material.) (Y0 is the centerline of the spindle and material.) (Z0 is the top of the part.) T1 M06 (Tool #1 is a .500 end mill to mill hex.) G00 G90 G54 X.250 Y-.500 A0 S4500 M03 G43 H01 Z.1 M08 M98 P1235 L6 G00 G90 Z.1 M09 T2 M06 (Tool #2 is a .375 Ø NC spot drill.) G00 G90 G54 X1.0 Y0 A0 S5000 M03 G43 H02 Z.1 M08 G82 Z-.1 F10. R.1 P300 X2.0 A90. X1.0 A180. X2.0

A270. X1.0

(Cont'd.)

G00 G80 Z.1 M09

SERIES Operator's Manual



T3 M06 G00 G90 G54 X1.0 Y0 A0 S5000 M03 G43 H03 Z.1 M08 G83 Z-1.125 F12. R.1 Q.25 X2.0 A90. X1.0 G00 G80 Z.1 M09 T4 M06 G00 G90 G54 X1.0 Y0 A0 S5000 M03 G43 H04 Z.1 M08 M98 P1236 G00 G90 Z.1 M09 G28 G91 Y0 Z0 M30 % % O1235 G01 Z-.125 F50. Y.5 F35. G00 Z.1 G91 Y-1.0 A60. G90 M99 %

(Tool #3 is a .1875 Ø stub twist drill.)

(Tool #4 is a .125 Ø end mill.)

(Subprogram to mill hex.)

The following subprogram can be written in absolute or incremental programming. Examine each program and determine which style would be faster and easier to understand and to program in the future.

INCREMENTAL:

ABSOLUTE:

%	%
O1236 (Subprogram to mill channels.)	O1236 (Subprogram to mill channels.)
G01 Z25 F15.	G91
X2.0 A90.	G01 Z35 F15.
G00 Z.1	X1.0 A90.
A180.	G00 Z.35
G01 Z25	A90.
X1.0 A90.	G01 Z35
G00 Z.1	X-1.0 A-90.
A180.	G00 Z.35
G01 Z25	A90.
X2.0 A270.	G01 Z35
G00 Z.1	X1.0 A90.
A360.	G00 Z.35
G01 Z25	A90.
X1.0 A270.	G01 Z35
G00 Z.1	X-1.0 A-90.
M99	G00 G90 Z.1
%	M99
	%



Formulas

TAPPING -

STANDARD thread formula:

Revolutions per minute (RPM) divided by threads per inch (TPI) = Feed rate in inches per minute **RPM/TPI = F**

METRIC thread formula:

Pitch (P) multiplied by .03937 = ____ multiplied by RPM = Feed rate in inches per minute (P x .03937) x RPM = F

SPEED AND FEEDS -

S.F.M. (Surface Feet per Minute):

.262 multiplied by the cutter diameter multiplied by the RPM = SFM

.262 x Cutter Diameter x RPM = SFM

R.P.M. (Revolutions Per Minute):

3.82 multiplied by the recommended SFM divided by the cutter diameter = RPM (3.82 x SFM) / Cutter Diameter = RPM

I.P.M. (Inch Per Minute):

Feed per tooth multiplied by the number of cutter teeth multiplied by the RPM = Feed rate in inches per minute.

(Feed/tooth x n) x RPM = IPM or F

CUBIC INCH PER MINUTE: MATERIAL REMOVAL RATE

Effective diameter of cut multiplied by the depth of cut multiplied by the inch per minute feed rate = cubic inch per minute.

(E Diameter x d) x IPM = CIPM

3.13 SUBROUTINES

One of the more important programming features of a CNC machine is subroutines. Subroutines allow the CNC programmer to define a series of commands which might be repeated several times in a program and, instead of repeating them many times, they can be "called." A subroutine call is done with M97 or M98 and a **Pnnnn**. The **P** code is the same as the **O** number of the subroutine to be called.

It is important to note that there is little difference between the main program and the subroutines. In the LIST PROG display, they all appear as numbered programs. When starting execution of a program, the LIST PROG display is used to select the **main** program and any subroutines used are called from within the main program.

Local subroutines can be used with M97. This can be even easier to use than M98 because the subroutine is part of a single main program, without the need to define a different **Onnnnn** program. With local subroutines, you can code an M30 for the end of your main program, followed by a line number and a subroutine that ends with an M99.

The subroutine call causes the blocks in the subroutine to be executed just as if they were included in the main program. In order to return control to the main program, subroutines must end with an M99.

Another very important feature of subroutines is that the M98 "call" block may also include an L or repeat count. If there is an L, the subroutine call is repeated that number of times before the main program continues with the next block.

The most common use of subroutines is in the definition of a series of holes which must first be center-drilled, then peck-drilled, tapped, and chamfered. If a subroutine is defined that consists only of the X-Y position of the holes, the main program can call that subroutine after defining a canned cycle to do each of the operations. Thus, the X-Y positions can be used several times and need not be repeated for each tool. An example follows:

O0100 G54 G00 G90 X0. Y0. ;	(MAIN PROGRAM FOR EXAMPLE OF SUBROUTINES);
T01 M06	(CENTER DRILL);
G81 R0.2 Z-0.1 F20. L0 S2000 M03 ;	(NO OPERATION HERE, JUST DEFINE CANNED CYCLE);
M98 P0200	(CENTER DRILL EACH HOLE);
T02 M06	(PECK DRILL);
G83 R0.2 Z-1. F10. L0 S1000 M03 ;	(NO OPERATION HERE, JUST DEFINE CANNED CYCLE);
M98 P0200	(PECK DRILL EACH HOLE);
T03 M06	(TAP IN FLOATING HOLDER OR HARD TAP);
G84 R0.2 Z-1. F10. L0 S200	(NO OPERATION HERE, JUST DEFINE CANNED CYCLE); (1/4-20);
M98 P0200	(TAP EACH HOLE);
T04 M06	(CHAMFER);
G81 R0.2 Z-0.1 F20. L0 S2000 M03 ;	(NO OPERATION HERE, JUST DEFINE CANNED CYCLE);
M98 P0200	(CHAMFER EACH HOLE);
G28 M30	(END OF MAIN PROGRAM);
O0200	(SUBROUTINE EXAMPLE LISTING ALL HOLE POSITIONS);





X0. Y0. ; X1. Y0. ; X2. Y0. ; X0. Y1. ; X1. Y1. ; X2. Y1. ; X0. Y2. ; X1. Y2. ; X2. Y2. ; M99	(END OF SUBROUTINE);
O0300	(EXAMPLE USING A LOCAL SUBROUTINE)
G54 G00 G90 X0. Y0.; G81 R0.2 Z-0.1 F20 L0 S2000 M03; M97 P0500 T02 M06 G83 R0.2 Z-1. F10. L0 S1000 M03; M97 P0500 G28 M30	(NO OPERATION HERE, JUST DEFINE CANNED CYCLE); (CENTER DRILL EACH HOLE); (PECK DRILL); (NO OPERATION HERE, JUST DEFINE CANNED CYCLE); (PECK DRILL EACH HOLE); (END OF MAIN PROGRAM);
N0500 X0. Y0,; X1. Y0.; X2. Y0. X0. Y1. X1. Y1. X2. Y1. X0. Y2. X1. Y2. X2. Y2. M99	(LOCAL SUBROUTINE EXAMPLE LISTING ALL HOLE POSITIONS); (END OF SUBROUTINE):
	(2.12 0) 002.0001.12),

SUBPROGRAMS AND CANNED CYCLES

After reviewing the canned cycle, we can get a good idea of the amount of lines of code required to produce the five holes. The best way to conserve on program space and programming time is to use a subprogram. We can do this by grouping the **X** and **Y** locations of the holes into a separate program and then calling up this program when we need to tell a canned cycle the X,Y coordinates.

Instead of writing the X,Y locations once for each tool, we can write the X,Y locations once for any number of tools.

The canned cycle program that we reviewed on the previous page could use some constructive rearranging.

% O1234 (Example program) T1 M06 G90 G54 G00 X.565 Y-1.875 S1275 M03 G43 H01 Z.1 M08 G82 Z-.175 P.03 R.1 F10. M98 P1000 G80 G00 Z1.0 M09 T2 M06 G00 G90 G54 X.565 Y-1.875 S2500 M03 G43 H02 Z.1 M08 G83 Z-.720 Q.175 R.1 F15. M98 P1000 G00 G80 Z1.0 M09 T3 M06 G00 G90 G54 X.565 Y-1.875 S900 M03 G43 H03 Z.2 M08 G84 Z-.600 R.2 F56.25 M98 P1000 G80 G00 Z1.0 M09 G28 G91 Y0 Z0 M30 %

% O1000 (X,Y LOC. SUB) X 1.115 Y-2.750 X 3.365 Y-2.875 X 4.188 Y-3.313 X 5.0 Y-4.0 M99 %

SUBPROGRAMS WITH MULTIPLE FIXTURES

So far we have learned that using subprograms with canned cycles can save programming time and help reduce coordinate input error. Let's take this one step further. There are six vises mounted on the table. Each of these vises will use a new X,Y zero. They will be called up in the program as G54 through G59. The machine will have to be told where each of the vises is located on the table. By using an edge finder or an indicator, the zero point on each part can be established. Use the part zero set key in the work coordinate offset page to record each X,Y location. Once the X,Y zero position for each vise is in the offset page, the programming can begin.

The figure shows what this setup would look like on the machine table.

For an example, each of these six parts will need to be drilled at the center, X and Y zero.





% O2000 T1 M06 G00 G90 G54 X0 Y0 S1500 M03 G43 H01 Z.1 M08 M98 P3000 G55 M98 P3000 G56 M98 P3000 G57 M98 P3000 G58 M98 P3000 G59 M98 P3000 G00 Z1.0 M09 G28 G91 Y0 Z0 M30 %

% O3000 X0 Y0 G83 Z-1.0 Q.2 R.1 F15. G00 G80 Z.2 M99 %

The following figure represents a multiple-fixture setup. Each vise will have an absolute zero once it is specified in the program. This is done by using G54 through G59 and G110 through G129, a total of 26 possible positions.



Multiple fixture setup.

SERIES Operator's Manual

LOOPING CANNED CYCLES

The following is an example of a program using a drilling canned cycle that is incrementally looped. Compare the grid plate drawing to the program.





Grid plate for multiple-fixture subprogram exercise.

PROGRAM EXAMPLE

DESCRIPTION

% O3400 (Drilling grid plate) T1 M06 G00 G90 G54 X1.0 Y-1.0 S2500 M03 G43 H01 Z.1 M08 G81 Z-1.5 F15. R.1 G91 X1.0 L9 G90 Y-2.0 (Or stay in G91 and repeat Y-1.0) G91 X-1.0 L9 G90 Y-3.0 G91 X1.0 L9 G90 Y-4.0 G91 X-1.0 L9 G90 Y-5.0 G91 X1.0 L9 G90 Y-6.0 G91 X-1.0 L9 G90 Y-7.0 G91 X1.0 L9 G90 Y-8.0 G91 X-1.0 L9 G90 Y-9.0 G91 X1.0 L9 G90 Y-10.0 G91 X-1.0 L9 G00 G90 G80 Z1.0 M09 G28 G91 Y0 Z0 M30 %





Modifying Canned Cycles

In this section we will cover canned cycles that have to be customized in order to make the programming of difficult parts easier. In result, making the machining process more efficient.

Using G98 and G99 to clear clamps:

For example, we have a square part being held to the table with one inch tall table clamps. We need to write a program to clear the table clamps.

PROGRAM EXAMPLE

DESCRIPTION

% O4500 T1 M06 G00 G90 G54 X1.0 Y-1.0 S3500 M03 G43 H01 Z1.125 M08 G81 G99 Z-1.500 R.05 F20. X2.0 G98 X6.0 G99 X8.0 X10.0 X12.0 G98 X16.0 G99 X18.0 G98 G00 G80 Z2.0 M09 G28 G91 Y0 Z0 M30 %

(Will return to starting point after executing cycle) (Will return to reference plane after executing cycle)

X,Y Plane Obstacle Avoidance In A Canned Cycle:

So far we have learned how G98 and G99 can be used to avoid an obstacle in the Z-axis. There is also a way to avoid an obstacle in the X,Y plane during a canned cycle by placing an L0 in a canned cycle line, we can tell the control to make an X,Y move without executing the Z-axis canned operation.

For example, we have a six inch square aluminum block, with a one inch by one inch deep flange on each side. The print calls for two holes centered on each side of the flange. We need to write a program to avoid each of the corners on the block.

SERIES Operator's Manual

PROGRAM EXAMPLE

DESCRIPTION

% O4600 (X0,Y0 is at the top left corner) (Z0 is at the top of the part) T1 M06 G00 G90 G54 X2.0 Y-.5 S3500 M03 G43 H01 Z-.9 M08 G81 Z-2.0 R-.9 F15. X4.0 X5.5 L0 Y-2.0 Y-4.0 Y-5.5 L0 X4.0 X2.0 X.5 L0 Y-4.0 Y-2.0 G00 G80 Z1.0 M09 G28 G91 Y0 Z0 M30

(angular corner avoidance)

SPECIAL CANNED CYCLES

%

In this section, we will cover the special canned cycles that the Haas control offers. These canned cycles are used in conjunction with other drilling, boring, and tapping cycles.

G70 = BOLT HOLE CIRCLE G71 = BOLT HOLE ARC G72 = BOLT HOLES ALONG AN ANGLE

The sample program below will show the format for using a G70 to drill a three inch diameter bolt hole pattern combined with a G81 drilling canned cycle.

% O5000 T1 M06 G00 G90 G54 X0 Y0 S1500 M03 G43 H01 Z.1 M08 G70 I1.5 J0 L8 G81 Z-1.0 R.1 F15. G00 G80 Z1.0 M09 G28 G91 Y0 Z0 M30 %

RULES FOR BOLT PATTERN CANNED CYCLES:

- 1. The tool must be placed at the center of the bolt pattern before the canned cycle execution. The center is usually X0, Y0.
- 2. The **J** code is the angular starting position and is always 0 to 360 degrees counterclockwise from the three o'clock position.

In the case of conflicting address codes, You can specify a drilling cycle prior to the block that invokes the special canned cycle. For instance:





Bolt Hole Pattern Canned Cycles

% 05000 T1 M06 G00 G90 G54 X0 Y0 S1500 M03 G43 H01 Z.1 M08 G83 R.1 Z-1.0 I.25 J.03 K.15 F15. L0 (L0 PREVENTS DRILLING AT CENTER) G70 I1.5 J0 L8 G00 G80 Z1. M09 G28 G91 Y0 Z0 M30 %

3.14 Tool Functions (TNN)

The **Tnn** code is used to select the next tool to be placed in the spindle from the tool changer. The **T** address does not start the tool change operation; it only selects which tool will be used next. M06 and M16 are used to start a tool change operation. The **Tnn** does not need to be in a block prior to the M06 or M16; it can be in the same block.

NOTE: There is no X or Y motion required prior to performing a tool change and it would waste time in most cases to return X or Y to the home position. However, if your work piece or fixture is quite large, you may need to position X or Y prior to a tool change in order to prevent a crash between the tools and your fixture.

You may command a tool change with the X, Y, and Z axes in any position, and the control will bring the Z axis up to the machine zero position prior to starting the tool change. The control will move the Z axis to a position above machine zero during a tool change but will never move below machine zero. At the end of a tool change, the Z axis will be at machine zero.

Tools are always loaded through the spindle and, in order to avoid crashes, should never be installed directly into the carousel.

The toolholders used are #40 taper, V flange, commonly called "CT 40." The tool changer is manufactured to hold either BT40 or CAT40 tools. They are NOT interchangeable. For the 50-taper spindle option, the toolholders used are CT #50 taper, V flange, commonly called "CT 50."

For machines equipped for CAT40 tools, use a 45-degree, P40T type 1, inch-threads pull stud built to JMTBA standard MAS 403-1982. This pull stud is characterized by a long shaft and a 45-degree shoulder under the head. Do not use the short shaft or pull studs with a sharp right angle (90-degree) head, as they will not work and will cause serious damage.

For machines equipped for BT40 tools, use only Haas pull studs (PN: 20-7165).





 NOTE:
 CT 40T Pullstud
 = One Identification Groove

 BT 40T Pullstud
 = Two Identification Grooves

 MIKRON 40T Pullstud
 = Three Identification Grooves

114 –



Toolholders and pull studs must be in good condition and tightened together with wrenches or they may stick in the spindle taper. Clean the tool tapers with a lightly oiled rag to leave a film to prevent rusting. Tools that make a loud bang when being released indicate a problem and should be checked before serious damage to the shuttle occurs. When the TOOL RELEASE button is pressed the tool should be pushed out of the spindle by a small amount (approximately 0.07 inch). This is an indication that the pull stud is correctly touching the release mechanism.

Low air pressure or insufficient volume will reduce the pressure applied to the tool unclamp piston and will slow down tool change time or will not release the tool.

CAUTION! Do not exceed the maximum specifications.

After **POWER UP/RESTART** and **ZERO RET**, the control will ensure that the tool changer is in a normal position. To load a new tool, select MDI mode, put the tool in the spindle with the **TOOL RELEASE** button and then push **ATC FWD** or **ATC REV**, and the machine will put the tool in the carousel. Use the CURNT COMDS display to see what tool is currently in the spindle.

NOTE: Tool changer goes to tool #1 first, then to the tool designated in Setting 81.

To manually select another tool, use **ATC FWD** or **ATC REV** while in MDI mode. To select a tool other than an adjacent one, enter the **T** number first. That is, enter T8 and press **ATC FWD** to place tool 8 in the spindle.

If the shuttle should become jammed, the control will automatically come to an alarm state. To correct this, push the **EMERGENCY STOP** button and remove the cause of the jam. Push the **RESET** key to clear any alarms. Push the **TOOL CHANGER RESTORE** button to reset the tool changer.

CAUTION! Never put your hands near the tool changer when powered unless the EMERGENCY STOP button is pressed first.

The tool changer is protected by a fuse. It might be blown by an overload or jam of the tool changer. Operation of the tool changer can also be interrupted by problems with the tool clamp/unclamp function and the spindle orientation mechanism.



3.15 Side-Mount Tool Changer



NOTE: On mills equipped with a side-mount tool changer, air pressure is checked prior to moving the carousel. Alarm 120, LOW AIR PRESSURE, is generated if such a problem exists.

CAUTION:	Keep clear of the tool changer during power up, power down, and	
	any tool changer operations.	

Maximum Tool Diameter	40-Taper VF 1-4 3"	40-Taper VF 5-11 3"	50-Taper VF 5 4"	50-Taper VF 6-11 4"
Maximum Tool Diameter	5"	6"	7"	10"
Maximum Tool Length from gauge line	13"	16"	16"	16"
Maximum Tool Weight	12 lb	12 lb	30 lb	30 lb
Tool Capacity	25 (41 opt VF 3/4)	25 (41 optional)	31 tools	31 tools
Number of Tool Pockets	24 (40 opt VF 3/4)	24 (40 optional)	30	30
	SHUTTLE TOO	DL CHANGER SI	PECIFICATIONS	
	20-Pocket	32-pocket		
Maximum Tool Weight	12 lb	12 lb		
Maximum Total Tool Weight	120 lb		200 lb	
CAUTION!	Extremely he Ensure there	avy tool weights s	hould be distributed	evenly.

SIDE-MOUNT TOOL CHANGER SPECIFICATIONS

N! • Extremely heavy tool weights should be distributed evenly.
• Ensure there is adequate clearance between tools in the tool changer before running an automatic operation. This distance is 3.6" for a 20-pocket and 3.4" for a 32-pocket tool changer.

Power Up Procedure

- 1. Press the green **POWER ON** button and wait for the control to complete the boot-up process.
- 2. Press the **POWER UP/RESTART** button and wait for the machine to perform a Zero Return.

Setting 81, TOOLAT POWERDOWN, will cause one of the following actions to occur during power-up:

- A. If Setting 81 is set to zero, the carousel will be rotated to pocket #1. No tool change will be performed.
- B. If Setting 81 contains the tool number of the tool currently in the spindle, the carousel will remain at the same pocket and no tool change will be performed.
- C. If Setting 81 contains the tool number of a tool not currently in the spindle, the carousel will be rotated to pocket #1 and then to the pocket containing the tool specified by Setting 81. A tool change will be performed to change the specified tool into the spindle.

Overview

NOTE: If alarms occur while using a Vertical Mill side-mount tool changer, the associated parameters should first be verified (and corrected if necessary), and then the tool change recovery procedure should be performed.

The side-mount tool changers allow the control to rotate the carousel to the next tool needed while the current tool is still in the spindle. When a tool change is commanded, the two tools are swapped by the tool arm. Thus, a tool will be taken from one pocket and returned to another. This means that pockets designated as normal size are not dedicated to any particular tool; during tool change operations a normal size tool can be taken from one pocket and put back into another. Tool pockets designated as large size are dedicated only to large tools; large tools will not migrate to an empty 'normal' pocket during a tool change.

Using 'O' for a Tool Designation

A **0** (number zero) can be inserted in the tool table in place of a tool number. If this is done the tool changer does not "see" this pocket and will never try to install or retrieve a tool from pockets with a "0" designation.

A **0** cannot be used to designate the tool inserted into the spindle. The spindle must always have a tool number designation.

To designate a pocket as an "always empty" pocket: Use the arrow keys to move to and highlight the pocket to be empty, press the **0** button on the numeric keypad and then press **WRITE/ENTER**.



TOOL LOADING

- **NOTE:** A normal size tool has a diameter of less than 3" for 40-taper machines, or less than 4" for 50-taper machines. Tools larger than these measurements are considered large size.
- 1. Ensure the tools you will be loading are of the correct pull stud type for your mill.
- 2. Press the **POWER UP/RESTART** button and wait for the machine to perform a Zero Return.
- 3. Enter Handle Jog mode.
- Press the OFSET button. From a fresh Power Up/Restart, press the END key, then the PAGE DOWN key once to reach the Tool Pocket Table display. From a normal operating state, press Page Up/Down until you reach the Tool Pocket Table.
- Clear any current Large tool designations. Use the cursor keys to scroll to any tool pocket that has an "L" next to it. Press SPACE, then WRITE/ENTER to clear the Large tool designations.
- 6. Press ORIGIN to reset the Tool Pocket Table to default values. This will place tool 1 in the spindle, tool 2 in pocket 1, tool 3 in pocket 2, etc. This is done to clear the previous Tool Pocket Table settings as well as renumber the Tool Pocket Table for the next program. Another way to reset the Tool Pocket Table is to enter 0 (zero) and press Origin, this will reset all the values to zero.

- 7. Determine if your next program will need any large tools. A large tool has a diameter of greater than 3" for 40-taper machines and greater than 4" for 50-taper machines. If you will not be using any large tools, proceed to Step 10. If you will be using large tools, proceed to the next step.
- 8. Organize your tools to match to your CNC program. Determine the numerical positions of any large tools and designate those pockets as Large in the Tool Pocket Table. To designate a tool pocket as Large, scroll to that pocket and press L, then **WRITE/ENTER**.

NOTE: You cannot have two different tool pockets holding the same tool number. Trying to enter a tool number already displayed in the Tool Pocket Table will result in an "Invalid Number" error.

NOTE: When setting up the tooling for your CNC program, large tools need to have the surrounding pockets empty to prevent a tool changer crash. However, large tools can share adjoining empty pockets. Placing large tools next to each other will help conserve space in the tool changer.

SERIES Operator's Manual



Large tool with surrounding pockets empty.

CAUTION:	A large tool cannot be placed in the tool changer if one or both of the surrounding pockets already contain tools. Proceeding with this
	action will cause the tool changer to crash.

- 9. When you have designated all necessary Large tool pockets, press the **ORIGIN** key to renumber the Tool Pocket Table. At this point, the machine is ready to accept tool 1 into the spindle.
- 10. Take tool 1 in your hand and insert the tool (pull stud first) into the spindle. Turn the tool so that the two cutouts in the tool line up with the tabs of the spindle. Push the tool upward while pressing the TOOL RELEASE button. When the tool is fitted into the spindle, release the TOOL RELEASE button. One TOOL RELEASE button is located on the right side of the head cover just above the spindle; a second one is located on the keypad.







- 11. Press PAGE UP, then HOME to go to the Offset Tool Length display.
- 12. Jog the Z axis to set the tool offset. Press the TOOL OFFSET MESUR (measure) button on the keypad. Press the NEXT TOOL button.
- 13. Repeat Steps 10 through 12 until you have loaded all your tools.

SERIES Operator's Manual

Tool Loading Flowchart





Moving Tools in the Carousel

Should you need to move tools around in the carousel, follow the steps below.

CAUTION: Plan out your reorganization of the tools in the carousel ahead of time. To reduce the potential for tool changer crashes, keep your tool movement to a minimum. If you have any large size tools currently in the tool changer, ensure that you only move them between tool pockets designated as large.

Creating Room for a Large Size Tool

The tool changer pictured has an assortment of normal size tools. For the purposes of this example, tool 12 will be moved to pocket 18 to create room for a large size tool to be placed in pocket 12.

- 1. Select MDI mode. Press the **OFSET** button. Press **PAGE UP/PAGE DOWN** (if necessary) until you reach the Tool Pocket Table display. Verify which tool number is in pocket 12.
- 2. Enter **Tnn** into the control (where **Tnn** is the tool number from step 1). Press **ATC FWD**. This will place the tool from pocket 12 into the spindle.
- 3. Enter P18 into the control, then press **ATC FWD**. This will place the tool currently in the spindle into pocket 18.



- 4. Scroll to pocket 12 in the Tool Pocket Table and press L, **WRITE/ENTER** to designate that pocket as Large.
- 5. Enter the tool number into SPNDL (spindle) on the Tool Pocket Table. Insert the tool into the spindle.

NOTE: You cannot have two different tool pockets holding the same tool number. Trying to enter a tool number already displayed in the Tool Pocket table will result in an "Invalid Number" error.

6. Enter P12 into the control and press **ATC FWD**. The tool will be placed into pocket 12.

VF Operator's Manual



Power Down Procedure

1. Assuming the machine has been zeroed since it was powered up, press the **POWER UP/RESTART** button and wait for the machine to perform a Zero Return.

Setting 81, TOOLAT POWERDOWN, will cause one of the following actions to occur during power down:

- A. If Setting 81 is set to zero, the carousel will remain at the same pocket. No tool change will be performed.
- B. If Setting 81 contains the number of the tool that is already in the spindle, the carousel will remain at the same pocket and no tool change will be performed.
- C. If Setting 81 contains the number of a tool that is **not** currently in the spindle, the carousel will be rotated to pocket #1, then to the pocket containing the tool specified by Setting 81. A tool change will be performed that places the specified tool in the spindle.
- D. If Setting 81 contains the number of a tool not listed in the Tool Pocket Table, the carousel will be rotated to pocket #1 and no tool change will be performed.
- 2. Press the red **POWER OFF** button.

Tool Changer Recovery

If a problem occurred during a tool change, a tool changer recovery needs to be performed. Enter the tool changer recovery mode by pressing **TOOL CHANGER RESTORE**. Once in tool changer recovery mode, the operator is given instructions and questions to perform a proper tool changer recovery. The entire tool changer recovery process must be completed before exiting. If an exit was done prematurely the tool changer recovery must be started from the beginning.

The flow chart for the tool changer restore function is at the end of this section.



SIDE MOUNT TOOL CHANGER RECOVERY



 $\begin{array}{l} \text{SIDEMOUNT MILL TOOL RECOVERY} \\ \text{SCREEN TEXT = UPPER CASE} \\ \text{ACTIONS - DECISIONS = LOWER CASE} \\ \text{S = SITUATION} \\ \text{M = NEXT MODE} \end{array}$

3.16 Spindle Speed Functions

Spindle Speed Commands

Spindle speed functions are controlled primarily by the **S** address code. The **S** address specifies RPM in integer values from 1 to maximum spindle speed (Parameter 131, **not to be changed by the user**).

Speeds from S1 to the Parameter 142 value (High/Low Gear Change; usually 1200) will automatically select low gear, and speeds above Parameter 142 will select high gear. Two **M** codes can be used to override the gear selection: M41 for low gear override and M42 for high gear override. Low gear operation above S1250 is not recommended. High gear operation below S100 may lack torque or speed accuracy. If there is no gear box in your machine, the gear box is disabled by parameters, it is always in high gear, and M41 and M42 commands are ignored.

Three **M** codes are used to start and stop the spindle. M03 starts the spindle clockwise, M04 starts the spindle counterclockwise, and M05 stops the spindle.

Note that only one **M** code is allowed in a block. This means that if you wish to override the gear with M41 or M42, you must put the **Snnnn** and M41 (or M42) in one block and the M03 (or M04) in the next block. The **Snnnn** should always be in the same block as the M41 or M42, as an unneeded double gear change might otherwise be performed.

3.17 TAPPING WITH THE VF-SERIES CNC MILL

Making tapped holes with the VF Series CNC Mill can be done with several devices. Threads may be generated with a tap held in a rigid toolholder (called rigid tapping), a floating tap holder, a reversing tapping head, or helical thread milling. Each method has distinct advantages.

Tapping is done using canned cycles. You must select the tapping rpm and, using the pitch (threads per inch), calculate the feedrate that is entered in the **F** command. The HELP/CALC page will compute these numbers for you.

RIGID **T**APPING

Note: This feature is optional on the Mini Mill

Rigid tapping eliminates the cost of special tap holders since taps can be held in drill collet holders. The spindle is accurately synchronized with the Z-axis feed, thereby producing threads as accurately as a lead screw tapper. Rigid tapping eliminates the pullout and distortion of the first thread that occurs on all spring compression/tension devices and tapping heads. You can also re-tap a hole without cross-threading, provided the tap and **Z** depths have not been changed. Rigid tapping is used with canned cycles G74 and G84. Example:

N100 G84 Z-1. R.3 F37.5 (for a 20-pitch thread at 750 rpm)

The mill can retract from a tap faster than it went in. The way to specify this is to use a J code in the line that commands the tap. J2 retracts twice as fast as the entry motion, J3 retracts three times as fast, and so on, up to J9. The J code is not modal, and must be specified in each block where the effect is wanted.

Rigid tapping will operate from 100 to 2000 RPM and up to 100 inches per minute feed. Bottom depth control is better at lower speeds. Thread pitch is limited, from 4 to 100 TPI.

NOTE: When using a G74 or G84, you do not ever need to use M03, M04, or M05. These canned cycles start and stop the spindle automatically. This applies to using normal or rigid tapping.





Using Floating Tap Holders

Floating tap holders are probably the most common method of tapping holes. The tap is held in a quick change holder that can float up and down slightly. This is done to allow the tap to follow the hole it is tapping and compensate for differences in the acceleration and deceleration of the spindle versus the feed of the Z axis.

If the holder is pulled out or pushed in to its mechanical limits while tapping, you can break the tap, damage the threaded part, or pull the tap completely out of the holder. Also, tapping of diameters less than 5/16 of an inch while below 1201 rpm (low gear shift point, parameter 142) should be done in high gear. Spindle reversal is quicker in high gear and will minimize tap pullout. This is done by putting an M42 code with the speed command, such as: M42 S900. Tapping is done with G74 and G84 cycles which automatically reverse the spindle at **Z** depth. The feedrate can be calculated by using the HELP display, paging down to the tapping calculator and inputting your speed and tap pitch into the control to obtain your feedrate, which is then input to the **F** command of the cycle. Example:

N100 G84 Z-1.0 R.3 F46.875 (for a 32-pitch tap at 1500 RPM)

Autoreversing Tapping Heads

Auto reversing tapping heads eliminates the need for the spindle to reverse at the bottom, and provides for high production rates. The reversing function of the tapping head requires an arm to prevent the body from rotating. This must be considered when changing tools so as not to interfere with operation. The tool block on the VF Series CNC Mill will accommodate the Tapmatic series of heads. Several sizes are available and should be chosen dependent on tap size. Choose the head specifically for NC use as they have a 1:1 feed rate. Manual types have a faster withdrawal rate that leads to clatter on the upstroke.

Use the G85 or G89 (dwells at bottom) cycle when using a tapping head. Example: N100 G98 G85 Z-1.0 R0.25 F46.875

THREAD MILLING

Thread milling is accomplished with helical milling. Use a standard G02 or G03 move to create the circular move in X-Y and then insert a Z move on the same block corresponding to the thread pitch. The feedrate is selected as in standard milling practice. This will generate one turn of the thread. The multiple teeth of the cutter will generate the rest. Internal holes smaller than 3/8 inch may not be possible or practical. It does allow for making thread diameter compensation and external threads. A typical line would be as follows:

N100 G02 I-1.0 Z-.05 F5. (generates a 1-inch radius for 20-pitch thread)

We will use the following example and go through the thread milling procedures step-by-step to get the desired result:

DATA:

- I.D. Thread milling a 1.5 x 8 TPI hole.
- Using .750 diameter x 1.0 thread hob.
- Take the hole diameter 1.500. Subtract cutter diameter .750 = .750 Then divide by 2 = .375.
- **STEP 1:** Within this space we need to turn on cutter compensation and ramp on to the circle to be machined.
- **STEP 2:** Perform complete circle while simultaneously moving in the Z-axis the amount of one full pitch of the thread. This is called **helical interpolation**.
- **STEP 3:** Ramp off the circle and turn off the cutter compensation.

NOTE: Always climb cut the cutter.

I.D. will be G03; **O.D**. will be G02. An **I.D**. right hand thread will move **up** in the Z-axis by the amount of one thread pitch. An **O.D**. right hand thread will move **down** in the Z-axis by the amount of one thread pitch.

PITCH = 1.0/Threads per inch

Example 1.0 divided by 8 TPI = .125

Cutter compensation cannot be turned off or on during an arc movement. A linear turn on and turn off movement must be made, either in the X- or Y-axis. This move will be the maximum compensation amount that can be adjusted.



Thread milling exercise

PROGRAM EXAMPLE

% O2300 (Thread milling 1.5 diameter x 8 TPI) (X0, Y0 is at the center of the hole) (Z0 is at the top of the part) (Using .5 thick material) G00 G90 G54 X0 Y0 S400 M03 G43 H01 Z.1 M08 Z-.6 N1 G01 G41 D01 X.175 F25. (Turn on Cutter Comp) N2 G03 X.375 R.100 F7. (Ramp on move) N3 G03 I-.375 Z-.475 (One full revolution with Z moving up. 125) N4 G03 X.175 R.100 (Ramp off move) N5 G01 G40 X0 Y0 (Cancel Cutter Comp) G00 Z1.0 M09 G28 G91 Y0 Z0 M30 %

DESCRIPTION

NOTE: Maximum cutter compensation adjustability is .175, which is more than enough for this application.

Start with zero in the diameter offset column and enter a negative number to increase the thread diameter.





O.D. THREAD MILLING -



O.D. thread milling exercise.

PROGRAM EXAMPLE

DESCRIPTION

(Thread milling a 2.0 diameter post x 16 TPI)

% O2400 (X0,Y0 is at the center of the post) (Z0 is at the top of the part) (Post height is 1.125 inch) G00 G90 G54 X0 Y2.0 S2000 M03 G43 H01 Z.1 M08 7-1.0 G41 D01 X-1.5 Y1.125 G01 X0. F15. G02 J-1.125 Z-1.0625 G01 X1.5 G00 G40 X0 Y2.0 Z1.0 M09 G28 G91 Y0 Z0 M30 %

(Turning on cutter compensation.) (Linear interpolation onto the post.) (360° helical circle; negative Z move.) (Linear interpolation off the post.) (Turning off cutter compensation.)

NOTE: A cutter compensation turn on move can consist of any X or Y move from any position just as long as the move is greater than the amount being compensated for. The same rule applies for turning off cutter compensation.

Operator's Manual



SINGLE-POINT THREAD MILLING

Using the following data, we will write a program for single-point thread milling procedures:

DATA:

- 2.500 Ø hole
- Diameter of cutter (Subtract .750): 1.75
- Radial value (Divide by 2) : .875
- Thread pitch: .0833 (12 TPI)
- Part thickness: 1.00

PROGRAM EXAMPLE

DESCRIPTION

%		
O1000		
(X0,Y0 is at	the center of the hole)	
(Z0 is at the	e top of the part)	
T1 M06		(Tool #1 is a .750 diameter single-point thread tool)
G00	G90 G54 X0 Y0 S2500	M03
G43	H01 Z.1 M08	
G01	Z-1.083 F35.	
G41	X.275 DI	(Radial value)
G3	X.875 I.3 F15.	
G91	G3 I875 Z.0833 L14	(Multiply .0833 pitch x 14 passes = 1.1662 = total in Z-axis)
G90	G3 X.275 I300	
G00	G90 Z1.0 M09	
G1	G40 X0 Y0	
G28	G91 Y0 Z0	
M30		
%		





3.18 WARMUP COMPENSATION

When the machine is powered on, if Setting 109 and at least one of Settings 110, 111 or 112 are set to a nonzero value, the following warning will be displayed:

CAUTION! Warm-up Compensation is specified! Do you wish to activate Warm-up Compensation (Y/N)?

If the operator responds "Y," the control immediately applies the total compensation (Setting 110,111 and/or 112), and the compensation begins to decrease as the time elapses. For instance, after 50% of the time in Setting 109 has elapsed, the compensation distance for the X axis, in Setting 110, will be 50%.

As with other settings, the Warm-up Compensation values can be changed at any time. Updating the Warm-up Compensation Time may activate compensation, but changes to the X, Y or Z distance settings will not activate compensation. To "restart" the time period, it is necessary to power the machine off and on, and then answer "yes" to the compensation query at start-up.

WARNING!

Changing settings 110, 111 or 112 while compensation is in progress can cause a sudden movement of up to 0.0044 inch.

The amount of remaining warm-up time is displayed on the bottom right hand corner of the Diagnostics Inputs 2 screen using the standard hh:mm:ss format.

3.19 How the Control Moves the Machine

Acceleration and deceleration is what the machine does when it is changing speed. Acceleration is what the machine does when the speed is increasing and deceleration is what the machine does when it is slowing down. The machine cannot change speed instantly so that a change of speed occurs over some amount of time and a distance.

Changes of speed affect how the control moves for both rapid motion and feed motion. Rapid motion occurs independently for each axis in motion and uses acceleration set for each axis. Feed motion coordinates one or more axes to accelerate in unison, move in unison, and decelerate in unison. This type of feed motion is called acceleration before interpolation and uses a fixed acceleration rate for all axes.

RAPID MOTION

Rapid motion uses constant acceleration and deceleration, with maximum acceleration and maximum speed set as parameters per axis. End-point arrival in rapid motion occurs with S-curve velocity to prevent shock vibration to the machine. A rapid motion followed by another rapid motion is blended with a rounded corner, controlled by a parameter called "In Position Limit." It is usually about 0.06 inch. A rapid motion followed by a feed motion or a rapid motion in "Exact Stop" mode will always decelerate to an exact stop before the next motion.

S-curve velocity control refers to the rate of change of acceleration or deceleration. Without S-curve, there may be abrupt changes in deceleration, resulting in machine vibration. With S-curve at the end of a rapid move, there are only gradual changes to deceleration and thus machine vibration is reduced.

130 ·



FEED MOTION

A feed motion coordinates or "interpolates" the motion of multiple axes. Feed motions always use constant acceleration before interpolation. With the Haas control, up to five axes can be in motion in a feed. These are X, Y, Z, A and B. Maximum feedrate is 500 inches per minute for the linear (XYZ) axes and 300 degrees per minute for the rotary (AB) axes.

The blending of axis motion is controlled by Setting 85 (Max Corner Rounding) and the G187 command. Setting 85 and G187 provide for a continuously adjustable range of corner rounding between an exact stop and inexact stop. The value of the setting is the maximum deviation allowed from the exact programmed path.

A linear move (G01) started at an exact stop and ending at an exact stop will have zero positioning error. That is, it will follow exactly that programmed path. It is only at the start or end at speed that blending or corner rounding can occur. This blending action should not be confused with overshoot. Overshoot is where a control would go past a corner and then reverse back onto the required path. The Haas control does not overshoot under any circumstances.

Circular moves (G02 or G03) are not treated any differently than a linear feed motion. In a circular motion, if a feed starts at an exact stop and ends at an exact stop, there is no positional error introduced no matter what the feedrate. Feed in a circular motion is limited to 300 inches per minute. Corner rounding can still occur when a circular motion is blended with a linear or a circular motion, but is also controlled by Setting 85 and G187.

Feed Path Look-Ahead

Block look-ahead is something that is needed when the distance which the control requires to get up to speed is more than half the length of the programmed linear strokes. Without look-ahead, the control will simply overlap the deceleration of one stroke with the acceleration of the next stroke. This would limit the speed of the motion based on the length of those strokes. The Haas control has block look-ahead standard, but without the High-Speed Machining option it is limited. With look-ahead, blending of one stroke to another can occur at full speed, but the angle of blending is small without the High-Speed Machining option.



3.20 Cutter Compensation

Cutter compensation is a method of shifting the tool path so that the actual finished cut is moved to either the left or right of the programmed path. Normally cutter compensation is programmed to shift by exactly the radius of the tool so that the finished cut matches the programmed path. The Offset display is used to enter the amount for the tool to be shifted. The offset can be entered as either diameter or radius for both the geometry and wear values. The effective value is the sum of the geometry and wear values. Setting 40 is used to select either diameter or radius. If diameter is specified, the shift amount is half of the value entered. Cutter radius compensation is only available in the X and Y axes (G17). For 3D machining, cutter radius compensation is available in the X and Y axes (G141).

General Description of Cutter Compensation

G41 will select cutter compensation left; that is, the tool is moved to the left of the programmed path to compensate for the size of the tool. G42 will select cutter compensation right, which will move the tool to the right of the programmed path to compensate for the size of the tool. A **Dnnn** must also be programmed to select the correct tool size from compensation memory. If compensation memory contains a negative value for cutter size, cutter compensation will operate as though the opposite G codewas specified, for example a negative value entered for a G41 will behave as if a positve value was entered for G42. Cutter path compensation in this machine applies only to motion in the **X** and **Y** axes.

The code G40 will cancel cutter compensation and is the default condition when a machine is powered on. When canceled, the programmed path is the same as the center of the cutter path. You may not end a program (M30, M00, M01, or M02) with cutter compensation active.

If cutter radius compensation is selected (G41 or G42), you may only use the X-Y plane for circular motions (G17). Cutter radius compensation is only available in the **X** and **Y** axes.

The control operates on one motion block at a time. However, it will look ahead to check the next two blocks containing **X** or **Y** motions. The interference checks are performed on these three motions.

Setting 58 controls how this part of cutter compensation works. It will be set to Fanuc or Yasnac.

When Setting 58 is set to Yasnac, the control must be able to position the tool edge along all of the programmed cuts without overcutting the next two motions. All outside angles are joined by a circular motion.

When Setting 58 is set to Fanuc, the control does not require that the tool cutting edge be placed along all programmed cuts. Overcutting, however, is still prevented, and if overcutting cannot be prevented, an alarm will occur. Outside angles less than or equal to 270 degrees are joined by a square corner and outside angles of more than 270 degrees are joined by an extra linear motion.

The following four diagrams show how cutter compensation works for the two possible values of Setting 58. Note that a small cut of less than tool radius and at a right angle to the previous motion will only work with the Fanuc setting.

VF Operator's Manual













ENTRY AND EXIT FROM CUTTER COMPENSATION

When entering and exiting cutter compensation or when changing from left side to right side compensation, there are special considerations to be aware of. Cutting should not be performed during any of these three moves. In a block that turns on cutter compensation, the starting position of the move is the same as the programmed position, but the ending position will be offset by the cutter compensation size. In a block that turns off cutter compensation, the starting point is offset and the ending point is not offset. Similarly, when a block changes from left to right compensation, the starting point is shifted in one direction and the ending point is shifted in the other direction. The result of all this is that the tool is moved through a path that may not be the same as the intended path or direction.

If cutter compensation is turned on or off in a block without any X-Y move, there is no change made to cutter compensation until the next **X** or **Y** move is encountered. To enter cutter compensation, a nonzero **D** code must be specified and either G41 or G42 specified. To exit from cutter compensation, you may specify either D0 or G40, or both.

You should always turn off cutter compensation in a move which clears the tool away from the part being cut. If a program is terminated with cutter compensation still active, an alarm is generated. In addition, you cannot turn cutter compensation on or off during a circular move (G02 or G03); otherwise an alarm will be generated.

An offset selection of D0 will use zero as the offset size and have the effect of turning off cutter compensation. If a new value from offset memory is selected while cutter compensation is active, the starting point of a move will reflect the old value and the ending point will reflect the new value. This will have the effect of shifting the motion to something other than what was intended by the programmer. You cannot change the offset code or side during a circular motion block.

When turning on cutter compensation in a move that is followed by a second move at an angle of less than 90 degrees, there are two ways of computing the first motion: cutter compensation type A and type B (Setting 43). Type A is the default in Setting 43 and is what is normally needed; the tool moves directly to the programmed start point for the second cut. Type B is used when clearance around a fixture of clamp is needed, or in rare cases when part geometry demands it. The diagrams on the following pages illustrate the differences between type A and type B for both Fanus and Yasnac settings (Setting 58).

Feed Adjustments in Cutter Compensation

When using cutter compensation in circular moves, there is the possibility of speed adjustments to what has been programmed. If the intended finish cut is on the outside of a circular motion, the tool should be slowed down to ensure that the surface feed does not exceed what was intended by the programmer. There are problems, however, when the speed is slowed by too much. For this reason, Setting 44 is used to limit the amount by which the feed is adjusted in this case. It can be set between 1% and 100%. If set to 100%, there will be no speed changes. If set to 1%, the speed can be slowed to 1% of the programmed feed.

When the cut is on the inside of a circular motion, there is no speed-up adjustment made to the feedrate.

134

Cutter Compensation Entry (Yasnac)



Cutter Compensation Entry (Fanuc style)

TYPE A

TYPE B


CIRCULAR INTERPOLATION AND CUTTER COMPENSATION

In this section, we will cover the usage of G02 (Circular Interpolation Clockwise) and G03 (Circular Interpolation Counterclockwise) and Cutter Compensation (G41: Cutter Compensation Left, G42: Cutter Compensation Right).

Using G02 and G03, we can program the machine to cut circular moves and radii. Generally, when programming a profile or a contour, the easiest way to describe a radius between two points is with an **R** and a value. For complete circular moves (360°), an **I** or a **J** with a value must be specified. The circle section illustration below will describe the different sections of a circle.

By using cutter compensation in this section we, the programmers, will be able to shift a cutter by the amount of the cutter radius and be able to program a profile or a contour to the exact print dimensions. By shifting the cutter radius, the programming time and the likelihood of calculation error is reduced.

Before we get into circular interpolation and how it is used, below are a few rules about cutter compensation that have to be closely followed in order to perform successful machining operations. Always refer to these rules when programming!

- 1. Cutter compensation must be turned ON during a G00 or G01 X,Y move that is equal to or greater than the cutter radius, or the amount being compensated for.
- 2. When an operation using cutter compensation is done, the cutter compensation will need to be turned OFF, using the same rules as the turn ON process, i.e., what is put in must be taken out.
- 3. In most machines, during cutter compensation, a linear X,Y move that is smaller than the cutter radius may not work. (Setting 58 set to Fanuc for positive results.)
- 4. Cutter compensation cannot be turned ON or OFF in a G02 or G03 arc movement.



-1.11.1.1.5-



The following illustration shows how the tool path is calculated for the cutter compensation.



Programming exercise showing tool path.

The following program uses no cutter compensation. Tool path is programmed to centerline of the cutter. This is also the way the control calculates for cutter compensation.

% O6100 T1 M06 G00 G90 G54 X-.125 Y-.2 S5000 M03 G43 H01 Z.1 M08 G01 Z-1.0 F50. Y4.125 F25. G02 X.250 Y4.375 R.375 G01 X1.6562 G02 X2.0 Y4.0313 R.3437 G01 Y3.125 G03 X2.375 Y2.750 R.375 G01 X3.5 G02 X4.0 Y2.25 R.5 G01 Y.4375 G02 X3.4375 Y-.125 R.5625 G01 X-.2 G00 Z1.0 M09 G28 G91 Y0 Z0 M30 %





3.21 QUICK CODE

INTRODUCTION

This programming option can be activated by contacting your local HAAS dealer.

Quick Code is an innovative new way to program CNC machines. It combines the simplicity and flexibility of G code programming with English descriptive sentences to enable even beginning programmers to construct most 2 dimensional parts. Experienced programmers will also love the speed they can now enter programs manually. This is possible because with one menu selection you can replace a large number of individual keystrokes, with just a few. And what if you don't like the way Quick Code is programmed? Simple! You can change it to suit your needs or programming tastes. Make it as complex or as simple as you like.

Background

When NC machines were first introduced they had very limited or no memory at all. They were often run from tapes and instructions needed to be as concise as possible. In order to accomplish this a sort of encryptive language evolved which we called G code programming. A command to "TURN OFF COOLANT" which requires 16 letters and spaces is reduced to "M09" which takes only 3 characters. This made tape lengths and memory requirements manageable to say the least. As it evolved, hundreds of instructions and canned cycles were encrypted into G and M code programming. For an experienced programmer, the G codes are actually very easy to use but the learning process requires constant referring back to the manual to figure out which code to use to accomplish the task. And even the most experienced programmers would have to admit that every once in a while they forget to put the right "I,K,Q or P's" into say, a G83 drilling cycle. Quick Code eliminates this tedium. Simply handle cursor over to the drill cycle you want and press the write button and all the code you need to drill the hole is inserted with default values for all necessary "I,K,Q,P's". And you can edit those values to suit your individual needs.

How It Works

Quick Code reverses the G code encryption confusion. On the right side of the screen you have English commands that describe the operation to perform. By selecting the operation and with one button push, the code is inserted in your program on the left side of the screen. A program is constructed by selecting English commands that are than changed over to machine language or G codes. In doing this you will learn quickly the G code format without studying any manual. Another feature is the ability to cursor through a program and Quick Code will tell you what all the G and M codes mean, shown at the bottom of the screen, a great help in learning the code.

An Open System

Quick Code is adaptable to the way you program. Everybody programs a little differently and have special preferences, such as, do you put the "T" command on the same line as the tool change command or before? With Quick Code you can edit the program so that any English command you desire can be matched with any G code to be inserted. Because of this open format we are letting you define innovative new ways to program complex parts using Quick Code.



What it is Not

Quick Code is not a CAD/CAM package for generating complex moves on 3 dimensional parts. With most CAM packages you have to draw a drawing much like you would in AUTO CAD and then indicate the moves around the drawing and finally generate the code through the post processor. Not a simple task. Nor is it a conversational program with icons where you are asked to fill in the blanks. The difference with these packages is that they require training and much like learning a second language you have to have the time and determination to learn them. They have a tremendous amount of power but you don't always need it. Quick Code is a bridge between high end CAD/CAM and slow and cumbersome G code programming. It is our expectation that it can be used by anyone with very minimal training. For most simple parts we believe that Quick Code is an ideal choice.

Conversational Quick code

Conversational Quick Code makes programming with Quick Code even easier. This feature can be used to "prompt" the operator for the information necessary to create a program. Refer to the "Conversational Quick Code" section for a description of how to use this feature.

QUICK CODE TERMINOLOGY

Before describing the Quick Code environment you need to know the terms listed below. Following this brief list is an illustration of the Quick Code display and how the terms are related to the display.

EDIT WINDOW	Portion of the display that shows the currently edited program.
GROUP WINDOW	Portion of the display which presents a list of groups and items.
GROUP	A list of items that usually have something in common so that they can be grouped together.
ITEM	A line of text representing code that can be added to the edit window when it is selected.
HELP WINDOW	Portion of the display which presents user created help, address code help, and warning messages.







The Quick Code display.

USAGE AND **F**EATURES

ACCESSING QUICK CODE

Before Quick Code can be used, the bit labeled ENA QUIKCODE in parameter 57 must be set to 1. When this bit is set to 0, you will not be able to access the Quick Code screen. Enter Quick Code by selecting edit mode and then pressing the PRGRM/CONVRS key twice. The first press of the PRGRM/CONVRS key enters the standard editor, whereas the second press of this key will enter the 80 column format of the Quick Code screen. Each additional press of this key will switch between the Advanced editor, the standard editor, and Quick Code modes.

THE EDIT WINDOW

The Quick Code edit window is exactly the same as the standard editor on the HAAS control. Each time that you select a group item, as described below, the edit window will be updated to show you what code has been added to the currently edited program. You have access to all of the edit functions with the exception of the jog handle and the block copy function keys. In the standard editor, you can use the jog handle to traverse program text quickly. While in Quick Code, the jog handle is reserved to maneuver through the group list. You can still cursor through the program text by using the cursor keys provided on the center of the keypad. You are also restricted from using the block copy keys while in Quick Code. For this, you can always switch back to standard edit mode by pressing the PROGRM/CONVRS key. At this point you have access to the jog handle, for long comments, and the block copy functions. Quick Code is not available while in BACKGROUND EDIT MODE.



THE GROUP WINDOW

The group window displays a list of groups that are defined in the Quick Code source file. The groups can be moved through for selection by turning the jog handle in the plus (clockwise) direction. For each jog handle click in the plus direction, the group window cursor will advance to the next group. In this manner you can move through every group in the list. When the last group is highlighted, the next plus click will move the cursor to the first group in the list. To view and cursor through items within a group, turn the jog handle in the minus, counter clockwise, direction. As long as you turn the jog handle in the minus direction the cursor will advance through, display and highlight items in the current group. By turning the jog handle one click clockwise, the group item list will be closed and additional plus clicks will continue to traverse the group list.

THE HELP WINDOW

The help window is just below the group window. It is used to display Quick Code source file help, address code help, and warning messages to the user.

The Quick Code source file can contain comments that will not be placed into the edit window. These comments will be displayed on the first five lines of the help window. These comments are typically used for explaining item code and usage.

As the user cursors through a program, each address code that is highlighted will be interpreted and a short description of its usage is displayed below the edit window. This address code help is as accurate as possible. Since the program is not being interpreted sequentially as it is when a program is run, full interpretation cannot take place. When the context of an address code cannot be fully determined, the most likely usage is displayed.

Sometimes during editing we can determine if a run time error will occur without actually running the program. For instance we can tell if multiple codes from one G code group are on a line. In this case Quick Code will display a highlighted warning message to the user indicating that there is a problem. This is found below the help window.

SPECIAL KEYS

Quick Code makes use of the jog handle to select from the group list and group items. This is described in the group window section above. Quick Code action takes place when the WRITE key is pressed. If there is text on the input line, normal text insertion takes place when the WRITE key is pressed. When the input line is blank, pressing the WRITE key will cause Quick Code to take the following action:

-If the currently highlighted Quick Code item is designed as a text help item only, the edit window is not modified.

-If numeric program code is found associated with the highlighted Quick Code item, the edit window cursor is moved to the end of the current edit block and the associated code is inserted after that block. The edit cursor is left at the end of the last Quick Code block that was inserted.





CONVERSATIONAL QUICK CODE

Quick Code is used to "prompt" the operator for the information necessary to create a program. The "prompting comments" are created by placing a '?' as the first character of a (?comment) in the Quick Code source file (O9999). A comment is any text, up to 34 characters, that is contained in parentheses. When a program is being written using Quick Code, the prompting comments will appear on the screen, requiring a response from the operator. The numeric value entered by the operator will be assigned to the G-code item that immediately precedes the prompting comment in the source file. The Quick Code source file program is O9999.

For example, defining an X axis feed move, the following line of code would be in the source file:

G01 X2. (?WHAT IS THE X LOCATION) F15. (?WHAT IS THE FEEDRATE)

Will produce the following prompt when creating a new program, under a another program number (O1234) using Quick Code. And the default X location value displayed below with the prompt, as shown:

WHAT IS THE X LOCATIONX2.and you ENTER a new X location value of 2.25X2.25and then the next command prompt comes up.

With the default feed rate value displayed below the prompt, as shown:

WHAT IS THE FEED RATE

F15.

and you decide to keep this default feedrate value.

The operator must then enter a numeric value and press the WRITE key to change the default feed rate, or simply press the WRITE key to accept the default feed rate. The control will wait for an operator response before entering the block to the edit window. Unacceptable responses, such as those containing too many digits or an unnecessary decimal, will cause the control to flash an error message and wait for another response.

Once the operator has input a value for all of the 'variable' G-code items in a block of code, the entire (revised) block is displayed on the input line, as shown:

CORRECT (Y/N)? G01 X2.5 F15. ;

If the block of code is too long to fit on the screen, the operator can scroll to view the entire line using the right or left arrow keys, the HOME key, or the END key. The operator then must enter 'Y' to accept the block, or 'N' to cancel it. If it's accepted, the block is written to the edit file, and the Quick Code processing resumes with the next block (if there is one). If it is not accepted, the prompting process is repeated for the same block.

Pressing the UNDO key while in Quick Code, will exit the current block at any time and remain where your at in the program.

Pressing RESET will exit Quick Code and send the cursor back to the beginning.



A SAMPLE QUICK CODE SESSION

The following illustrates how Quick Code can be used to build a program. A program will be built to spot, drill, and tap 5 holes on a circular bolt hole pattern. We will assume that tool 1 is a spot drill, tool 2 is a drill for a 10-32 tap, and tool 3 is the tap. Before you proceed, make sure that Quick Code is enabled in parameter 57. ENA QUIKCODE should be set to 1. You will also need the Quick Code source program O9999 in the control.

The jog handle is an integral part of using Quick Code and is used quite often. For brevity we use JHCW to mean jog handle clockwise and JHCCW to mean jog handle counter clockwise. For instance, seeing JHCW means that you should turn the jog handle in a clockwise direction.

CREATE A PROGRAM

Quick Code will not generate the new program number for you. So the first thing you must do is to create or select a program. To create a program do the following.

- 1. Press LIST PROG.
- 2. Type O0005 (or any other convenient program number)
- 3. Press WRITE.

This creates a program in the usual manner. Proceed to edit the program by pressing EDIT. The control will switch to the PROGRAM display and you will see the program number and semicolon in the top left of the screen. Now press the PRGRM/CONVRS key twice to enter Quick Code or in the advanced edit menus under the HELP menu is a sub menu selection for Quick Code.

The following screen is presented.

<u>000005</u>	QUICKCODE START UP COMMANDS 1. MACHINE MOVES 2. CUTTER COMP. MOVES 3. DRILL /TAP/BORE CYCLES 4. DRILL /TAP/BORE LOCATIONS 5. CIRCULAR POCKET MILLING 6. CUSTOM SETTINGS 7. MISC COMMANDS ENDING COMMANDS
	Turn handle CCW for a SUB-MENU to start Entering a tool sequence.
	Turn handle CW to go back to the MAIN MENU and then CCW again to start the SUB-MENU selection.
-	PROGRAM NUMBER

Empty Program.



SELECT THE START UP COMMANDS

- 1. JHCW until the group titled **START UP COMMANDS** in the group window is highlighted.
- 2. JHCCW one click. The items belonging to **START UP COMMANDS** will appear and the item, **Program Name** is the one highlighted.
- 3. Press the WRITE key. This will enter in a (T), for you to cursor arrow left twice onto the T inbetween the parenthesis, then type in a program name and press ALTER.

The following figure shows what the screen should look like. Note that for the code that was added, you have text information displayed in the help window just below the group window. When the Quick Code source file is constructed properly, you will see examples of the program code, or instructions, for that command in this HELP window. This can be helpful in determining which item in a group you want.

	000005 ; PROGRAM NAME) ;		OUICKCODE START UP COMMANDS Program Name Set Machine Defaults Sequence Comment Call Tool Tool Start Up Commands DoneChoose an Operation 1. MACHINE MOVES 2. CUTTER COMP. MOVES 3. DRILL /TAP/BORE CYCLES EXAMPLE: [TEXT] After pressing ENTER for a program name Cursor ARROW LEFT twice onto the letter T between the parenthesis! Type in program text, press ALTER.
--	-----------------------------	--	---

Start a program using Quick Code.

- CALL TOOL 1

- 1. While on the START UP COMMANDS menu JHCCW and highlight the group item titled **Call Tool**.
- 2. Press the WRITE key to have the control query you for a tool number in your program, and the control will be flashing with a 1 in the lower left corner as the default value. Press WRITE to accept the number 1.

Press WRITE or Y to except the block listed in the lower left corner. Or N for no, to start the questioning again.

- 3. JHCCW and highlight the group item titled **Tool Start Up Commands**.
- 4. Press the WRITE key to have the control query you for the commands to define the start up of tool 1, and enter into your program.



QUICK CODE

Note that the cursor will move to the end of the block, when you start selecting Quick Code menu items for your program. This is where the next block of code will be entered in after.

QUICKCODE (EDIT)	O00005 N00000	
O00005; (PROGRAM NAME); T1 M06 (T); G90 G54 G00 X0 Y0; S750 M03; G43 H01 Z1. M08;		OUICKCODE START UP COMMANDS Program Name Set Machine Defaults Sequence Comment Call Tool Tool Start Up Commands DoneChoose an Operation 1. MACHINE MOVES 2. CUTTER COMP. MOVES 3. DRILL /TAP/BORE CYCLES EXAMPLE: G90 G54 G00 X0. Y0. S750 M03

Programmed with the Start Up Command selections entered in with Quick Code for tool 1.

Remember that after pressing WRITE you can always edit the program to make minor adjustments to code that Quick Code inserts into your program. You do not have to leave the Quick Code display to do this. But you must remember to reposition the cursor back to the block where you want to add the next item. Quick Code will automatically seek the end of the current block that the cursor is on, so there is no need to cursor to the end of the block.

We will assume that the material is aluminum and that the work coordinate zero for G54 is at the center of the bolt hole pattern. The Quick Code source file (O9999) was created with a common program format and menu selections. You could have a different Quick Code source file (O9998 or O9997) for different menu selections and formats. By changing parameter 228 (to 9998 or 9997) you can quickly change the file that Quick Code works with if you had created one.

- INVOKE THE SPOT DRILLING CANNED CYCLE G82

- 1. JHCW and highlight the group titled **5. DRILL/TAP/BORE CYCLES.**
- 2. JHCCW two clicks. Drill with Dwell G82 will be highlighted.
- 3. Press the WRITE key to have the control query you, and answer the questions, to set up drilling with G82.

Note that Quick Code defined a block of code to execute a spot drill cycle at that present location. You can add more X and Y drill cycle locations if needed by selecting **6. DRILL/TAP/BORE LOCATIONS**.

Note: We do not want to drill a hole at X0 Y0, which is the center of the bolt hole circle, so manually edit in an L0 on the end of the G82 command line. This will ignore the G82 canned cycle until the next location.





Your program will look like this.

ENTER drill locations with menu #6.	O00005; (PROGRAM NAME); T1 M06 (T); G90 G54 G00 X0 Y0; S750 M03; G43 H01 Z1. M08; G82 G99 Z-0.109 P0.2 R0.1 F5. <mark>;</mark>	QUICKCODE 3. DRILL/TAP/BORE CYCLES Drill G81 Drill with Dwell G82 Deep Hole Peck Drill G73 H.S.P.D. W/Return R plane G73 Bore IN Bore OUT G85 Bore IN Rapid OUT G86 Bore IN Shift Rapid OUT G76 Right Hand Tapping G84 G80 CANCEL Canned Cycle EXAMPLE: G82 G99 Z15 P2 R.1 F5. G98 Initial point return G99 Rapid plane return P5 = 1/2 Second dwell at Z depth.
		ENTER drill locations with menu #6.

Program with spot drilling invoked.

- EXECUTE A CIRCULAR BOLT HOLE PATTERN

- 1.) JHCW and highlight the group titled 6. DRILL/TAP/BORE LOCATIONS.
- 2.) JHCCW and highlight the group titled **Bolt Hole Circle Locations**
- 3.) Press the WRITE key to have the control query you for the code on positioning around a bolt hole circle.
- 4.) Enter in the numbers to answer all the questions in the lower left corner of the control screen, to define all the commands necessary to position around a G70 Bolt Hole Circle to drill with a G82 canned cycle.

Here Quick Code will question you for, a G70 command to execute a bolt hole circle pattern. The control will first query you for an X Y center location of the bolt hole pattern.

The next question will be for the radius of the bolt hole circle. The value 1.5 will be flashing in the lower left corner of the screen as the default value for the bolt hole circle radius. If the radius of the bolt circle is different, then enter in the new radius value.

The next questions will be for the number of holes. The value 6 will be flashing in the lower left corner of the screen as the default meaning that 6 holes on a circle will be drilled. We want 5 holes to be drilled. So here you will enter the number 5 to change the pattern so that L5 will be on the G70 line.

Your program will look like this.

Program with a bolt hole circle added.

By now you should have a good idea of how your program changes, after selecting a group item with the handwheel and pressing WRITE. To save space we will not show you each display as a selection is made. Instead we will list the remaining actions needed to finish drilling and tapping the 5 holes. The remaining selections are very similar to what we have already done.

- CALL TOOL 2

- 1. JHCW to the group titled **START UP COMMANDS** then JHCCW and highlight the group item titled **Call Tool**.
- 2. Press the WRITE key to have the control query you for a tool and enter in the number 2.
- 3. JHCCW and highlight the group item titled **Tool Start Up Commands**.
- 4. Press the WRITE key to have the control query you for defining all the commands to start up tool 2 in your program.

- INVOKE THE SPOT DRILLING CANNED CYCLE G83

- 1. JHCW and highlight the group titled **5. DRILL/TAP/BORE CYCLES.**
- 2. JHCCW three clicks. Deep Hole Peck Drill G83 will be highlighted.
- 3. Press the WRITE key to have the control query you for the code on setting up drilling with G83.

Note that Quick Code defined a block to execute a spot drill cycle at that present location. You can add more X and Y drill cycle locations if needed by selecting **6. DRILL/TAP/BORE LOCATIONS**.

Note: We do not want to drill a hole at X0 Y0, which is the center of the bolt hole circle, so manually edit in an L0 on the end of the G82 command line. This will ignore the G82 canned cycle until the next location.



- EXECUTE A CIRCULAR BOLT HOLE PATTERN

- 1. JHCW and highlight the group titled **6. DRILL/TAP/BORE LOCATIONS**.
- 2. JHCCW and highlight the group titled Bolt Hole Circle Locations
- 3. Press the WRITE key to have the control query you for the code on positioning around a bolt hole circle.
- 4. Enter in the numbers to answer all the questions in the lower left corner of the control screen, to define all the commands necessary to position around to drill a Bolt Hole Circle with a G83 canned cycle.

And now for tool 3, the 10-32 tap.

- CALL TOOL 3

- 1. JHCW to the group titled **START UP COMMANDS** then JHCCW and highlight the group item titled **Call Tool**.
- 2. Press the WRITE key to have the control query you for a tool and enter in the number 3.
- 3. JHCCW and highlight the group item titled **Tool Start Up Commands**.
- 4. Press the WRITE key to have the control query you for defining all the commands to start up tool 3 in your program.

- INVOKE THE TAPPING CANNED CYCLE G84

- 1. JHCW and highlight the group titled **5. DRILL/TAP/BORE CYCLES.**
- 2. JHCCW nine clicks. Right Hand Tapping G84 will be highlighted.
- 3. Press the WRITE key to have the control query you for the code on setting up tapping with G84.

Note that Quick Code defined a block to execute a tapping cycle at that present location. You will need to enter in the appropriate speed and feed for this tapping cycle. You can add more X and Y tap cycle locations if needed by selecting **6. DRILL/TAP/BORE LOCATIONS**.

Note: We do not want to tap a hole at X0 Y0, which is the center of the bolt hole circle, so manually edit in an L0 on the end of the G84 command line. This will ignore the G84 canned cycle until the next location.

- EXECUTE A CIRCULAR BOLT HOLE PATTERN

- 1. JHCW and highlight the group titled **6. DRILL/TAP/BORE LOCATIONS**.
- 2. JHCCW and highlight the group titled Bolt Hole Circle Locations
- 3. Press the WRITE key to have the control query you for the code on positioning around a bolt hole circle.
- 4. Enter in the numbers to answer all the questions in the lower left corner of the control screen, to define all the commands necessary to position around to tap a Bolt Hole Circle with a G84 canned cycle.





At this point you may decide to position the table forward to remove the part. You can do this in your program with the following.

- Rapid Z axis coolant OFF

- 1. JHCW and highlight the group titled ENDING COMMANDS.
- 2. JHCCW one click, to have the Rapid Z axis coolant OFF highlighted.
- 3. Press WRITE.

This will query you for the location to Rapid the Z axis and turn OFF the coolant with an M09.

And finally, you can properly end your program with:

- Sending the machine home and ending the program

- 1. JHCW and highlight the group titled ENDING COMMANDS.
- 2. JHCCW until Home Y and Z axes is highlighted.
- 3. Press WRITE.
- 4. JHCW and highlight the group titled End Program/Reset to Beginning.
- 5. Press WRITE.

You now have a program ready to run. You should always verify everything in graphics to make certain that you have not forgotten any steps. Although this looks like a lot of steps, it is actually very easy once you become familiar with the Quick Code environment. The above program can be generated in less than a minute.

THE QUICK CODE SOURCE FILE

All of the text seen in the group window, all of the code associated with items of groups, and much of the help text observed in the help window is contained in a G code program. This program is called the Quick Code source file. With this design, the user can modify Quick Code and tailor it to his specific needs. You can add or change groups and items. The user can develop his own Quick Code file, or program, by editing this file. Dealers can develop new applications and distribute them to their customers. The ability to edit the source file makes Quick Code an extremely flexible tool.

SOURCE FILE PROGRAM DESIGNATION

Program number 9999 is the default Quick Code source file. Every HAAS control equipped with Quick Code comes with a sample O9999 program installed. The default program number can be changed by changing parameter 228. If the file number in parameter 228 is not found in the control, the message FILE NOT FOUND is displayed and you will not be able to enter the Quick Code screen. The source file must be formatted as defined below. If program O9999 is not formatted in the appropriate manner then you may not see all, or any, of the defined Quick Code groups. You can use the following skeleton as a start for defining a Quick Code source file.

% O9999 (QUICK CODE - HAAS AUTOMATION INC.) () (ADD ANY COMMENTS HERE THAT PERTAIN TO) (THE ENTIRE SOURCE FILE. FOR INSTANCE) (YOU CAN RECORD WHO MADE THE FILE, THE) (DATE AND TIME OF THE LAST CHANGE, A) (VERSION NUMBER, OR ANYTHING ELSE YOU) (WANT. ALL COMMENTS PRIOR TO THE FIRST) (GROUP ARE NOT SEEN BY THE USER.) ()





(QUICK CODE GROUP DEFINITIONS FOLLOW)

```
:
()
(END OF QUICK CODE)
%
```

DEFINING A GROUP IN THE GROUP LIST (*)

To define a group that will show up in the group window, simply enter a comment where the first character is an asterisk. For instance if you want five groups to show up in the group window, then you would include the following five lines in the Quick Code source file.

(*GROUP1) (*GROUP2) (*GROUP3) (*GROUP4) (*GROUP5)

Of course, you can use any descriptive title for the group that is appropriate to what the group will contain. Group titles can be up to 35 characters long. Any additional characters beyond 35 will not be displayed.

GROUP HELP

The first five comments after the group definition will be displayed in the help window. These comments can be used to explain what is contained in the group. For example:

(*GROUP) (THIS GROUP CONTAINS HELP ON HOW TO) (USE QUICK CODE. WHEN THIS GROUP IS) (HIGHLIGHTED, TURN THE JOG HANDLE IN) (THE MINUS DIRECTION FOR MORE HELP.)

Additional comments beyond five lines are not displayed by Quick Code. This is a method of documenting the source file for the developer of the Quick Code file. Documenting comments can also be hidden in the source file by placing an empty comment after group help comments. In the following example only the first two comments are displayed in the help window.

(*HELP) (ONLY THE FIRST TWO COMMENTS ARE) (DISPLAYED IN THE HELP WINDOW.) () (THIS COMMENT IS NOT DISPLAYED)

If more than five lines are required to comment on a group, then you can use several groups to display 5, 10 or 15 lines of help. With this method you can add any amount of information you want about that group.

GROUP CODE

What happens when a group definition is highlighted and the user presses the WRITE key? If there is a G code after the group definition and before any other group or item definitions, then that G code will be inserted into the program that is being developed. Groups do not have to contain items for generating G code. A group title can stand alone as a code generating entity. The following group definition would add a G28 M30 to the program being developed when WRITE is pressed.



Note that the user will not see what G code is generated until the WRITE key is pressed and the code is inserted into the program. For this reason you may want to place the code that is to be generated in a help comment as is done above.

Quick Code can also generate comments in the program being generated. Any comments following an empty comment will be added to the currently edited program. In fact all code following an empty comment is inserted into the program until another empty comment is encountered or until a group or item definition is encountered. The empty comment must be the first code in the block. Any code in the same block as the empty comment is not entered into the program. In the following example, only the code in blocks between the empty comment blocks are added to the program being generated.

(*GENERATES COMMENTS AND CODE) (THIS IS NOT ADDED TO PROGRAM) ()(THIS IS NOT ADDED TO PROGRAM) (THESE COMMENTS WILL BE ADDED TO THE) (PROGRAM WHEN THIS GROUP IS) (HIGHLIGHTED AND WRITE IS PRESSED) G0 G90 G54 (THIS CODE IS ADDED) () (THESE COMMENTS ARE NOT ADDED TO THE) (PROGRAM BEING GENERATED)

DEFINING AN ITEM BELONGING TO A GROUP (**)

To define an item belonging to a group simply enter a comment after a group definition where the first two characters of the comment are asterisks. For instance, the following code generates a group with four subordinate items.

(*GROUP) (**ITEM1) (**ITEM2) (**ITEM3) (**ITEM4)

With the above Quick Code source file, only one group is displayed in the group window when the jog handle is turned clockwise. When the jog handle is turned counter clockwise, the five items are displayed and traversed. The item titles are indented one space so that you can differentiate items from groups. Only 34 characters of the item definition comment are displayed in the group window. Additional characters are ignored. The group that items belong to will always be displayed on the screen. The only limit to the number of items in a group is the amount of control memory available.

ITEM HELP

Item help works the same way as group help. The first four comments after the item definition are displayed in the help window. If more than four lines are required, it is recommended that prior items contain the desired comments. In this case instructions would have to be added to indicate which item generates the G code.

For example:





Although the above example is somewhat awkward, it does provide a method that will satisfy unusual cases. The line with all of the asterisks is legal. It is not inserted into the current program when the WRITE key is pressed. It is used to visually separate groups.

ITEM CODE

Code generated by group items is formatted in the same manner as group code is formatted. Refer to the section on group code for an explanation of how code is generated.

A SAMPLE QUICK CODE SOURCE FILE

After developing or modifying a Quick Code file, it is recommended that you save an off-line copy in a computer. You can keep comments in the Quick Code source file prior to the first group indicating what version the file is and how it differs from other versions. Maintain this program as you would any other G code program in your control with a proper backup scheme. **Remember! This source program file operates the Quick Code feature in your HAAS machine.** And you can have more then one Quick Code file, but the one the control is using is the program number listed under parameter 228 which should be a 9000 number and the one Haas uses is program number O9999.

A sample Quick Code source file can be found on the floppy that comes with the control. It contains many examples of how Quick Code can be used.

VISUAL QUICK CODE

Visual Quick Code (VQC) is a graphical editor made to help simplify programming for commonly made, simple parts. Given a standard part template and a set of dimensions, a program is created.

Quick Start Guide

- 1. Either create a new, empty program, or place the cursor at the "," (End of Block) where the new program will be added. Note: You must be in Advanced Editor.
- In Edit mode, press the PRGRM/CONVRS key three times to enter VQC. You can also enter VQC by using the pull-down menus in the Advanced Editor under HELP. After entering you will see a mostly empty screen with a list of words or short phrases on the right. These are the part categories.
- 3. Using the up and down arrow keys, select the part category you want, then press WRITE. Part templates will be seen in the large square area.
- 4. Using the up, down, left and right arrow keys, select a part template and press WRITE or press CANCEL to return to the category selection screen (step 3). Pressing WRITE (on the part template) will display an enlarged image of the selected part in the large square area including variables identifying the part dimensions.





- 5. Enter the data for the part. NOTE: Z0 will typically be 0, and the other Z values will typically be negative. R and C values are used to specify the radius or chamfer of a corner.
- 6. When the last value is entered, the control will ask if all data is correct. Press Y or N. If Y is pressed, the new program will be generated and sent to the Advanced Editor. Check the program that was created, for example, run the program in graphics mode and check the tool paths. Verify the tool offsets, and run the preliminary part using reduced feeds.
 - **Note:** Cutter Compesation may be applied, if so all Cutter Compensation rules will be used, refer to the Cutter Compensation section for complete details.

VISUAL QUICK CODE INTRODUCTION

Starting

You have the choice of either starting from scratch by creating a new empty program; or use VQC to insert code into an existing program. To insert into an existing program, select the program, enter Advanced Editor and position the cursor at the ";" (end of block) where you want the new code to be inserted **after**.

If you choose to start with a new program, VQC will end the program with an M30 (program end and rewind), if it exists in the template.

VQC will not end the code with an M30 if it is inserted into an existing program. Regardless if there is an M30 in the template (this is to prevent unwanted or multiple M30s).

To start Visual Quick Code (VQC) enter Edit mode then press the PRGRM/CONVRS key three times. Another way to use the pull down menus in the Advanced Editor under HELP.

Selecting a Category

Use the arrow keys to select the parts category that most closely matches the desired part and press WRITE. A set of thumbnail illustrations of the parts in that category will appear. These are the part templates for that category.







Selecting a Part Template

Use the arrow keys to select a template on the page. Pressing WRITE will display an outline of the part and allow the programmer to enter dimensions and other information to make the selected part. Press CANCEL to return to the list of categories.



Entering the Data

The control will prompt the programmer for information about the selected part. The data is not checked for consistency, so be careful to enter the numbers correctly. Once the information is entered, the final prompt is: Correct (Y/N). Press Y if the information is correct, or N to go back and edit the data.

After pressing Y, the G-code necessary to produce the part specified will be written to the selected program number. Additionally the program will be put into the Advanced Editor in order to double check the program. Verify the program by first running it in Graphics mode.





Extending Visual Quick Code

The Visual Quick Code system uses program O09997 to generate the icons and questions that the user sees, and the G code that is produced. Program O09997 consists entirely of comments. The comments contain keywords that the Visual Quick Code system understands. Some of the keywords are used to divide program O09997 into sections. The sections are hierarchical, that is the whole program is divided into CATEGORY sections, a CATEGORY section is divided into part TEMPLATE sections, and a TEM-PLATE is divided into DIAGRAM, PARAMETER, and CODE sections.

Other keywords are used within sections to set the attributes of the object defined in that section. For example, within the PARAMETER section, we might see the following lines:

(#DC) (LABEL DEPTH CUT) (POSITION [20,6])

The first line defines the variable which is used to hold the information entered by the user. The second line defines the "label", to put on the visual portion of the screen. This "label" represents the variable on the first line for better clarity. "LABEL" tells the Visual Quick Code system to print anything following the keyword "LABEL" on the screen. The third line with the key word "POSITION" tells the Visual Quick Code where to put the label on the screen. The following is a complete list of the keywords used by Visual Quick Code.





List of Keywords

Definition	Section
The beginning of a CATEGORY section	
The end of a CATEGORY section	
The beginning of a TEMPLATE section	Category
The end of a TEMPLATE section	Category
The beginning of a DIAGRAM section	Template
The end of a DIAGRAM section	Template
Specifies a LINE in the DIAGRAM	Diagram
Specifies a DATUM in the DIAGRAM	Diagram
Specifies an ARROW in the DIAGRAM	Diagram
Specifies a clockwise arc	Diagram
Specifies a counterclockwise arc	Diagram
Specifies a circle	Diagram
Specifies a thread in the DIAGRAM	Diagram
Specifies a label in the DIAGRAM	Diagram
The beginning of a PARAMETER section	Template
R The end of a PARAMETER section	Template
The LABEL attribute of a Parameter	Parameters
Sets the NO DECIMAL attribute	Parameters
Sets the ONE PLACE attribute	Parameters
Sets the TWO PLACE attribute	Parameters
Sets the THREE PLACE attribute	Parameters
Sets the FOUR PLACE attribute	Parameters
The beginning of a G-code section	Template
The end of a Template section	Template
	DefinitionThe beginning of a CATEGORY section The end of a CATEGORY section The beginning of a TEMPLATE section The end of a TEMPLATE section The beginning of a DIAGRAM section The end of a DIAGRAM section Specifies a LINE in the DIAGRAM Specifies a DATUM in the DIAGRAM Specifies a Counterclockwise arc Specifies a clockwise arc Specifies a label in the DIAGRAM Specifies a label in the DIAGRAM The beginning of a PARAMETER section The end of a PARAMETER section The LABEL attribute of a Parameter Sets the NO DECIMAL attribute Sets the TWO PLACE attribute Sets the FOUR PLACE attribute Sets the FOUR PLACE attribute The beginning of a G-code section The end of a Template section

The Visual Quick Code system expects the keyword to appear in the Section column. If the keyword appears in a different area, Visual Quick Code will ignore it, or produce an error message because it mistook the keyword for one that it expected, and the text following the keyword did not fit into the Visual Quick Code pattern.

PROGRAMMIMG VISUAL QUICK CODE

The selections fall into two groups, categories and parts. The programmer first selects, from a list, the type of machining that will be used, for example, Drill/tap, bolt hole patterns, bore cycles, etc. This is the catagory group. Selecting one of these categories displays an illustrated group of parts. The programmer chooses from these illustrations the one that most resembles the desired part. Once chosen the control now prompts the programmer for the dimensions of the parts. Programming code is generated after the programmer enter the dimensions.

Program O09997 is the Visual Quick Code model. The program consists of several Category sections which define the categories available to the programmer.

The following is a basic outline of program O9997 using a top-down approach, becomming more and more specific. This is the way that Visual Quick Code is used. First the user sees a list of catagories. After selecting a category, the user sees a list of parts. After selecting a part, the user sees what dimensions he or she can specify, and then the G-code is produced.



% 009997 (CATEGORY)

. . .

(END CATEGORY) (CATEGORY)

(END CATEGORY) (CATEGORY)

(END CATEGORY) (CATEGORY)

(END CATEGORY) %

Each CATEGORY section in turn consists of several TEMPLATE sections. These sections define which parts are available to the user once a category has been selected.

% 009997 (CATEGORY)

(TEMPLATE)

. . .

(END TEMPLATE) (TEMPLATE)

(END TEMPLATE) (TEMPLATE)

(END TEMPLATE) (END CATEGORY) %

Each TEMPLATE section consists of a DIAGRAM section, a PARAMETER section, and a GCODE section. The GCODE section is where the programming code is stored, but is missing some values that are entered by the programmer, via variables.

% O09997 (CATEGORY) ... (TEMPLATE) ... (DIAGRAM) ... (END DIAGRAM) (PARAMETER) ... (END PARAMETER) (GCODE) ... (END GCODE) (END TEMPLATE) (END CATEGORY) %





CATEGORY Section

The Category section is a collection of Part Templates. The necessary items are a beginning, a name, templates, and an end. CATEGORY marks the beginning of a Category section, and END CATEGORY marks the end. All of the templates that appear between the beginning and the end of a category belong to that category. NAME (your category name) should be the first line in the category section. The entered name will appear in the list of Visual Quick Code categories (this list appears when Visual Quick Code is first started).

Example: % (CATEGORY) (NAME: Parts With holes) (TEMPLATE)

(DIAGRAM)

. . .

. . .

(END DIAGRAM) (PARAMETER)

(END PARAMETER) (GCODE)

(END GCODE) (END TEMPLATE) (END CATEGORY) %

Part TEMPLATE Section

The Part TEMPLATE section specifies all the information about a typical part. This includes an illustration of the part and what variables can be entered to machine the part.

DIAGRAM Section

The DIAGRAM section is the part of the program that creates the part illustration on the screen. The illustration can be drawn with lines, arcs, and jagged lines that represent threads. This drawing is both for the thumbnail sketch and the full-sized illustration. The labels that appear on the full-sized version of the part are specified in the PARAMETERS section (see Parameters description).

DIAGRAM Coordinates

Each of the elements of the diagram must have a starting point and an ending point. The notation is [X,Y] where X is the horizontal coordinate and Y is the vertical coordinate. The best way to find out what the starting and ending points should be is to use graph paper. First sketch, on the graph paper, what is to appear on the screen. Then pick a point on the graph paper to be the origin, [0,0] (Any point will work, as the diagram will be scaled to fit wherever it is drawn). You can then determine the starting and ending points of all the lines, arcs (CW or CCW) and threads.

DIAGRAM Elements

The elements that make up a diagrams are lines, arcs (CW or CCW) and Threads. For each element, the starting point is specified first, then the ending point.

The format for a line is:

(LINE [X1,Y1] [X2,Y2])

The format for a clockwise arc is:

(CW [X1,Y1] [X2,Y2] r)

where r is the radius of the arc.

The format for a counterclockwise arc is:

(CCW [X1,Y1] [X2,Y2] r)

where r is the radius of the arc.

The format for a jagged line to represent a thread is;

(THREAD [X1,Y1] [X2,Y2])

NOTE: Arcs (CW or CCW) may only cover 180 degrees, or half a circle. If an arc of more than 180 degrees is needed, another arc must be used.

PARAMETERS Section

The PARAMETERS section lists all of the parameters that can be used to customize the standard part. Some of these would be the physical dimensions of the raw material and the part. Others would be tool and offset information, feed rates, and spindle speeds.

Each parameter begins with "#", which tells Visual Quick Code that value followed by the "#" will be the name for a specific variable. The format is:

(PARAMETERS) (#your variable name) (END PARAMETERS)

After a variable (parameter) has been specified, then any attributes of that particular parameter can be specified.

The POSITION Attribute

If you wish the parameter to appear in the diagram, you must supply a position. The format is (POSITION [X,Y]), where X is the horizontal coordinate and Y is the vertical coordinate. These coordinates are relative to the coordinates specified in the DIAGRAM section. Typically, only physical dimensions of the part will have a POSITION attribute.

Formatting Attributes

Several attributes are used to modify the value entered by the user. This is so that when the PARAMETER is used in the GCODE section, it will appear correctly. The Format column in the following table shows what would result from the G code template X#A, if the user enters 1 when asked for the value of parameter A. If none of the formatting attributes are used, the resulting G code would be X1.

Operator's Manual OUICK CODE SERIES Attribute Format Description X1 (NO DECIMAL) The value will appear in the final G-code output without a decimal point. Can be used for spindle speeds, tool numbers and offsets. (ONE PLACE) X.1 Numbers entered without a decimal point are automatically scaled to tenths. (TWO PLACE) X.01 Numbers entered without a decimal point are automatically scaled to hundredths. (THREE PLACE) X.001 Numbers entered without a decimal point are automatically scaled to thousandths. (FOUR PLACE) X.0001 Numbers entered without a decimal point are automatically scaled to ten-thousandths.

If more than one of these attributes are used with a single parameter, the results are not defined.

NOTE: Do not use more than one formatting attribute for a single parameter.

G CODE Section

The GCODE section is responsible for producing the G code necessary to cut the specified part. Similar to the previous sections of program O09997, the GCODE section consists only of comments. The comments contain standard programming code, just as a user would type it into the editor, except that the end-of-block marker (;) is not used within the comments. The other difference is an extension similar to macro variables: in place of a numeric value, "#" followed by a letter may be entered. The letter represents the variable name of a parameter in the PARAMETERS section.

For example, one of the lines might be:

(X#A)

Which means, "X followed by the number entered for parameter A." For example, if the user entered 3.5 for parameter A, the resulting G-code would be

X3.5;

Remember, the "#letter" combination can be used anywhere a number would be used; this means in expressions, as well as with simple codes. For example, (X [#A - #B]) is valid, as long as both A and B exist in the PARAMETER section.

NOTE: Be sure to use the parameter formatting attributes to make sure the G-code that is produced is valid. For example," T101.;" is not a valid G-code, because of the decimal point. So if a line in the G-code section reads (T#E), then parameter E must have the NO_DECIMAL attribute set.

lune 2002

Example Program

Below is an example of a simple program. This example is a complete O09997 template and is provided to help complete what you have just read.

% 09997 (CATEGORY)

(TEMPLATE) (NAME SQUARE MILLING)

(DIAGRAM) (LINE [0,0] [40,0]) (CENTER LINES) (LINE [0,0] [0,37]) (DATUM [34,31])

(LINE [4,31] [34,31]) (LINE [34,31] [34,3]) (LINE [34,3] [4,3]) (LINE [4,3] [4,31])

(LINE [4,32] [4,34]) (LINE [34,32] [34,34]) (LINE [35,31] [37,31]) (LINE [35,3] [37,3])

(ARROW [16,33] [4,33]) (ARROW [22,33] [34,33]) (ARROW [36,17] [36,31]) (ARROW [36,13] [36,3])

(END DIAGRAM)

(PARAMETERS) (#ToolNo) (NO DECIMAL)

(#WrkOfset) (NO DECIMAL)

(#CuterRad)

(#SpdleRpm) (NO DECIMAL)

(#DpthCut)

(#XDist) (POSITION [17,34])

(#YDist) (POSITION [35,16])

(#Feedrate)





(END PARAMETERS)

(GCODE) (T#ToolNo M06) (G00 G90 G#WrkOfset X[#CuterRad+.1] Y[#CuterRad+.1]) (S#SpdleRpm M03) (G43 H#ToolNo Z1. M08) (G01 Z-#DpthCut F50.) (G01 G41 D#ToolNo X0) (G01 Y-#YDist F#Feedrate) (G01 X-#XDist) (G01 Y0) (G01 X[0+#CuterRad+.1]) (G01 G40 Y[#CuterRad+.1]) (G00 Z1. M09) (G28 G91 Z0 M05) (M30) (END GCODE)

(END TEMPLATE)

(END CATEGORY) %

3.22 Advanced Editor

The HAAS Advanced Editor gives the user the ability to view and edit two CNC programs at a time. This makes it easier to modify existing programs and to create new ones. The editor includes pull-down menus that allow the user to access the features of the editor. Additionally, a context-sensitive help function is available to provide information on all of the editor's features.

The Advanced Editor is entered by pressing the EDIT key. The user can alternate between the Advanced Editor, the 40 column editor, and Quick Code with successive presses of the PRGRM/CONVRS key.

Whenever the pull-down menu system is active, the current menu is pulled down and one item is highlighted. The user can then use the jog handle to scroll through the menu items. The user can also use the up and down arrow keys to scroll through the items of that menu, or use the left and right arrow keys to open other menus.

The UNDO key is used to deactivate the pull-down menu system. If UNDO is pressed after invoking an executing function from a pull-down menu, it will abort that function.

The EDIT key can be used to "switch", left or right, between the two programs that have been selected to edit.

Pressing the F4 key will open another copy of the current program in the Advanced Editor. The user can quickly edit two different locations in the same program by pressing F4, moving to the second location, and then using the EDIT key to move back and forth between the two locations. If the user enters 'Onnnnn' and then presses F4, program Onnnnn is opened in the inactive window.

PROGRAM (EDIT) Ommon PROGRAM EDIT SEARCH MODIFY VO HELP Ommon	FIKEY TURNS MENU ON / OFF
Active Edit Display	Inactive Edit Display
Messages Input	Context sensitive help Alarm Messages

The following figure illustrates the layout of the advanced editor.

The advanced editor screen layout.

The advanced editor screen is divided into the following areas:

- Mode and Control Status contain the Current Display page, Operating mode and Control status.
- Messages where control status messages are displayed. This area is used to display prompts for user input in the advanced editor, and any alarm messages.
- Input where the user's input is displayed.



- Menu Bar contains the pull-down menu banner.
- **Key Help** contains short immediate help messages. Shows the user the most important keys that can be used in the current context or operation.
- Left/Right Side Display shows the active and inactive programs. When first entering the editor, the current program will be displayed on the left side and the right side will be blank. These areas can display another program or display program lists and help pages, when the appropriate menu item is selected from the pull-down menu.
- Context-Sensitive Help where context-sensitive help is displayed when you cursor onto a menu item.

Advanced Editor Features

This section briefly describes each feature of the advanced editor, each item found in the pull-down menus, and any prompts that might appear.

CONTEXT SENSITIVE HELP (The F1 key)

While in the advanced editor, press the F1 key to get into the menus, use the arrow keys or the jog handle to highlight the menu item. The help text for that item will appear in the lower right corner of the screen. PAGE UP and PAGE DOWN keys are used to view the help text. Press UNDO to go back to the menu, or RESET to exit the menus entirely.

THE PROGRAM MENU

Create New Program

This menu item will create a new program, providing there is room in the program directory and enough memory is available. Enter a program name (Onnnn) in the range of 0 through 99999 that is not already in the program directory.

Select Program From List

The HAAS control maintains a directory of programs that the user can select. Select this menu item to edit a program that exists in the directory.

When this menu item is selected, a list of programs is presented for viewing. Scroll through the list by using the cursor keys or the jog handle. Pressing the ENTER or SELECT PROG key will select the program that is highlighted and will replace the selection list with the selected program. The selected program is now active, and the previously active program will appear on the inactive edit screen.

Duplicate Active Program

This menu item will create a new program, copy the contents of the current program into it, rename it as specified, and make it the active program.

Delete Program From List

This menu item will delete a program from the program directory. A list of all programs is presented, with 'ALL' at the end.

To delete a single program, cursor to the program number and press the ENTER key. A prompt will ask for a confirmation of the deletion operation. Enter 'Y' to delete the highlighted program. If any other key is pressed, the program will not be deleted. After a program is deleted, the list of programs will again be presented.

To delete all programs, cursor to 'ALL' and press ENTER. Confirm deletion of all programs by pressing 'Y'. When all programs are deleted, program O0000 is created, and it is made the active program.

164 -





Switch To Left Or Right Side

This will switch left and right between the two programs, to make the active program inactive and the inactive program active. If there is no inactive program, then nothing happens. There are only two possible displays: one on the left and one on the right. The inactive display is used when a second program is selected or created.

THE EDIT MENU

Undo

The last insert, delete, or alter (simple edit) operation will be undone. Pressing UNDO again will restore the previous editing operation, up to the last 9 editing operations. If a block has been selected, choosing this item will simply exit block select mode without undoing anything.

Select Text

This item will set the start point of the block selection. To set the end point, scroll up or down to the desired place, and press the F2 or ENTER key. The selected block will then be highlighted. To deselect the block, press UNDO. This function works the same as in the 40 column editor, except this menu option is used to start selecting text, instead of the F1 key. Either the ENTER or F2 key can be used to end the selection. The following prompt will appear when this item is selected:

SCROLL UP/DOWN, PRESS ENTER OR F2 (to complete the text selection)

Move Selected Text

All selected text will be moved to the line following the cursor arrow position.

Copy Selected Text

All selected text will be copied to the line following the cursor arrow position.

Delete Selected Text

This item deletes any selected block. If no block is selected, the currently highlighted item is deleted. The UNDO key will restore any deleted comment or individual commands, but will not restore any blocks of code that were deleted. The DELETE key deletes individual characters from comments and is the hot key for this menu item.

Cut Selection To Clipboard

All selected text will be moved from the current program to a new program called the clipboard. Any previous contents of the clipboard are deleted. The program number (8998) for the clipboard is specified by Parameter 226 and can be altered, if necessary.

Copy Selection To Clipboard

All selected text will be copied from the current program to a new program called the clipboard. Any previous contents of the clipboard are deleted. The program number (8998) for the clipboard is specified by Parameter 226 and can be altered, if necessary.

Paste From Clipboard

The contents of the clipboard are copied into the current program at the line following the current cursor position.





THE SEARCH MENU

Find Text

This menu item will search for one or more G-Code items in the current program. The search can be performed in either the forward or backward direction from the current cursor location. If the item is found, the cursor will be positioned on it.

Find Again

This menu item will search the current program for the last block of code that was searched for. It will begin to search at the current cursor location, in the direction that was specified in the previous search. This function will search both selected and unselected blocks.

Find And Replace Text

This menu item will search the current program for one or more occurrences of a specified G-Code item and optionally replace each (or all) with another G-Code item. The search can be performed in either the forward or backward direction from the current cursor location. As each G-Code item is found, the cursor will be positioned on it, and a prompt will ask whether to replace the item, continue the search, both, or neither.

THE MODIFY MENU

Remove All Line Numbers

This menu item will automatically remove all unreferenced N-Codes from the edited program. If a block is selected, only the G-Code blocks contained within it will be affected.

Renumber All Lines

This menu item will either renumber all selected blocks in the program or, if a block is selected, renumber only those G-Code blocks contained in that block.

Renumber By Tool

Searches selected text, or the entire program, for T codes and renumbers program blocks grouped by T code.

Reverse + & - Signs

This menu item will reverse the signs of all numeric values associated with one or more address codes in the program. If a certain block is selected, only the address codes in the selected block will be affected.

Reverse X & Y

When this menu item is selected, all X address codes in the program will be changed to Y address codes, and Y's to X. If a block is selected, only the address codes contained within it will be affected.

THE I/O MENU

Send RS-232

This menu will send program(s) that are selected from the program directory to the RS-232 port. When this menu item is selected, a list of all the programs in memory is presented, with 'ALL' at the end.

To select a program, cursor to the program number and press the INSERT key. A highlighted space will appear before the program to indicate it has been selected. Pressing INSERT again will deselect the program, and the highlighted space will disappear. The DELETE key can be used to deselect all selected programs. When the cursor is on "ALL", all the programs are selected regardless of highlighting

To send the selected program(s), press the ENTER key. If more than one program or 'ALL' is selected, the data will be sent with one "%" at the beginning of the stream and one at the end.

Receive RS-232

This menu item will receive program(s) from the RS-232 serial port. The program(s) will then be stored in the CNC memory with the corresponding Onnnnn program number(s).

166-

Operator's Manual

On LISTPROG "ALL" must first be highlighted before using this menu item. The Onnnnn program numbers will be entered automatically from the input stream data. Note, "ALL" must be reselected on the LIST PROG screen after each file transfer.

Send Disk

This menu item will send program(s) to the disk. When this menu item is selected, a list of all the programs in memory is presented, with 'ALL' at the end.

To select a program, cursor to the program number and press the INSERT key. A highlighted space will apear before the program to indicate it has been selected. Pressing INSERT again will deselect the program, and the highlighted space will disappear. The DELETE key can be used to deselect all selected programs. When the cursor is on "ALL", all programs are selected regardless of highlighting.

ENTER DISK FILENAME: Type in the desired disk filename (in standard PC DOS format) for the disk file being sent, then press the ENTER key. If more than one program or "ALL" is selected, the data will be sent with one "%" at the beginning of the stream and one at the end. If a filename is not entered, the controller will send each selected file separately using the Onnnnn program number as the filename.

Receive Disk

This menu item will receive programs from the disk. The program(s) will then be stored in the CNC memory with the corresponding Onnnnn program number(s).

ENTER DISK FILENAME: Type in the filename (in standard PC DOS format) of the disk file being received, then press the ENTER key.

Disk Directory

This menu item will display the directory of the disk, with the first entry highlighted. To select a file, press the up and down arrow buttons or use the jog handle. To load a file, select it and press the WRITE key. The G-code programs in the file will be loaded into memory.

If there is insufficient memory for the entire file, Alarm 429 will be generated, and only a partial directory will be displayed.

THE F1:HELP MENU

How To Use The Editor

The on-line help is displayed whenever a menu is accessed. The help manual gives a brief description of the editor and its features. The up and down arrows and the jog handle control the menus, and the Page Up, Page Down Home and End keys are used to scroll through the help display. In addition, if the F1 key is pressed during the use of one of the menu options, the help is likewise displayed. Pressing F1 again will exit the help display. Pressing the UNDO key returns to the active program.

Quick Code

Selecting this menu item will place Quick Code on the inactive side of the editor. All Quick Code functions are now available to the user. Refer to the Quick Code section of the Operator's Manual for a full description of Quick Code. Pressing the EDIT key will exit Quick Code.





Advanced Editor Shortcuts

Pressing these keys, when in the Advanced Editor display, will quickly get you to these menu items without having to press the F1 key and cursoring to that selection.





3.23 MACROS

INTRODUCTION

This control function is optional. If you would like further information on installing this feature please call Haas Automation or your dealer for more information.

This is an introduction to macros as implemented on the HAAS CNC controls. MACROS adds capabilities and flexibility to standard G-code programming that allow the programmer to better define a tool path in a quicker and more natural way. With few exceptions, MACROS, as implemented on the HAAS controls, is compatible with FANUC 10M and 15M controls. Macro features not included in the current release are listed at the end of this section. Programmers already familiar with macro programming will want to review this section in order to avoid unnecessary work.

In traditional CNC programming, a program consists of subroutines that CANNOT be changed or altered except by editing individual values with an editor. MACROS allows the capability to program subroutines where the tool path or location of the tool path is changed, depending on the values contained within variables set by the programmer. These variables can be passed to the subroutine as parameters, or the values can reside in what are called *global variables*.

What this all means is that a programmer can create a collection of subroutines that have been fully debugged. These programs can be used as high level tools that can enhance programmer and machinist productivity. MACROS is not intended to replace modern CAD/CAM software, but it can and has improved machine productivity for those who use it.

Here are a few examples of the applications for MACROS. Rather than give macro code here, we will outline the general applications that MACROS can be used for.

Tools For Immediate, On-Table Fixturing

Many setup procedures can be semi-automated to assist the machinist. Tools can be reserved for immediate situations that were not anticipated during tool design. For instance, suppose a company uses a standard clamp with a standard bolt hole pattern. If it is discovered, after setup, that a fixture will need an additional clamp and if macro subroutine 2000 has been programmed for drilling the bolt pattern of the clamp, then the following two-step procedure is all that is needed for adding the clamp to the fixture.

- 1. Determine X, Y, and Z coordinates and angle where the clamp is to be placed by jogging the machine to the proposed clamp position and reading the position coordinates from the machine display.
- 2. Execute the following command in MDI mode:

G65 P2000 X??? Y??? Z??? A??? ; Where **???** are the values determined in Step 1.

Here, macro 2000 (not shown) takes care of all the work since it was designed to drill the clamp bolt hole pattern at the specified angle of **A**. Essentially, the machinist has created his own custom canned cycle.



Simple Patterns That Are Repeated Over And Over Again In The Shop

Patterns that recur over and over again can be parameterized and kept around for easy, immediate use. For example:

- 1) Bolt hole patterns.
- 2) Slotting.
- 3) Angular patterns, 5 holes at 30 degrees 1 inch apart.
- 4) Specialty milling such as soft jaws.
- 5) Matrix Patterns, 12 across and 15 down.
- 6) Flycutting a surface, 12 inches by 5 inches using a 3 inch fly cutter.

Automatic Offset Setting Based On The Program

With macros, coordinate offsets can be set in each program so that setup procedures become easier and less error-prone.

Probing

Probing enhances the capabilities of the machine in many ways. Below is just a hint of the possibilities.

- 1) Profiling of a part to determine unknown dimensions for later machining.
- 2) Tool calibration for offset and wear values.
- 3) Inspection prior to machining to determine material allowance on castings.
- 4) Inspection after machining to determine parallelism and flatness values as well as location.

Macros allow less experienced personnel to operate the machine. Conditions can be detected and custom operator messages or alarms can be displayed on the console to notify the operator.

MACRO SUBROUTINE CALL (G65)

G65 is the command that calls a subroutine with the ability to pass arguments to it. The format follows.

[N#####] G65 P##### [L####] [arguments] ;

Anything enclosed in brackets is optional. This should not be confused with expression brackets that are explained below. The G65 command requires a **P** address parameter corresponding to any program number currently in memory. When the optional **L** address is used the macro call is repeated the specified number of times.

In Example 1, subroutine 1000 is called once with no parameters passed to the routine. G65 calls are similar to, but not the same as, M98 calls. Up to four G65 calls can be made at the same time, (Nesting four deep).

Example 1:	G65 P1000 ; M30 ; O1000 ;	(Call subroutine 1000 as a macro) (Program stop) (Macro Subroutine)
	 M99 ;	(Return from Macro Subroutine)

In Example 2, subroutine 9010 is designed to drill a sequence of holes along a line whose slope is determined by the X and Y arguments that are passed to it in the G65 command line. The Z drill depth is passed as **Z**, the feed rate is passed as **F**, and the number of holes to be drilled is passed as **T**. The line of holes is drilled starting from the current tool position when the macro subroutine is called.



Example 2:	G00 G90 X1.0 Y1.0 Z.05 S1000 M03; G65 P9010 X.5 Y.25 Z.05 F10. T10 ; G28 M30 ; O9010 ; F#9 ; WHILE [#20 GT 0] DO1; G91 G81 Z#26 ; #20=#20-1 ; IF [#20 EQ 0] GOTO5 ; G00 X#24 Y#25 ; N5 END1 ; M99 :	(Position tool) (Call 9010) (Diagonal hole pattern) (F =Feed rate) (Repeat T times) (Drill To Z depth) (Decrement counter) (All holes drilled) (Move along slope) (Return to caller)
	M99 ;	(Return to caller)

ALIASING

Aliasing is a means of assigning a G code to a G65 P##### sequence. For instance, in Example 2 it would be easier if one could write:

G06 X.5 Y.25 Z.05 F10. T10;

Here, we have substituted an unused G code, G06 for G65 P9010. In order for the above block to work we must set the parameter associated with subroutine 9010 to 06 (Parameter 91).

Note that G00, G65, G66, and G67 can not be aliased. All other codes between 1 and 255 can be used for aliasing.

Program numbers 9010 through 9019 are reserved for G code aliasing. The following table lists which HAAS parameters are reserved for macro subroutine aliasing.

Haas Parameter	O Code
91	9010
92	9011
93	9012
94	9013
95	9014
96	9015
97	9016
98	9017
99	9018
100	9019

Setting an aliasing parameter to 0 disables aliasing for the associated subroutine. If an aliasing parameter is set to a G-code and the associated subroutine is not in memory, then an alarm will be given.

M code Aliasing

Haas Parameter	M Macro Call
81	9000
82	9001
83	9002
84	9003
85	9004
86	9005
87	9006
88	9007
89	9008
90	9009




Macro Arguments

The arguments in a G65 statement are a means of sending values to and setting the local variables of a called macro subroutine.

In Example 2 above, the arguments X and Y are passed to the macro subroutine local variables. Local variable #24 is associated with X and is set to 0.5. Similarly, Local variable #25 is associated with Y and is set to 0.25.

The following two tables indicate the mapping of the alphabetic address variables to the numeric variables used in a macro subroutine.

Alphabetic Addressing

Address:	A	B	C	D	E	F	G	H		J	K	L	M
Variable:	1	2	3	7	8	9	-	11	4	5	6	-	13
Address:	N	0	P	Q	R	S	T	U	V	W	X	Y	Z
Variable:	-		-	17	18	19	20	21	22	23	24	25	26

Alternate Alphabetic Addressing

Address:	A	B	C		J	K		J	K	І	J
Variable:	1	2	3	4	5	6	7	8	9	10	11
Address:	K	І	J	K	І	J	K	І	J	K	І
Variable:	12	13	14	15	16	17	18	19	20	21	22
Address:	J	K	І	J	K	І	J	K	І	J	K
Variable:	23	24	25	26	27	28	29	30	31	32	33

Arguments accept any floating point value to four decimal places. If you are in metric, the control will assume thousandths (.000). In Example 3 below, local variable #7 will receive .0004.

If a decimal is <u>not</u> included in an argument value, such as:

G65 P9910 A1 B2 C3

The values are passed to macro subroutines according to the following table:

Integer Argument Passing (no decimal point)

Address:	A	B	C	D	E	F	G	H	l	J	K	L	M
Variable:	.001	.001	.001	1.	1.	1.	-	1.	.0001	.0001	.0001	1.	1.
Address:	N	0	P	Q	R	S	T	U	V	W	X	Y	Z
Variable:	-		-	.0001	.0001	1.	1.	.0001	.0001	.0001	.0001	.0001	.0001

All 33 local macro variables can be assigned values with arguments by using the alternate addressing method. The following example shows how one could send two sets of coordinate locations to a macro subroutine. Local variables #4 through #9 would be set to .0001 through .0006 respectively.

Example 3: G65 P2000 I1 J2 K3 I4 J5 K6 ;

The following letters cannot be used to pass parameters to a macro subroutine: G, L, N, O or P.

Macro Constants

Constants are floating point values placed in a macro expression. They can be combined with addresses A...Z or they can stand alone when used within an expression. Examples of constants are .0001, 5.3 or -10.

Macro Variables

There are three categories of macro variables: system variables, global variables, and local variables.

Variable Usage

All variables are referenced with a number sign (#) followed by a positive number. Examples are: #1, #101, and #501.

Variables are decimal values that are represented as floating point numbers. If a variable has never been used, it can take on a special "undefined" value. This indicates that it has not been used. A variable can be set to undefined with the special variable #0. #0 has the value of undefined or 0.0 depending on the context it is used in. More about this later. Indirect references to variables can be accomplished by enclosing the variable number in brackets.

#[<expression>]

The expression is evaluated and the result becomes the variable accessed. For example:

#1=3;

#[#1]=3.5 + #1;

This sets the variable #3 to the value 6.5.

Variables can be used in place of G-code address constants where "address" refers to the letters A..Z.

In the block

N1 G0 G90 X1.0 Y0;

the variables can be set to the following values:

#7=0; #11=90; #1=1.0; #2=0.0;

and the block replaced by:

N1 G#7 G#11 X#1 Y#2;

The values in the variables at runtime are used as the address values.



Local Variables

Local variables range between #1 and #33. A set of local variables is available at all times. When a call to a subroutine with a G65 command is executed, the local variables are saved and a new set is available for use. This is called "nesting" of the local variables. During a G65 call, all of the new local variables are cleared to undefined values and any local variables that have corresponding address variables in the G65 line are set to the G65 line values. Below is a table of the local variables along with the address variable arguments that change them.

Variable: Address: Alternate:	1 A	2 B	3 C	4 1	5 J	6 K	7 D I	8 E J	9 F K	10 I	11 H J
Variable: Address: Alternate:	12 K	13 M I	14 J	15 K	16 I	17 Q J	18 R K	19 S I	20 T J	21 U K	22 V I
Variable: Address: Alternate:	23 W J	24 X K	25 Y I	26 Z J	27 K	28 I	29 J	30 K	31 I	32 J	33 K

Note that variables 10, 12, 14..16 and 27..33 do not have corresponding address arguments. They can be set if a sufficient number of I, J and K arguments are used as indicated above in the section about arguments.

Once in the macro subroutine, the local variables can be read and modified by referencing the variable numbers 1..33.

When the **L** argument is used to do multiple repetitions of a macro subroutine, the arguments are set only on the first repetition. This means that if local variables 1..33 are modified in the first repetition, then the next repetition will have access only to the modified values. Local values are retained from repetition to repetition when the **L** address is greater than 1.

Calling a subroutine via an M97 or M98 does not nest the local variables. Any local variables referenced in a subroutine called by an M98 are the same variables and values that existed prior to the M97 or M98 call.

Global Variables

Global variables are variables that are accessible at all times. There is only one copy of each global variable. Global variables occur in two ranges: 100..199 and 500..599. The global variables remain in memory when power is turned off. They are not cleared as in the FANUC controls.

System Variables

System variables give the programmer the ability to interact with a variety of control parameters and settings. By setting a system variable, the function of the control can be modified or altered. By reading a system variable, a program can modify its behavior based on the value in the variable. Some system variables have a READ ONLY status. This means that they can not be modified by the programmer. A brief table of currently implemented system variables follows with an explanation of their use.

SERIES Operator's Manual

USAGE

VARIABLES

#0	Not a number (read only)
#1-#33	Macro call arguments
#100-#199	General purpose variables saved on power off
#500-#699	General purpose variables saved on power off
#700-#749	Hidden variables for internal use only.
#800-#999	General purpose variables saved on power off
#1000-#1063	64 discrete inputs (read only)
#1064-#1068	Maximum axis loads.
#1080-#1087	Raw analog to digital inputs (read only)
#1090-#1098	Filtered analog to digital inputs (read only)
#1094	Spindle load with OEM spindle drive (read only)
#1098	Spindle load with Haas vector drive (read only)
#1100-#1139	40 discrete outputs
#1140-#1155	16 extra relay outputs via multiplexed output
#1264-#1268	Maximum axis loads.
#2000-#2199	Tool length offsets
#2201-#2399	Tool length wear
#2401-#2599	Tool diameter/radius offsets
#2601-#2799	Tool diameter/radius wear
#3000	Programmable alarm
#3001	Millisecond timer
#3002	Hour timer
#3003	Single block suppression
#3004	Override control
#3006	Programmable stop with message
#3011	Year, month, day
#3012	Hour, minute, second
#3020	Power on timer (read only)
#3021	Cycle start timer (read only)
#3022	Feed timer (read only)
#3023	Present part timer (read only)
#3024	Last complete part timer (read only)
#3025	Previous part timer (read only)
#3026	Tool in spindle (read only)
#3027	Spindle RPM (read only)
#3901	M30 count 1
#3902	M30 count 2
#4000-#4021	Previous block group codes
#4101-#4126	Previous block address codes

NOTE: Mapping of 4101 to 4126 is the same as the alphabetic addressing of "Macro Arguments" section; e.g. the statement x1.3 sets variable #4124 to 1.3.

Previous block end position

Present tool offset Common offset G54 work offsets G55 work offsets G56 work offsets G57 work offsets

Present machine coordinate position Present work coordinate postion Present skip signal position - X,Y,Z,A,B

#5000-#5005
#5020-#5025
#5041-#5045
#5061-#5065
#5081-#5085
#5201-#5205
#5221-#5225
#5241-#5245
#5261-#5265
#5281-#5285





#5301-#5305	G58 work offsets
#5321-#5325	G59 work offsets
#5401-#5500	Tool feed timers (seconds)
#5501-#5600	Total tool timers (seconds)
#5601-#5699	Tool life monitor limit
#5701-#5800	Tool life monitor counter
#5801-#5900	Tool load monitor maximum load sensed so far
#5901-#6000	Tool load monitor limit
#6001-#6277	Settings (read only)
#6501-#6999	Parameters (read only)
NOTE:	The low order bits of large values will not appear in the macro variables for

settings and parameters

#7001-#7005	G110 additional work offsets
#7021-#7025	G111 additional work offsets
#7041-#7045	G112 additional work offsets
#7061-#7065	G113 additional work offsets
#7081-#7085	G114 additional work offsets
#7101-#7105	G115 additional work offsets
#7121-#7125	G116 additional work offsets
#7141-#7145	G117 additional work offsets
#7161-#7165	G118 additional work offsets
#7181-#7185	G119 additional work offsets
#7201-#7205	G120 additional work offsets
#7221-#7225	G121 additional work offsets
#7241-#7245	G122 additional work offsets
#7261-#7265	G123 additional work offsets
#7281-#7285	G124 additional work offsets
#7301-#7305	G125 additional work offsets
#7321-#7325	G126 additional work offsets
#7341-#7345	G127 additional work offsets
#7361-#7365	G128 additional work offsets
#7381-#7385	G129 additional work offsets

System Variables In-Depth

This section fully describes system variables.

1-Bit Discrete Inputs

Inputs designated as "spare" can be connected to external devices and used by the programmer.

1-Bit Discrete Outputs

The HAAS control is capable of controlling up to 56 discrete outputs. However, a number of these outputs are already reserved for use by the HAAS controller.

> CAUTION! Do not use outputs that are reserved by the system. Using these outputs may result in injury or damage to your equipment.

The user can change the state of these outputs by writing to variables designated as "spare". If the outputs are connected to relays, then an assignment of "1" sets the relay. An assignment of "0" clears the relay.



Referencing these outputs will return the current state of the output and this may be the last assigned value or it may be the last state of the output as set by some user M code. For example, after verifying that output #1108 is "spare":

#1108=1;	(Turns #1108 relay on)
#101=#3001+1000;	(101 is 1 second from now)
WHILE [[#101 GT #3001] A	ND [#1109 EQ 0]] D01
END1	(Wait here 1 second or until relay #1109 goes high)
#1108=0;	(Turns #1108 relay off)

The number of outputs available to the user and where user M codes are mapped is model dependent. If your control is not equipped with the M-code relay board, then M21 through M28 will be mapped from #1132-#1139. If you have equipment with the M-code relay board installed, see the 8M option section for information and instructions.

You should always test or dry run programs that have been developed for macros that is running with new hardware.

Maximum axis loads available in variables

The following variables are used to contain the maximum load values for each axis. They can be cleared by cycling power to the machine or by setting the macro to zero in a program (for example, #1064=0;).

1064 = X axis 1264 = C axis 1065 = Y axis 1265 = U axis 1066 = Z axis 1266 = V axis 1067 = A axis 1267 = W axis 1068 = B axis 1268 = T axis

Tool Offsets

HAAS macros have been implemented with FANUC control memory C option in mind. This means that each tool offset has a length (H) and radius (D) along with associated wear values.

#2001-#2200	H geometry offsets (1-200) for length.
#2200-#2400	H geometry wear (1-200) for length.
#2401-#2600	D geometry offsets (1-200) for diameter.
#2601-#2800	D geometry wear (1-200) for diameter.

Programmable Messages

#3000 ALARMS can be programmed. A programmable alarm will act just like HAAS internal alarms. An alarm is generated by setting the macro variable #3000 to a number between 1 and 999.

#3000= 15 (MESSAGE PLACED INTO ALARM LIST);

When this is done, ALARM flashes in the lower right hand corner of the display and the text in the next comment is placed into the alarm list. The alarm number (in this example, 15) is added to 1000 and used as an alarm number. If an alarm is generated in this manner all motion stops and the program must be reset to continue. Programmable alarms can always be identified in alarm history because the alarm numbers range between 1000 and 1999.

The first 34 characters of the comment will be used for the alarm message. The first 15 characters of the comment will be displayed on the lower left corner of the screen.





Timers

HAAS macros supports access to two timers. These timers can be set to a value by assigning a number to the respective variable. A program can then later read the variable and determine the time passed since the timer was set. Timers can be used to emulate dwell cycles, determine part to part time or wherever time dependent behavior is desired.

- #3001 MILLISECOND TIMER The millisecond timer is updated every 20 milliseconds and thus activities can be timed with an accuracy of only 20 milliseconds. At POWER ON, the millisecond timer is reset. The timer has a limit of 497 days. The whole number returned after accessing #3001 represents the number of milliseconds.
- #3002 HOUR TIMER The hour timer is similar to the millisecond timer except that the number returned after accessing #3002 is in hours. The hour and millisecond timers are independent of each other and can be set separately.

System Overrides

#3003 Variable 3003 is the Single Block Suppression parameter. It overrides the Single Block function in G-code. In the example below, suppression of Single Block is initiated when #3003 is set equal to 1. After M3003 is set =1, each G-code instruction block (lines 2-4) are executed continuously even though the Single Block function is enabled. When #3003 is set equal to zero, the operator of Single Block will resume as normal. That is, the user must press Cycle Start to initiate each new code block (lines 6-8).

#3003=1; G54 G00 G90 X0 Y0; G81 R0.2 Z-0.1 F20 L0; S2000 M03; #3003=0; T02 M06; G83 R0.2 Z-1 F10. L0; X0. Y0.;

#3004 Variable #3004 is a bitmapped variable that overrides specific control features during runtime.

The first bit disallows FEED HOLD from the keypad. If you do not want feed hold to be executed during any section of code, then bracket that code with assignments to variable #3004. Assigning "1" to #3004 disables the console's feed hold button. Assigning "0" to #3004 re-enables the FEED HOLD button. For example:

Approach code	(FEED HOLD allowed)
#3004=1;	(Disables FEED HOLD button)
Non-stoppable code	(FEED HOLD not allowed)
#3004=0;	(Enables FEED HOLD button)
Depart code	(FEED HOLD allowed)

Operator's Manual

The following is a map of variable #3004 bits and the associated overrides. E=Enabled D=Disabled

-			
#3004	FEED HOLD	FEED RATE OVERRIDE	EXACT STOP CHECK
0	E	E	E
1	D	E	E
2	E	D	E
3	D	D	E
4	E	E	D
5	D	E	D
6	E	D	D
7	D	D	D

Programmable Stop

#3006 Stops can be programmed. A programmable stop acts like an M00. In the following example, when the assignment statement is executed, the first 15 characters of the comment are displayed in the messaging area on the lower left part of the screen above the command input line. The control stops and waits for a cycle start from the operator. Upon cycle start, operation continues with the next block after the assignment statement.

IF [#1 EQ #0] THEN #3006=101(ARG.A REQUIRED);

Last Block (MODAL) Group Codes

#4001-#4021 The grouping of G codes permits more efficient processing. G codes with similar functions are usually under the same group. For instance, G90 and G91 are under group 3. Vari ables have been set aside to store the last or default G code issued for any of 21 groups. By reading the group code, a macro program can change its behavior based on the contents of the group code. If 4003 contains 91, then a macro program could determine that all moves should be incremental rather than absolute. There is no associated variable for group zero, group zero G codes are NON-modal.

Last Block (MODAL) Address Data

#4101-#4126 Address codes A..Z (excluding G) are also maintained as modal values. The modal information represented by the last block interpreted by the lookahead process is con tained in variables 4101 through 4126. The numeric mapping of variable numbers to alphabetic addresses corresponds to the mapping under alphabetic addresses. For instance, the value of the previously interpreted **D** address is found in #4107 and the last interpreted **I** value is #4104.

Last Target Position

#5001-#5005 The final programmed point, target position, for the most recent motion block can be accessed through variables #5001-#5005, X, Y, Z, A, and B, respectively. Values are given in the current work coordinate system and can be used while the machine is in motion.

Current Machine Coord Position

#5021-#5025 The current position in machine coordinates can be obtained through #5021-#5025, X, Y, Z, A, and B, respectively. The values CANNOT be read while the machine is in motion. #5023 (Z) represents the value after tool length compensation has been applied.





Current Work Coord Position

#5041-#5045 The current position in the current work coordinates can be obtained through #5041-5045, X, Y, Z, A, and B, respectively. The values can NOT be read while the machine is in motion. #5043 (Z) represents the value after tool length compensation has been applied.

Current Skip Signal Position

#5061-#5065 The position where the last skip signal was triggered can be obtained through #5061-#5065, X, Y, Z, A, and B, respectively. Values are given in the current work coordinate system and can be used while the machine is in motion. #5063 (Z) represents the value after tool length compensation has been applied.

Tool Length Compensation

#5081-#5085 The current total tool length compensation that is being applied to the tool is returned. This includes tool length offset referenced by the current modal value set in H (#4008) plus the wear value.

Offsets

All tool work offsets can be read and set within a macro expression. This allows the programmer to preset coordinates to approximate locations, or to set coordinates to values based upon the results of skip signal locations and calculations. When any of the offsets are read, the interpretation lookahead queue is stopped until that block is executed.

#5201-#5205	G52 X, Y, Z, A, B OFFSET VALUES
#5221-#5225	G54 " " " " " " "
#5241-#5245	G55 " " " " " " "
#5261-#5265	G56 " " " " " " "
#5281-#5285	G57 " " " " " " "
#5301-#5305	G58 " " " " " " "
#5321-#5325	G59 " " " " " " "
#7001-#7005	G110 X, Y, Z, A, B OFFSET VALUES
""	
#7381-#7385	G129 X, Y, Z, A, B OFFSET VALUES

Address Constant Substitution

The usual method of setting control addresses A..Z is by appending a constant to the address. For instance,

G01 X1.5 Y3.7 F20.;

sets addresses G, X, Y and F to 1, 1.5, 3.7 and 20.0 respectively and thus instructs the control to move linearly, G01, to position X=1.5 Y=3.7 at a feed rate of 20 inches per minute. Macro syntax allows the constants to be replaced with any variable or expression in any section of code (i.e., you do not have to be in a macro subroutine).

The previous statement can be replaced by the following code:

#1=1; #2=.5; #3=3.7; #4=20; G#1 X[#1+#2] Y#3 F#4 ;

Operator's Manual

A-#101 Y[#5041+3.5] Z-[SIN[#1]]



The permissible syntax on addresses A..Z (exclude N or O) is as follows:

<address><-><variable></variable></address>	
<address>[<expression>]</expression></address>	
<address><->[<expression>]</expression></address>	

If the value of the variable does not agree with the range of the address, then the usual control alarm will result. For instance, the following code would result in a range error alarm because tool diameter numbers range from 0..50.

#1=75; D#1;

When a variable or expression is used in place of an address constant, then the floating point value is rounded to the least significant digit. If #1=.123456, then G1X#1 would move the machine tool to .1235 on the X axis. If the control is in the metric mode, the machine would be moved to .123 on the X axis.

When an UNDEFINED variable is used to replace an address constant, then that address reference is ignored. For example, if #1 is undefined then the block

G00 X1.0 Y#1;

becomes

G00 X1.0. No Y movement takes place.

Macro Statements

Macro statements are lines of code that allow the programmer to manipulate the control with features similar to any standard programming language. Included are functions, operators, conditional and arithmetic expressions, assignment statements, and control statements.

Functions and operators are used in expressions to modify variables or values. The operators are essential to expressions while functions make the programmer's job easier.

Functions

Functions are built-in routines that the programmer has available to use. All functions have the form **<function_name>[argument]**. Functions can be passed any expression as arguments. Functions return floating point decimal values. The function provided with the HAAS control are as follows:

FUNCTION	ARGUMENT	RETURNS	NOTES	
SIN[]	Degrees	Decima	al	Sine
COS[]	Degrees	Decima	al	Cosine
TAN[]	Degrees	Decima	al	Tangent
ATAN[]	Decimal	Degree	s	Arctangent
				Same as FANUC
				ATAN[]/[1]
SQRT[]	Decimal	Decima	al	Square root
ABS[]	Decimal	Decima	al	Absolute value
ROUND[]	Decimal	Decima	al	Round off a decimal
FIX[]	Decimal	Integer		Truncate fraction
ACOS[]	Degrees	Decima	al	Arccosine
ASIN[]	Degrees	Decima	al	Arcsine
#[]	Integer	Integer		Variable Indirection
DPRNT[]	ASCII tex	ĸt		External Output





Notes on Functions

The function ROUND works differently depending on the context that it is used. When used in arithmetic expressions, the round function works as one would expect. That is, any number with a fractional part greater than or equal to .5 is rounded up to the next whole integer; otherwise, the fractional part is truncated from the number.

#1= 1.714; #2= ROUND[#1]; (#2 is set to 2.0) #1= 3.1416; #2= ROUND[#1]; (#2 is set to 3.0)

When round is used in an address expression, then the argument of round is rounded to the addresses significant precision. For *metric* and *angle* dimensions, three-place precision is the default. For *inch*, four-place precision is the default. Integral addresses such as D, T and H are rounded normally.

```
#1= 1.00333;
G0 X[ #1 + #1 ];
(Table moves to 2.0067);
G0 X[ ROUND[ #1 ] + ROUND[ #1 ] ];
(Table moves to 2.0066);
G0 A[ #1 + #1 ];
(Axis moves to 2.007);
G0 A[ ROUND[ #1 ] + ROUND[ #1 ] ];
(Axis moves to 2.006);
D[1.67] (Diameter 2 is made current);
```

Operators

Operators can be classified into three categories: Arithmetic operators, Logical operators and Boolean operators.

Arithmetic Operators

Arithmetic operators consist of the usual unary and binary operators. They are:

+	- Unary plus	+1.23
-	- Unary minus	-[COS[30]]
+	- Binary addition#1=#	1+5
-	- Binary subtraction	#1=#1-1
*	- Multiplication	#1=#2*#3
1	- Division	#1=#2/4
MOD	- Remainder	#1=27 MOD 20
		(#1 contains 7)

Logical Operators

Logical operators are operators that work on binary bit values. Macro variables are floating point numbers. When logical operators are used on macro variables, only the integer portion of the floating point number is used. The logical operators are:

OR - logically OR two values together XOR - Exclusively OR two values together AND - Logically AND two values together

Examples:

```
#1=1.0; 0000 0001
#2=2.0; 0000 0010
#3=#1 OR #2 0000 0011
```

Here the variable #3 will contain 3.0 after the OR operation.

#1=5.0; #2=3.0;

IF [[#1 GT 3.0] AND [#2 LT 10]] GOTO1 Here control will transfer to block 1 because #1 GT 3.0 evaluates to 1.0 and #2 LT 10 evaluates to 1.0, thus 1.0 AND 1.0 is 1.0 (TRUE) and the GOTO occurs.

As can be seen from the previous examples, CARE must be taken when using logical operators so that the desired result is achieved.

Boolean Operators

Boolean operators always evaluate to 1.0 (TRUE) or 0.0 (FALSE). There are six Boolean operators. These operators are not restricted to conditional expressions, but they most often are used in conditional expressions. They are:

EQ - Equal to NE - Not Equal to GT - Greater Than LT - Less Than GE - Greater than or Equal to LE - Less Than or Equal to

The following are four examples of how Boolean and Logical operators can be used:

Example

IF [#1 EQ 0.0] GOTO100; WHILE [#101 LT 10] DO1; #1=[1.0 LT 5.0]; IF [#1 AND #2 EQ #3] GOTO1

Explanation

Jump to block 100 if value in variable #1 equals 0.0. While variable #101 is less than 10 repeat loop DO1..END1. Variable #1 is set to 1.0 (TRUE). If variable #1 logically ANDed with variable #2 is equal to the value in #3 then control jumps to block 1.

Expressions

Expressions are defined as any sequence of variables and operators surrounded by the square brackets "[" and "]". There are two uses for expressions: conditional expressions or arithmetic expressions. Conditional expressions return FALSE (0.0) or TRUE (any non zero) values. Arithmetic expressions use arithmetic operators along with functions to determine a value.

Conditional Expressions

In the HAAS control, ALL expressions set a conditional value. The value is either 0.0 (FALSE) or the value is nonzero (TRUE). The context in which the expression is used determines if the expression is a conditional expression. Conditional expressions are used in the IF and WHILE statements and in the M99 command. Conditional expressions can make use of Boolean operators to help evaluate a TRUE or FALSE condition.

The M99 conditional construct is unique to the HAAS control. Without macros, M99 in the HAAS control has the ability to branch unconditionally to any line in the current subroutine by placing a P code on the same line. For example:

N50 M99 P10;

branches to line N10. It does not return control to the calling subroutine. With macros enabled, M99 can be used with a conditional expression to branch conditionally. To branch when variable #100 is less than 10 we could code the above line as follows.





N50 [#100 LT 10] M99 P10 ;

In this case, the branch occurs only when #100 is less than 10, otherwise processing continues with the next program line in sequence. In the above, the conditional M99 can be replaced with

N50 IF [#100 LT 10] GOTO10;

Arithmetic Expressions

An arithmetic expression is any expression using constants, variables, operators, or functions. An arithmetic expression returns a value. Arithmetic expressions are usually used in assignment statements, but are not restricted to them.

Examples of Arithmetic expressions: #101=#145*#30;

#1=#1+1; X[#105+COS[#101]]; #[#2000+#13]=0;

Assignment Statements

Assignment statements allow the programmer to modify variables. The format of the assignment statement is:

<expression>=<expression>

The expression on the left of the equal sign must always refer to a macro variable, whether directly or indirectly. The following macro initializes a sequence of variables to any value. Here both direct and indirect assignments are used.

O0300
N1 IF [#2 NE #0] GOTO2
#3000=1
N2 IF [#19 NE #0] GOTO3
#3000=2
N3 WHILE [#19 GT 0] DO1 ;
#19=#19-1
#[#2+#19]=#22
END1;
M99 ;

(Initialize an array of variables) ; (B=base variable) ; (BASE VARIABLE NOT GIVEN) ; (S=size of array); (SIZE OF ARRAY NOT GIVEN) ;

(DECREMENT COUNT); (V=value to set array to);

The above macro could be used to initialize three sets of variables as follows:

G65 P300 B101. S20 (INIT 101..120 TO #0); G65 P300 B501. S5 V1 (INIT 501..505 TO 1.0); G65 P300 B550. S5 V0 (INIT 550..554 TO 0.0);

The decimal point in B101., etc. would be required.

Control Statements

Control statements allow the programmer to branch, both conditionally and unconditionally. They also provide the ability to iterate a section of code based on a condition.

Unconditional Branch (GOTOnnn and M99 Pnnnn)

In the HAAS control, there are two methods of branching unconditionally. An unconditional branch will always branch to a specified block. M99 P15 will branch unconditionally to block number 15. The M99 can be used whether or not macros is installed and is the traditional method for branching unconditionally in the HAAS control. GOTO15 does the same as M99 P15. In the HAAS control, a GOTO command can be used on the same line as other G coding. The GOTO is executed after any other control commands as are traditional M codes.



Computed Branch (GOTO#n and GOTO[expression])

Computed branching allows the program to transfer control to another block in the same subprogram. The block can be computed on the fly, as in the case of the GOTO[expression] form, or the block can be passed in through a local variable, as in the GOTO#n form.

The GOTO will round the variable or expression result that is associated with the Computed branch. For instance, if #1 contains 4.49 and GOTO#1 is executed, the control will attempt to transfer to a block containing N4. If #1 contains 4.5, then execution will transfer to a block containing N5.

The following code skeleton could be developed to make a program that serializes parts:

O9200	(Engrave digit at current location.)
; (D=DECIMAL DIGIT TO ENGRAVE); IF [[#7 NE #0] AND [#7 GE O] AND [#7 LE 9]] GOTO #3000=1	D99; (INVALID DIGIT)
; N99 #7=FIX[#7] :	(TRUNCATE ANY FRACTIONAL PART);
, GOTO#7	(NOW ENGRAVE THE DIGIT) ;
; NO	(DO DIGIT ZERO)
M99	
; N1	(DO DIGIT ONE)
, M99	
; N2	(DO DIGIT TWO)
; (etc.,)	

With the above subroutine, you would engrave digit five with the following call:

G65 P9200 D5;

Computed GOTOs using expression could be used to brach processing based on the results of reading hardware inputs. An example might look like the following:

```
GOTO[[#1030*2]+#1031] ;
NO (1030=0, 1031=0) ;
M99;
N1 (1030=0, 1031=1) ;
M99;
N2 (1030=1, 1031=0) ;
M99;
N3 (1030=1, 1031=1) ;
M99;
```





The discrete inputs always return either 0 or 1 when read. The GOTO[expression] will branch to the appropriate G-code based on the state of the two discrete inputs #1030 and #1031.

Conditional Branch (IF and GOTOn)

Conditional branching allows the program to transfer control to another section of code within the same subroutine. Conditional branching can only be used when macros are enabled. The HAAS control allows two similar methods for accomplishing conditional branching.

IF [<conditional expression>] GOTOn

Here, as discussed above, <conditional expression> is any expression that uses the six Boolean operators EQ, NE, GT, LT, GE, or LE. The brackets surrounding the expression are mandatory. In the HAAS control, it is not necessary to include these operators. For example:

IF [#1 NE 0.0] GOTO5;

could also be:

IF [#1] GOTO5 ;

In this statement, if the variable #1 contains anything but 0.0, or the undefined value #0, then branching to block 5 will occur; otherwise, the next block will be executed. If portability to a control other than HAAS is desired, then it is recommended that the conditional operators be used.

In the HAAS control, a conditional expression can also be used with the M99 Pnnnn format, providing that macros have been enabled. An example is as follows:

G0 X0 Y0 [#1EQ#2] M99 P5;

Here, the conditional is for the M99 portion of the statement only. The machine tool is instructed to X0, Y0 whether or not the expression evaluates to TRUE or FALSE. Only the branch, M99, is executed based on the value of the expression. It is recommended that the IF GOTO version is used if portability is desired.

Conditional Execution (IF THEN)

Execution of control statements can also be achieved by using the IF THEN construct. The format is:

IF [<conditional expression>] THEN <statement>;

NOTE: To preserve compatibility with FANUC syntax "THEN" may not be used with GOTOn.

This format is traditionally used for conditional assignment statements such as:

IF [#590 GT 100] THEN #590=0.0;

Here, variable #590 is set to zero when the value of #590 exceeds 100.0. In the HAAS control, if a conditional evaluates to FALSE (0.0), then the remainder of the IF block is ignored. This means that control statements can also be conditioned so that we could write something like:

IF [#1 NE #0] THEN G1 X#24 Y#26 F#9 ;

This executes a linear motion only if variable #1 has been assigned a value. You might try something like this:

IF [#1 GE 180] THEN #101=0.0 M99;

This says that if variable #1 (address A) is greater than or equal to 180, then set variable #101 to zero and return from the subroutine.

Here is an example of an IF statement that branches if a variable has been initialized to contain any value. Otherwise, processing will continue and an alarm will be generated. Remember, when an alarm is generated, program execution is halted.

N1 IF [#9NE#0] GOTO3 (TEST FOR VALUE IN F); N2 #3000=11(NO FEED RATE); N3 (CONTINUE);

Iteration/Looping (WHILE DO END)

Essential to all programming languages is the ability to execute a sequence of statements a given number of times or to loop through a sequence of statements until a condition is met. Traditional G coding allows this with the use of the L address. A subroutine can be executed any number of times by using the L address.

M98 P2000 L5;

This is limited since you can not terminate execution of the subroutine on condition. Macros allows more flexibility with the WHILE-DO-END construct. The syntax is as follows:

WHILE [<conditional expression>] DOn ; <statements> ; ENDn ;

This executes the statements between DOn and ENDn as long as the conditional expression evaluates to TRUE. The brackets in the expression are necessary. If the expression evaluates to FALSE, then the block after ENDn is executed next. WHILE can be abbreviated to WH. The DOn-ENDn portion of the statement is a matched pair. The value of n is 1..3. This means that there can be no more than three nested loops per subroutine. A nest is basically a loop within a loop. A good example of how nesting of WHILE loops can be used is in defining a matrix.

```
#101= 3;
#102= 4;
G0 X#101 Y4.;
F2.5;
WH [ #101 GT 0 ] DO1;
#102= 4;
WH [ #102 GT 0 ] DO2;
G81 X#101 Y#102 Z-0.5;
#102= #102 - 1;
END2;
#101= #101 - 1;
END1;
```

M30;

This program drills a 3 x 4 matrix hole pattern.

Although nesting of WHILE statements can only be nested to three levels, there really is no limit since each subroutine can have up to three levels of nesting. If there ever is a need to nest to a level greater than 3, then the segment containing the three lowest levels of nesting can be made into a subroutine thus overcoming the limitation.





If two separate WHILE loops are in a subroutine, they can use the same nesting index. For example:

#3001=0 (WAIT 500 MILLISECONDS) ; WH [#3001 LT 500] DO1 ; END1 ;

<other statements>
#3001=0 (WAIT 300 MILLISECONDS);
WH [#3001 LT 300] DO1;
END1;

This is valid code.

You can use GOTO to jump out of a region encompassed by a DO-END, but you can not use a GOTO to jump into it. Jumping around inside a DO-END region using a GOTO is allowed.

An infinite loop can be executed by eliminating the WHILE and expression. Thus,

DO1 ; <statements> END1 ;

Executes until the RESET key is pressed.

CAUTION! The following code can be confusing:

WH [#1] D01 ; END1 ;

In the above, an alarm results indicating no "then" was found, here "then" refers to the D01. Change D01 (zero) to D01 (letter O).

Communication With External Devices - DPRNT[]

Macros allow additional capabilities to communicate with peripheral devices. One can do digitizing of parts, provide runtime inspection reports, or synchronize controls with user provided devices. The commands provided for this are POPEN, DPRNT[] and PCLOS.

Communication preparatory commands

POPEN and PCLOS are not required on the HAAS mill. It has been included so that programs from different controls can be ported to the HAAS. On some controls POPEN is required prior to using a DPRNT statement. POPEN prepares the device on the serial port by sending it a DC2 code. PCLOS terminates communication with external devices by sending it a DC4 code.

Formatted output

The DPRNT statement allows the programmer to send formatted text to the serial port. Any text and any variable can be printed to the serial port. Variables can be formatted. The form of the DPRNT statement is as follows:

DPRNT[<text> <#nnnn[wf]>...] ;

DPRNT must be the only command in the block. In the above, <text> is any character from A to Z or the letters (+,-,/,*, and the space). When an asterisk is output, it is converted to a space. The <#nnnn[wf]> is a variable followed by a format. The variable number can be any legal macro variable. The format [wf] is required and consists of two digits within square brackets. Remember that macro variables are real numbers with a whole part and a fractional part. The first digit in the format designates the total places reserved in the output for the whole part. The second digit designates the total places reserved for the fractional part. The total places reserved for output cannot be equal to zero or greater that eight. Thus the following formats are illegal:

[00] [54] [45] [36] /* not legal formats */

Operator's Manual



A decimal point is printed out between the whole part and the fractional part. The fractional part is rounded to the least significant place. When zero places are reserved for the fractional part, then no decimal point is printed out. Trailing zeros are printed as necessary if there is a fractional part. At least one place is reserved for the whole part, even when a zero is used there. If the value of the whole part has fewer digits than have been reserved, then leading spaces are output. If the value of the whole part has more digits than has been reserved, then the field is expanded so that these numbers are printed.

A carriage return is sent out after every DPRNT block.

DPRNT[] Examples	
Code	Output
N1 $\#1 = 1.5436$;	
N2 DPRNT[X#1[44] Z#1[03] T#1[40]];	X 1.3436 Z 1.344 T T MEASURED INSIDE DIAMETER
N4 DPRNT[]:	(no text, only a carriage return)
N5 #1=123.456789;	(
N6 DPRNT[X-#1[25]];	X-123.45679;
-	
EVECUTION	

DPRNT statements are executed at block interpretation time. This means that the programmer must be careful about where the DPRNT statements appear in the program, particularly if the intent is to print out positional information. Generally, a program is interpreted many blocks ahead in order to prevent the machine from pausing between movements.

G103 is useful for limiting lookahead. If you wanted to limit lookahead interpretation to one block, you would include the following command at the beginning of your program: (This actually results in a two block lookahead.)

G103 P1;

To cancel the lookahead limit, then issue a G103 P0 ;. G103 can not be used when cutter compensation is active.

OPERATION **N**OTES

This section explains the additional screens and operator actions that come with macros.

Macro variables can be saved and restored to RS-232 or the optional floppy, much like parameters, settings, and offsets. Refer to the "Part Program Input / Output" section for RS-232 sending and receiving of macro variables, or the "Floppy Operation" section for sending and receiving them with this method.

Variable Display Page

The macro variables are displayed and can be modified through the current commands display. The variable display is located after the operation timers display. To get to this page, press CURNT COMDS and use the page up/down key.

As the control interprets a program, the variable changes are displayed on the variable display page and results can be viewed.

Pages contain up to 32 variables and the display can be "paged" by pressing the left/right arrow keys.

Setting of a variable is accomplished by entering a value and then pressing the WRITE key. The variable that is highlighted on the screen is the variable that is affected.



Searching for a variable can be done by entering the variable number and pressing the up/down arrow. The page will change to the one that contains that variable and the entered variable will become the highlighted item.

The variables displayed represent the values of the variables at program interpretation time. At times, this may be up to 15 blocks ahead of the actual machine activity. Debugging of programs can be made easier by inserting a G103 at the beginning of a program to limit block buffering and then removing the G103 block after debugging is completed.

Editing

For the most part, the editing of macro programs from the control is the same as before. There are a few peculiarities to be aware of.

Editing macro statements is more open than previously. For instance, it is possible to place a floating point constant within a standard G-code block, but it doesn't make much sense, and the control will raise an alarm at runtime. For all instances of improperly structured or improperly placed macro statements, the control will raise an appropriate alarm. Most of these alarms have been put off until runtime so that operator editing can be more flexible. Be careful when editing expressions. Brackets must be balanced and you will not receive an alarm until runtime.

The DPRNT[] function can be edited much like a comment. You can delete it or move it as a whole item, or you can edit individual items within the brackets. Variable references and format expressions must be altered as a whole entity. If you wanted to change [24] to [44], place the cursor so that [24] is highlighted, enter [44] and press the write key. Remember, you can use the crank handle to maneuver through long

DPRNT[] expressions.

Addresses with expressions can be somewhat confusing. In this case, the alphabetic address stands alone. For instance, the following block contains an address expression in X:

G1 G90 X [COS[90]] Y3.0 (CORRECT) ;

Here, the **X** and brackets stand alone and are individually editable items. It is possible, through editing, to delete the entire expression and replace it with a floating point constant.

G1 G90 X 0 Y3.0 (!!! WRONG !!!);

The above block will result in an alarm at runtime. The correct form looks as follows:

G1 G90 X0 Y3.0 (CORRECT);

Note that the zero is attached to **X**. REMEMBER when you see an alpha character standing alone it is an address expression.

FANUC-STYLE MACRO FEATURES NOT INCLUDED IN HAAS CNC CONTROL

This section lists the FANUC macro features that have not yet been implemented.

MALIASING	REPLACE G65 Pnnnn V	VITH Mnn PROGS 9020-9029.	
G66	MODAL CALL IN EVERY MOTION BLOCK		
G66.1	MODAL CALL IN EVER	Y BLOCK	
G67	MODAL CANCEL		
M98	ALIASING, T CODE	PROG 9000, VAR #149, ENABLE BIT	
M98	ALIASING, S CODE	PROG 9029, VAR #147, ENABLE BIT	
M98	ALIASING, B CODE	PROG 9028, VAR #146, ENABLE BIT	
SKIP/N	N=19		
#3007	MIRROR IMAGE ON FL	AGEACHAXIS	
#4201-#4320	CURRENT BLOCK MO	DAL DATA	
#5101-#5106	CURRENT SERVO DEV	'IATION	
ADDITIONAL OFFSETS	G54.1P## FORMAT		
NAMES FOR VARIABLES	FOR DISPLAY PURPOS	SES	
ATAN []/[]	ARCTANGENT, FANUC	VERSION	
BIN []	CONVERSION FROM E	BCD TO BIN	
BCD[]	CONVERSION FROM E	BIN TO BCD	
FUP[]	TRUNCATE FRACTION	CEILING	
LN []	NATURAL LOGARITHM		
EXP[]	BASE E EXPONENTIAT	ION	
ADP []	RE-SCALE VAR TO WH	IOLE NUMBER	
BPRNT []			

The following can be used as alternative methods for achieving the same results for a few unimplemented FANUC macro features.

GOTO-nnnn

Searching for a block to jump in the negative direction, i.e. backwards through a program, is not necessary if you use unique N address codes.

A block search is made starting from the current block being interpreted. When the end of the program is reached, searching continues from the top of the program until the current block is encountered.





4. G CODES (PREPARATORY FUNCTIONS)

The following is a summary of the **G** codes. A "*" indicates the default within each group, if there is one.

Code:	Group:	Function:	Description On Page:
G00	01*	Rapid Motion	195
G01	01	Linear Interpolation Motion	196
G02	01	CW Interpolation Motion	198
G03	01	CCW Interpolation Motion	198
G04	00	Dwell	198
G09	00	Exact Stop	198
G10	00	Set Offsets	199
G12	00	CW Circular Pocket Milling (Yasnac)	199
G13	00	CCW Circular Pocket Milling (Yasnac)	200
G17	02*	XY Plane Selection	202
G18	02	ZX Plane Selection	203
G19	02	YZ Plane Selection	203
G20	06*	Select Inches	203
G21	06	Select Metric	203
G28	00	Return To Reference Point	204
G29	00	Return From Reference Point	204
G31	00	Feed Until Skip (optional)	205
G35	00	Automatic Tool Diameter Measurement (optional)	205
G36	00	Automatic Work Offset Measurement (optional)	206
G37	00	Automatic Tool Offset Measurement (optional)	205
G40	07*	Cutter Comp Cancel	206
G41	07	2D Cutter Compensation Left	206
G42	07	2D Cutter Compensation Right	206
G43	08	Tool Length Compensation +	207
G44	08	Tool Length Compensation –	207
G47	00	Text Engraving	207
G49	08*	G43/G44/G143 Cancel	207
G50	11	G51 Cancel	212
G51	11	Scaling (optional)	212
G52	12	Set Work Coordinate System G52 (Yasnac)	217
G52	00	Set Local Coordinate System G52 (Fanuc)	217
G52	00	Set Local Coordinate System (HAAS)	217
G53	00	Non-Modal Machine Coordinate Selection	217
G54	12*	Select Work Coordinate System 1	217
G55	12	Select Work Coordinate System 2	217
G56	12	Select Work Coordinate System 3	217
G57	12	Select Work Coordinate System 4	217
G58	12	Select Work Coordinate System 5	217
G59	12	Select Work Coordinate System 6	217
G60	00	Unidirectional Positioning	217
G61	13	Exact Stop Modal	217
G64	13*	G61 Cancel	217
G65	00	Macro Subroutine Call (optional)	170
G68	16	Rotation (optional)	214
G69	16	G68 Cancel (optional)	216
G70	00	Bolt Hole Circle (Yasnac)	218



G71	00	Bolt Hole Arc (Vasnac)	218
C72	00	Bolt Holes Along on Angle (Yeenee)	210
072	00	Link Sneed Deak Drill Conned Cycle	210
G73	09	Right Speed Peck Dhill Canned Cycle	220
G/4	09	Reverse Tap Canned Cycle	222
G/6	09	Fine Boring Canned Cycle	223
G77	09	Back Bore Canned Cycle	224
G80	09*	Canned Cycle Cancel	224
G81	09	Drill Canned Cycle	224
G82	09	Spot Drill Canned Cycle	226
G83	09	Normal Peck Drill Canned Cycle	227
G84	09	Tapping Canned Cycle	228
G85	09	Boring Canned Cycle	230
G86	09	Bore/Stop Canned Cycle	230
G87	09	Bore/Stop/Manual Retract Canned Cycle	231
G88	09	Bore/Dwell/Manual Retract Canned Cycle	231
G89	09	Bore/ Dwell Canned Cycle	232
G90	03*	Absolute	232
G91	03	Incremental	232
G07	00	Set Work Coordinates - FANILIC or HAAS	202
C02	00	Set Work Coordinates - TANGC OF HAAS	202
G92	00	Set Work Coordinates - FASNAC	200
G93	05		233
G94	05"	Feed Per Minute Mode	233
G98	10^	Initial Point Return	234
G99	10	R Plane Return	234
G100	00	Cancel Mirror Image	234
G101	00	Enable Mirror Image	234
G102	00	Programmable Output To RS-232	238
G103	00	Limit Block Buffering	238
G107	00	Cylindrical Mapping	239
G110	12	Select Work Coordinate System 7	242
G111	12	Select Work Coordinate System 8	242
G112	12	Select Work Coordinate System 9	242
G113	12	Select Work Coordinate System 10	242
G114	12	Select Work Coordinate System 11	242
G115	12	Select Work Coordinate System 12	242
G116	12	Select Work Coordinate System 13	242
G117	12	Select Work Coordinate System 14	242
G118	12	Select Work Coordinate System 15	242
G110 G110	12	Select Work Coordinate System 16	242
C120	12	Select Work Coordinate System 10	242
G120	12	Select Work Coordinate System 17	242
GIZI	12	Select Work Coordinate System 10	242
GIZZ	12	Select Work Coordinate System 19	242
G123	12	Select Work Coordinate System 20	242
G124	12	Select Work Coordinate System 21	242
G125	12	Select Work Coordinate System 22	242
G126	12	Select Work Coordinate System 23	242
G127	12	Select Work Coordinate System 24	242
G128	12	Select Work Coordinate System 25	242
G129	12	Select Work Coordinate System 26	242
G136	00	Automatic Work Offset Center Measurement	206
G141	07	3D+ Cutter Compensation	242
G143	08	5 AX Tool Length Compensation (optional)	243
G150	00	General Purpose Pocket Milling	242
G153	09	5-Axis High Speed Peck Drilling Canned Cycle	250

194 -



G154	09	5-Axis Reverse Tap Canned Cycle	251
G161	09	5-Axis Drill Canned Cycle	252
G162	09	5-Axis Spot Drill Canned Cycle	253
G163	09	5-Axis Normal Peck Drilling Canned Cycle	253
G164	09	5-Axis Tapping Canned Cycle	255
G165	09	5-Axis Boring Canned Cycle	255
G166	09	5-Axis Bore and Stop Canned Cycle	256
G169	09	5-Axis Bore and Dwell Canned Cycle	257
G174	00	CCW General Rigid Tap	257
G184	00	CW General Rigid Tap	257
G187	00	Accuracy Control for High Speed Machining	258

Each G code defined in this control is part of a group of G codes. The Group 00 codes are non-modal; that is, they specify a function applicable only to the block they are in and do not affect other blocks. The other groups are modal and apply to all subsequent blocks until the end of the program or until replaced by a different G code from the same group. A modal G code will remain in effect until another G code from the same group is specified.

There is also one case where the Group 01 G codes will cancel the Group 09 (canned cycles) codes. If a canned cycle (G73 through G89) is active, the use of G00 or G01 will cancel the canned cycle.

The control will now store up to 500 G-code programs in memory.

RAPID POSITION COMMANDS (GOO)

G00 Rapid Motion Positioning

- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Optional Z-axis motion command
- A Optional A-axis motion command

This G code is used to cause rapid traverse of the three or four axes of the machine. The auxiliary axes **B**, **C**, **U**, **V**, and **W** can also be moved with G00. This G code is modal, so a block with G00 causes all following blocks to be rapid motion until another Group 01 code is specified. The rapid traverse rate is dependent on the maximum speed possible for each axis independently, as modified by the RAPID OVERRIDE keys.

Generally, rapid motion will not be in a straight line. Each axis specified is moved at the same speed, but all axes will not necessarily complete their motions at the same time. The control will wait until all motions are complete before implementing the next command. Only the axes specified are moved, and the incremental or absolute position commands (G90 or G91) will change how those axis motion values are interpreted. Setting 57 can change how closely the machine waits for a precise stop before and after a rapid move.

Group 01





INTERPOLATION COMMANDS (G01, G02, G03)

G01 Linear Interpolation Motion

F Feedrate in inches (mm) per minute

- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Optional Z-axis motion command
- A Optional A-axis motion command
- ,R Radius of the circle
- ,C Distance from center of intersection where the chamfer begins

This G code provides for straight line (linear) motion from point to point. Motion can occur in 1, 2 or 3 axes. All axes will start and finish motion at the same time. The rotary axis may also be commanded with G01, providing helical motion. The speed of all axes is controlled so that the feedrate specified is achieved along the actual path. Rotary axis feedrate (helical motion) is dependent on the rotary axis diameter setting (Setting 34). The **F** command is modal and may be specified in a previous block. Only the axes specified are moved and the incremental or absolute position commands (G90 or G91) will change how those values are interpreted. The auxiliary axes **B**, **C**, **U**, **V**, and **W** can also be moved with G01, but only one axis is moved at a time.

Corner Rounding and Chamfering Example

F1.0;	
G17;	
G00 X-10. Y-6. Z-8.;	(Rapid to start point)
G01 X-10.0 Y-11,C1.;	(Chamfer)
G01 X-5. Y-11.,R1.;	(Rounding)
X-5. Y-6.;	(Terminating stroke)
M30;	

A chamfer block or a corner-rounding block can be automatically inserted between two linear interpolation blocks by specifying ,C (chamfering) or ,R (corner rounding). There must be a terminating linear interpolation block following the beginning block (a G04 pause may intervene). These two linear interpolation blocks specify a corner of intersection. If the beginning block specifies a C, the value following the C is the distance from the intersection to where the chamfer begins, and also the distance from the intersection to where the chamfer begins, and also the distance from the intersection to where the chamfer begins, and also the distance from the intersection to where the chamfer begins, and also the distance from the intersection to where the chamfer begins, and also the distance from the intersection to where the chamfer begins, and also the distance from the intersection to where the chamfer begins, and also the distance from the intersection to where the chamfer begins, and also the distance from the intersection to where the chamfer ends. If the beginning block specifies an R, the value following the R is the radius of a circle tangent to the corner at two points: the beginning of the corner-rounding arc and the endpoint of that arc. There can be consecutive blocks with chamfering or corner-rounding specified. There must be movement on the two axes specified by the selected plane, whether the active plane is **XY** (G17), **XZ** (G18) or **YZ** (G19).

G02 CW Circular Interpolation Motion

- F Feedrate in inches (mm) per minute
- I Optional distance along X axis to center of circle
- J Optional distance along Y axis to center of circle
- K Optional distance along Z axis to center of circle
- R Optional radius of circle
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Optional Z-axis motion command
- A Optional A-axis motion command

This G code is used to specify clockwise circular motion of two linear axes. Circular motion is possible in any two of the **X**, **Y**, and **Z** axes as selected by G17, G18, and G19. The **X**, **Y**, and **Z** commands specify the end point of the motion, which may be either absolute (G90) or incremental (G91) motion. If the **X**, **Y**, or **Z** location for the selected plane is not specified, the endpoint of the arc is the same as the starting point for that axis. There are two ways to specify the center of the circular motion; the first uses **I**, **J**, or **K** to specify the distance from the starting point to the center of the arc, and the second uses **R** to specify the radius of the arc (maximum 7740. inches). These are further described below.

Group 01





I, **J**, **K**: When **I**, **J**, or **K** is used to specify the center of the arc, **R** may not be used. Only the **I**, **J**, or **K** specific to the selected plane (IJ for G17, IK for G18, JK for G19) is allowed. If only one of the **I**, **J**, **K** values is specified, the others are assumed to be zero. The **I**, **J**, or **K** value is the signed distance from the starting point to the center of the circle. Small errors in these values are tolerated, up to 0.0010 inch. Use of **I**, **J**, or **K** is the only way to cut a complete 360-degree arc; in this case, the starting point is the same as the ending point and no **X**, **Y**, or **Z** value is needed.

To cut a complete circle of 360 degrees (360°), you do not need to specify an ending point **X**, **Y**, or **Z**; just program I, J, or **K** to define the center of the circle. The following line will cut a complete circle:



G02 I3.0 J4.0 (Assumes G17; XY plane)

In cases where you are cutting less than a complete circle, it is much easier to use R instead of I, J, K.

R: When **R** is used to specify the center of the circle, a complete 360-degree arc is not possible. An **X**, **Y**, or **Z** value is required to specify an endpoint different from the starting point. **R** is the distance from the starting point to the center of the circle. With a positive **R**, the control will generate a path of 180 degrees or less; to generate an angle of more than 180 degrees, specify a negative **R**. Small errors in this value are tolerated, up to 0.0010 inch.



The following lines will cut an arc less than 180 degrees (180°):



G01 X3.0 Y4.0 G02 X-3.0 R5.0

and the following lines will cut an arc of more than 180 degrees (180°):

G01 X3.0 Y4.0 G02 X-3.0 R-5.0

G03 CCW Circular Interpolation Motion

G03 will generate counterclockwise circular motion but is otherwise the same as G02.

HELICAL

Helical motion is possible with G02 or G03 by programming the linear axis that is not in the selected plane. This third axis will be interpolated along the specified axis in a linear manner, while the other two axes will be moved in the circular motion. The speed of each axis will be controlled so that the helical rate matches the programmed feedrate.

Miscellaneous G Codes (G04, G09)

G04 Dwell

P The dwell time in seconds or milliseconds

G04 is used to cause a delay or dwell in the program. The block containing G04 will delay for the time specified by the **P** code. If **P** has no fractional part, the delay is in milliseconds (0.001 second); otherwise the delay is in seconds.

G09 Exact Stop

The G09 code is used to specify an exact stop. It is non-modal and does not affect the following blocks. Rapid and interpolated moves will decelerate to an exact stop before another block is processed. In exact stop, moves will take longer and continuous cutter motion will not occur. This may cause deeper cutting where the tool stops.

Group 01

Group 00

Group 00



Group 00

Programmable Offset Setting (G10)

G10 Set Offsets

- L Selection of length, length wear, diameter, diameter wear, or work coordinates.
- P Selection of offset number.
- R Offset value or increment for length and diameter.
- X Optional X-axis zero location.
- Y Optional Y-axis zero location.
- Z Optional Z-axis zero location.
- A Optional A-axis zero location.

G10 can be used to change the tool length and work offsets from inside a program. The following codes are used for selection of offsets:

L2	Work coordinate origin for G52 and G54-G59
L10	Length offset amount (for H code)
L1 or L11	Tool wear offset amount (for H code)
L12	Diameter offset amount (for D code)
L13	Diameter wear offset amount (for D code)
L20	Auxiliary work coordinate origin for G110-G129

The **P** code is used to index the appropriate offsets.

P1-P100	Used to reference D or H code offsets	L10-L13
P0	G52 references work coordinate	L2
P1-P6	G54-G59 references work coordinates	L2
P1-P20	G110-G129 references auxiliary coordinates	L20

The **R**, **X**, **Y**, **Z**, and **A** codes are signed, fractional numbers in inches (or mm). The **R**, **X**, **Y**, **Z**, and **A** values are absolute or incremental, depending on the current G90/G91 mode.

G10 Examples:

G1 G1 G1 G1	0	L2 L20 L10 L12	P1 P2 G90 G90	G91 G90 P5 P5	X6.0 X10. R2.5 R.375	Y8.	{Move coordinate G54 6.0 to the right}; {Set work coordinate G111 to X10.0, Y8.0}; {Set offset for Tool #5 to 2.5}; {Set diameter for Tool #5 to 3/8"}:
GI	0	LI2	G90	P5	R.3/5		{Set diameter for 1001 #5 to 3/8 };

CIRCULAR POCKET MILLING (G12, G13)

There are two G codes that will provide for pocket milling of a circular shape. They are different only in which direction of rotation is used. Both are functional only in the default XY circular plane (G17).

G12 Circular Pocket Milling Clockwise

- *D Tool radius or diameter selection
 - I Radius of first circle (or finish if no K)
 - K Radius of finished circle (if specified)
 - L Loop count for repeating deeper cuts
 - Q Radius increment (must be used with K)
 - F Feedrate in inches (mm) per minute
 - Z depth of cut or increment

*In order to get the exact programmed circle diameter, the control uses the selected D code tool size. If this compensation is not desired, program D0.

This G code implies the use of G42.

Group 00





June 2002

The tool must be positioned at the center of the circle, either in a previous block or in this block using **X** and **Y**. The cut is performed entirely with circular motions of varying radius. To remove all the material within the circle, use I and Q values less than the tool diameter and a K value equal to the circle radius. To cut a circle radius only, use an I value set to the radius and no K or Q value. G12 belongs to Group 00 and thus is non-modal. If G91 (incremental) is specified and an L count is included, the Z increment is repeated L times at feedrate **F**.

G13 Circular Pocket Milling Counterclockwise

Group 00

This G code implies the use of G41 and is otherwise similar to G12. G13 is Group 00 and thus is non-modal.

% O00098(SAMPLE G12 AND G13) (OFFSET D01 SET TO APPROX. TOOL SIZE) (TOOL MUST BE MORE THAN Q IN DIAM.) T1M06 G54G00G90X0Y0 (Move to center of G54) G43Z0.1H01 S2000M03 G12I1.5F10.Z-1.2D01 (Finish pocket clockwise) G00Z0.1 G55X0Y0 (Move to center of G55) G12I0.3K1.5Q0.3F10.Z-1.2D01 (Rough and finish clockwise) G00Z0.1 G56X0Y0 (Move to center of G56) G13I1.5F10.Z-1.2D01 (Finish pocket counterclockwise) G00Z0.1 G57X0Y0 (Move to center of G57) G13I0.3K1.5Q0.3F10.Z-1.2D01 (Rough and finish counterclockwise) G00Z0.1 G28 M30 %









CIRCULAR POCKET MILLING

The control software includes a Yasnac-style circular pocket milling program (G12, Clockwise Circular Pocket; G13, Counterclockwise Pocket). These G codes assume the use of cutter compensation, so a G41 or G42 is not required in the program line. However, a D offset number, for cutter radius or diameter, is required to adjust the circle diameter.

In this section, we will cover the G12 and G13 format, as well as the different ways these programs can be written for various applications:

SINGLE PASS: Use I only.

APPLICATIONS: One-pass counterboring; rough and finish pocketing of smaller holes; ID keyway cutting; O-ring grooves.

MULTIPLE PASS: Use I, K, and Q.

APPLICATIONS: Multiple-pass counterboring; rough and finish pocketing of large holes with cutter overlap.

MULTIPLE Z-DEPTH PASS: Using I only, or I, K, and Q (G91 and L may also be used).

APPLICATIONS: Deep rough and finish pocketing; incremental Z depth stepping.

NOTE: The tool must be positioned at the center of the circle, either in a previous block or in the G12/G13 line, by using **X** and **Y**.

The previous figures show the tool path during the G12 and G13 cycles. One uses I only and the other uses I, K, and Q.

EXAMPLE G13 single-pass using I only:

PROGRAM EXAMPLE

% O2000 T1 M06 G00 G90 G54 X0 Y0 S4000 M03 G43 H01 Z.1 M08 G13 Z-1.0 F20. D01 I.500 G00 Z1.0 M09 G28 G91 Y0 Z0 M30 %

DESCRIPTION

(0.500 entered in the Radius/Diameter offset column) (Tool #1 is a 0.500" diameter endmill)

(Will complete a 1-inch diameter hole 1 inch deep) Odeep)





EXAMPLE G13 multiple-pass using I, K, and Q:

This example will complete a 3-inch diameter hole, 1 inch deep, with a cutter overlap of 0.100 inch.

PROGRAM EXAMPLE

DESCRIPTION

% O3000 T1 M06 G00 G90 G54 X0 Y0 S4000 M03 G43 H01 Z.1 M08 G13 Z-1.0 I.400 K1.5 Q.400 D01 F20. G00 Z1.0 M09 G28 G91 Y0 Z0 M30 %

(0.500 entered in the Radius/Diameter offset column) (Tool #1 is a 0.500" diameter endmill)

EXAMPLE G13 multiple-pass using I, K, Q, L, and G91:

This program uses G91 and an L count of 4, so this cycle will execute a total of four times. The Z depth increment is 0.500. This is multiplied by the L count, making the total depth of this hole 2.000.

The G91 and L count can also be used in a G13 "I only" line.

PROGRAM EXAMPLE

DESCRIPTION

% O4000 T1 M06 G00 G90 G54 X0 Y0 S4000 M03 G43 H01 Z.1 M08 G01 Z0 F10. G13 G91 Z-.5 I.400 K2.0 Q.400 L4 D01 F20. G00 G90 Z1.0 M09 G28 G91 Y0 Z0 M30 %

(0.500 entered in the Radius/Diameter offset column) (Tool #1 is a 0.500" diameter endmill)

CIRCULAR PLANE SELECTION (G17, G18, G19)

The plane used for circular motions must consist of two of the three axes X, Y, and Z. One of three G codes used to select the plane: G17 for XY, G18 for XZ, and G19 for YZ. Each are modal and apply to all subsequent circular motions until another Group 02 code is found.

G17 **XY Plane Selection**

The G17 code is used to select the XY plane for circular motion. It is modal and applies to all circular motions until another Group 02 command is programmed. In this plane, circular motion is defined as clockwise for the operator looking down onto the XY table from above. This defines the motion of the tool relative to the table.

Group 02

NOTE: If the geometry column of the control Offsets display has a value inserted, the circular pocket milling cycle will automatically read the data, regardless of whether D0 is present or not. The only effective way to cancel cutter compensation for pocket milling is to insert a D00 in the program line. This will bypass the value in the Offsets geometry column.



G18 XZ Plane Selection

The G18 code is used to select the XZ plane for circular motion. It is modal and applies to all circular motions until another Group 02 command is programmed. In the XZ plane, circular motion is defined as clockwise for the operator looking from the rear of the machine toward the front control panel.

G19 YZ Plane Selection

Group 02

Group 02

The G19 code is used to select the YZ plane for circular motion. It is modal and applies to all circular motions until another Group 02 command is programmed. In the YZ plane, circular motion is defined as clockwise for the operator looking across the table from the side of the machine where the control panel is mounted.

The default plane selection when the machine is powered on is G17, the XY plane. This means that a circular motion in the plane of the XY table may be programmed without first selecting G17. Plane selection also applies to G12 and G13, circular pocket milling, which must always be in the XY plane.

Helical motion is possible with G02 or G03 by programming the linear axis which is not in the selected plane. This third axis will be interpolated along the specified axis in a linear manner while the other two axes will be moved in the circular motion. The speed of each axis will be controlled so that the helical rate matches the programmed feedrate.

If cutter radius compensation is selected (G41 or G42), you may only use the XY plane (G17) for circular motion. Cutter radius compensation is only available in the **X** and **Y** axes.



INCH / METRIC SELECTION (G20, G21)

G20 Select Inches

G21 Select Metric

Group 06 Group 06

The standard G codes G20 and G21 are sometimes used to select between inch and metric, BUT, in the Haas control, the G20 (inch) and G21 (mm) codes can only be used to ensure that the inch/metric setting is set correctly for the program in use. Selection between inch and metric programming can only be done from Setting 9.



REFERENCE **POINT DEFINITION AND RETURN**

G28 Return to Machine Zero Thru Optional G29 Reference Point

Group 00

The G28 code is used to return all axes to machine zero. If an X, Y, Z, or A axis is specified in the same block, only those axes will move, through the location specified to the machine's zero point. Movement to machine zero will be through the specified point after applying the relevant work and tool offsets. This point is called the G29 reference point and is saved for use in G29. If no X, Y, Z, or A is specified, all axes will move directly to machine zero. Any auxiliary axes (B, C, etc.) are returned to home after the X, Y, Z, and A axes. After using the current offsets in moving to machine zero, G28 cancels tool length offsets for subsequent blocks.

Example 1

Work Offset G54: Z = -2.0Tool 2 Length: -12.0

Program segment:

G90 G54; G43 H02; G28 Z0.; G00 Z1.

The G28 block will move to machine coordinate Z = -14.0 before moving to Z = 0. The following block (G00 Z1.) will move to machine coordinate Z = -1.

Example 2

(same work and tool offsets as Example 1)

Program segment:

G91 G54; G43 H02; G28 Z0

The G28 block will move directly to machine coordinate Z = 0 since incremental positioning is in effect.

G29 Return From REFERENCE point

Group 00

The G29 code is used to move the axes to a commanded **X**, **Y**, **Z** or **A** position. The axes selected in this block are moved to the G29 reference point saved or recorded in G28, and then moved to the **X**, **Y**, **Z** or **A** location specified in the G29 command. The positions are interpreted in the current coordinate system.

SKIP FUNCTION (G31)

G31 Feed Until Skip (This G-code is optional and requires a probe)

Group 00

- F Feedrate in inches (mm) per minute
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Optional Z-axis motion command
- A Optional A-axis motion command
- B Optional B-axis motion command

The skip function is a non-modal operation that causes a linear move to the specified **X**, **Y**, **Z**, and/or **A** position. It applies only to the block in which G31 is specified. A feedrate must be defined previously or in this block. The specified move is started and continues until the end point or the skip signal. The skip signal is a discrete input that usually indicates that the end of travel has been reached; this is usually a probe. The control will beep when the end of travel is reached.

Cutter compensation may not be active during a skip function. M78 or M79 may be used to test if the skip signal was received. An M75 can be used to mark the probed point as the reference point for G35 or G136.

AUTOMATIC TOOL MEASUREMENT (G35, G37)

G35 Automatic Tool Diameter Measurement (This G-code is optional and requires a probe)Group 00G37 Automatic Tool Offset Measurement (This G-code is optional and requires a probe)Group 00

- F Feedrate in inches (mm) per minute
- D Tool diameter offset number (G35)
- H Tool offset number (G37)
- Z Required Z-axis offset

Automatic tool offset measurement (G37) is a non-modal operation that causes linear motion of the Z axis until the skip signal is received or the Z travel limit is reached. A non-zero H code must be active, G43 or G44 must be active, a Z value must be specified, and a feedrate must be defined. No X, Y, or A code is allowed. When the move is terminated, the specified Z and the final Z positions are used to set the specified tool offset (Hnnn). The active coordinate system is taken into account.

The coordinate system (G54–G59, G110–G129) and tool length offsets (H01–H200) may be selected in this block or in a previous block. The end point of the **Z** move is controlled only by the machine's travel limits.

The resulting tool offset value is such that a subsequent move to the **Z** value specified in the G37 command will move the tool to the position where the skip signal was sensed. The skip signal is a discrete input that usually indicates that the end of travel has been reached; this is sometimes a probe. Cutter compensation may not be active during a skip function. M78 or M79 may be used to test if the skip signal was received. The resulting tool offset is the offset between the work zero point and the point where the probe is touched.

The automatic tool diameter measurement function (G35) is used to set the tool diameter (or radius) using two different probe passes, one on each side of the tool. The first point is set with a G31 block using an M75, and the second point is set with the G35 block. The distance between these two points is set into the active **Dnnn** value. A nonzero **D** code must be selected. Setting 63 is used to reduce this measurement by the width of the tool probe.



Automatic Work Offset Measurement (G36, G136)

G36 Automatic Work Offset Center Measurement (optional G-code, requires a probe) G136 Automatic Work Offset Center Measurement

SERIES

Group 00 Group 00

- F Feedrate in inches (mm) per minute
- I Optional offset distance along X axis
- J Optional offset distance along Y axis
- K Optional offset distance along Z axis
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Optional Z-axis motion command
- A Optional A-axis motion command

Automatic work offset measurement is a non-modal operation that causes linear motion of the X, Y, Z, and A axes until the skip signal is received or the end of the programmed motion is reached. The X, Y, Z, and A axes are moved to the programmed position in a linear move but will stop early if the skip signal is received. Tool offsets must not be active when this function is performed. M78 or M79 may be used to test if the skip signal was received. The currently active work coordinate system is set for each axis programmed. The point where the skip signal is received becomes the work zero position. The work coordinate system may be selected in this block or in a previous block.

Operator's Manual

The points probed are offset by the values in Settings 59 through 62.

A G36 will set the work coordinates to the point where the probe hits. G136 will set the work coordinates to a point at the center of a line between the probed point and the point set with M75. This allows the center of a part to be found using two separate probed points.

Note that the X, Y, Z, and/or A commands programmed into this block are interpreted in the coordinate system that is about to be set. Thus, the end point of the move will be interpreted within the old work coordinate value. For this reason, it is easier to program these moves as incremental (G91).

If an I, J, or K is specified, the appropriate axis work offset is shifted by the amount in the I, J, or K command. This allows the work offset to be shifted some distance away from where the probe actually hits.

CUTTER COMPENSATION (G40, G41, G42)

G40 Cutter Comp Cancel

G40 will cancel G41 or G42 cutter compensation. Programming a D00 will also cancel cutter compensation.

G41 2D Cutter Compensation Left

G41 will select cutter compensation left; that is, the tool is moved to the left of the programmed path to compensate for the size of the tool. A **Dnnn** must also be programmed to select the correct tool size from compensation memory. If compensation memory contains a negative value for cutter size, cutter compensation will operate as though G42 was specified.

G42 2D Cutter Compensation Right

G42 will select cutter compensation right; that is, the tool is moved to the right of the programmed path to compensate for the size of the tool. A **Dnnn** must also be programmed to select the correct tool size from compensation memory. If compensation memory contains a negative value for cutter size, cutter compensation will operate as though G41 was specified.

///\/\5

Refer to the "Cutter Compensation" section for more information.

Group 07

Group 07

Group 07

Tool Length Compensation (G43, G44, G49)

G43 Tool Length Compensation + (plus)

This code selects tool length compensation in a positive direction. That is, the tool length offsets are added to the commanded axis positions. A nonzero **Hnnn** must be programmed to select the correct entry from offset memory. The automatically entered offsets using the TOOL OFSET MESUR key assume that G43 is being used.

G44 Tool Length Compensation – (minus)

This code selects tool length compensation in a negative direction. That is, the tool length offsets are subtracted from the commanded axis positions. A nonzero **Hnnn** must be programmed to select the correct entry from offsets memory.

G49 G43/G44/G143 Cancel

This **G** code cancels tool length compensation. Putting in an H0 will also cancel tool length compensation. G28, M30, and RESET will also cancel tool length compensation.

ENGRAVING (G47)

G47 Text Engraving

Will not work with G91 (incremental positioning)

- E = Plunge rate (units/min)
- F = Engraving feedrate (units/min)
- Angle of rotation (-360. to +360.); default is 0
- J = Scaling factor in inches (minimum = 0.001 inch); default is 1.0 inch
- P = **1** for sequential serial number engraving
 - 0 for literal string engraving
- R = Return plane
- X = X start of engraving
- Y = Y start of engraving
- Z = Depth of cut

The text to engrave should be in the form of a comment on the same line as the G47 command, with either a P1 or P0 before it. P1 selects sequential serial number engraving and P0 selects literal string engraving.

SEQUENTIAL SERIAL NUMBER ENGRAVING

This method is used to engrave numbers incrementally on a series of parts, with the number being increased by one each time. The # symbol is used to select the number of digits in the serial number. For example:

G47 P1 (####)

will limit the serial number to four digits.

The initial serial number can either be programmed or set manually. For example, if it is programmed:

G47 P1 (1234)

will set the initial serial number to "1234."

Group 08

Group 08

Group 08




The initial serial number can also be set manually into a macro variable. The Macros option does not have to be enabled to do this. Macro variables are temporary storage locations for numbers. Macro variable #599 is used to hold the initial serial number to be engraved. To set this variable, go to the CURNT COMDS page and press the PAGE DOWN key until the "Macro Variables" page appears. Then type in "599" and press the common of the desired initial serial number at the cursor and press the WRITE/ENTER key. For example, when macro variable #599 is set to "1234,"

G47 P1 (####)

will produce this:

1234

If the number in macro variable #599 has more characters than specified in the format string, only the quantity specified will be printed. For example, if #599 is set to "12345" and only four places are specified in the format string, only "2345" will be engraved.

LITERAL STRING ENGRAVING

This method is used to engrave desired text on a part. The characters available for engraving are:

A-Z a-z 0-9, !"#\$%&'()*+,-./:;<=>?[\]^ {}

Not all of these characters can be entered at the control. However, programs downloaded through the serial port or the floppy drive can take advantage of characters not available on the mill keypad.

For literal string engraving, the text should be in the form of a comment on the same line as the P0 statement. For example:

G47 P0 (ENGRAVE THIS)

will produce

ENGRAVE THIS

Note that P0 is used, instead of P1, for literal string engraving.

EXAMPLE

This example will create the figure shown.

G47 P0 X2.0 Y2.0 I45. J.5 R.05 Z-.005 F15.0 E10.0 (TEXT TO ENGRAVE)





In this example:

G47 P0	select literal string engraving
X2.0 Y2.0	select 2.0, 2.0 as the starting point for the text.
145.	places the text at a positive 45-degree angle
J.5	sets the text height to 0.5 inch
R.05	commands the cutter to retract to 0.05 inch (mm) above the cutting plane after engraving
Z005	selects a 0.005 inch (mm) deep cut
F15.0	selects an engraving feedrate of 15 units/min
E10.0	commands the cutter to plunge at a rate of 10 units/min

The milling strokes defining each character, i.e., the font, are compiled G-code in the HAAS control. The font characters may be redefined by supplying a different G-code program, giving it the name O9876. This program must conform to the format expected by the HAAS control. For guidance, some of the code from the built-in font program is shown below. The example below may be used as a template. Code should be written exactly as shown.





Example O9876 G-Code Program

% O9876 (Engraving) #700= #4003 #701=#4001 G00 X#24 Y#25 Z#18 #702= #5003 - #26 IF [#9 EQ #0] #9= #4109 IF [#8 EQ #0] #8= #9 G91 IF [#4 EQ #0] #4= 0.0 IF [#5 EQ #0] #5= 1.0 G68 R#4 G51 P [#5 * 1000] N1000 M97 GOTO1000 N125 M99 (SPACE) N126 G00 X0.864 F#8 M99 N127 G#700 G#701 M99 N1 (!) G00 X0.2692 G01 Z - #702 F#8 G03 J0.0297 F#9 G00 Z#702 G00 Y0.2079 G01 Z - #702 F#8 G01 X0.0495 Y0.6732 F#9 G03 X-0.099 R0.0495 G01 X0.0495 Y-0.6732 G00 Z#702 G00 X0.2692 Y-0.2079 M99 N2 («) G00 X0.2345 Y0.792 G01 Z - #702 F#8 G01 X0.0148 Y0.198 F#9 G01 X-0.0297

Comments

% marks the start of the program. The program number must be 9876. Save G90/G91 Save G00/G01 etc.

If R, move there with user's G90/G91

Use present F if none specified If no E, use F All incremental from here on

M97 auto M99 at end of string

This section mills a space.

Restore G90/G91 Restore G00/G01 etc.

This section mills an exclamation point

This section mills double quotes.

G01 X0.0148 Y-0.198 G00 Z#702 G00 X0.1485 G01 Z - #702 F#8 G01 X0.0148 Y0.198 F#9 G01 X-0.0297 G01 X0.0148 Y-0.198 G00 Z#702 G00 X0.2346 Y-0.792 M99 N3 This section mills a # sign. (#) G00 X0.4082 Y0.1666 G01 Z - #702 F#8 G01 X0.0433 Y0.8086 F#9 G00 Z#702 G00 X0.2627 Y0.0148 G01 Z - #702 F#8 G01 X-0.0433 Y-0.8234 F#9 G00 Z#702 G00 X0.2194 Y0.2374 G01 Z - #702 F#8 G01 X-0.6676 F#9 G00 Z#702 G00 X0.0155 Y0.319 G01 Z - #702 F#8 G01 X0.6614 F#9 G00 Z#702 G00 X0.2167 Y-0.723 M99 ...

%

% marks the end of the program.

For the creation of each character, there is a different label to start the code. Each section terminates with an M99.

Label	N126	N1	N2	N3	N4	N5	N6	N7	N8	N9
Character	space	!	"	#	\$	%	&	'	()
Label	N10	N11	N12	N13	N14	N15	N16	N17	N18	N19
Character	*	+	,	-		/	0	1	2	3
Label	N20	N21	N22	N23	N24	N25	N26	N27	N28	N29
Character	4	5	6	7	8	9		;	,	=
Label	N30	N31	N32	N33	N34	N35	N36	N37	N38	N39
Character	>	?	@	A	B	C	D	E	F	G
Label	N40	N41	N42	N43	N44	N45	N46	N47	N48	N49
Character	H	I	J	K	L	M	N	O	P	Q
Label	N50	N51	N52	N53	N54	N55	N56	N57	N58	N59
Character	R	S	T	U	V	W	X	Y	Z	[

F Operator's Manual

Label	N 60	N61	N62	N63	N64	N65	N66	N67	N68	N69
Character	\]	^	—	`	a	b	c	d	e
Label	N70	N71	N72	N73	N74	N75	N76	N77	N78	N79
Character	f	g	h	i	j	k	I	m	n	0
Label	N80	N81	N82	N83	N84	N85	N86	N87	N88	N89
Character	p	q	r	s	t	u	v	W	X	Y
Label Character	N90 Z	N91 {	N92 	N93 }						

Coordinate Rotation and Scaling (G50, G51, G68, G69)

This control function is optional. If you would like further information on installing this feature, please call Haas Automation or your dealer for more information.

G50 Cancel Scaling

G50 cancels scaling on all axes. Any axis scaled by a previous G51 command is no longer in effect.

G51 Scaling (This G-code is optional and requires Rotation and Scaling.)

- X optional center of scaling for the X axis
- Y optional center of scaling for the Y axis
- Z optional center of scaling for the Z axis
- P optional scaling factor for all axes; three-place decimal from 0.001 to 8383.000.

G51 [X...] [Y...] [Z...] [P...]

When scaling is invoked, all subsequent X, Y, Z, I, J, K, or R values pertaining to machine motion are multiplied by a scaling factor and are offset relative to a scaling center.

G51 is modal and modifies appropriate positional values in the blocks following the G51 command. It does not change or modify values in the block from which it is called. Axes X, Y, and Z are all scaled when the P code is used. If the P code is not used, the scaling factor currently in Setting 71 is used. The default scaling factor in Setting 71 is 1.0. A scaling factor of 1.0 means that no scaling is done. That is, all values are multiplied by 1.0 before being interpreted by the control.

A scaling center is always used by the control in determining the scaled position. If any scaling center is not specified in the G51 command block, then the current work coordinate position is used as the scaling center.

The following programs illustrate how scaling is performed when different scaling centers are used. All three examples call subroutine O0001, which follows.

Group 11

Group 11

SERIES Operator's Manual





The first example illustrates how the control uses the current work coordinate location as a scaling center. Here, it is X0 Y0 Z0.



The next example specifies the center of the window as the scaling center.



The last example illustrates how scaling can be placed at the edge of tool paths as if the part was being set against locating pins.







If macros are enabled, G65 arguments are not affected. Tool offsets and cutter compensation values are not affected by scaling.

The stored program is not changed by G51, so program lines displayed by the control will not reflect actual machine positions. Position displays WILL reflect the proper scaled values.

Scaling does not affect canned cycle Z axis movements such as clearance planes and incremental values. The final results of scaling are rounded to the lowest fractional value of the variable being scaled.

G68 Rotation (This G-code is optional and requires Rotation and Scaling.) Group 16 [G17 | G18 | G19] G68 [a...] [b...] [R...] ; [G17 | G18 | G19] G68 [a...] [b...] [R...] ; [G17 | G18 | G19] G68 [a...] [b...] [R...] ;

G17. G18. G19	optional plane of rotation.	default is current
an, and, and	optional plane of retation	doradit to our ont

- a optional center of rotation for the first axis of the selected plane
- b optional center of rotation for the second axis of the selected plane
- R optional angle of rotation specified in degrees
 - Three-place decimal -360.000 to 360.000.

In the above example, **a** and **b** correspond to the axes of the current rotation plane. If G17 is the current rotation plane, then **a** is X and **b** is Y.

When rotation is invoked, all subsequent X, Y, Z, I, J, and K values are rotated through a specified angle **R** using a center of rotation.

G68 is modal and modifies appropriate positional values in the blocks following the G68 command. Values in the block containing G68 are not rotated. For subsequent blocks, only the values in the plane of rotation are rotated. Thus, if G17 is the current plane of rotation, only X and Y values are affected.

For a positive angle, rotation is counterclockwise. If the angle of rotation – the R code – is not specified in the G68 command block, then the angle of rotation is taken from Setting 72. The default rotation angle in Setting 72 is 0.0 degrees.

A center of rotation is always used by the control to determine the positional values passed to the control after rotation. If any axis' center of rotation is not specified, then the current location of the work coordinate is used as the center of rotation.

In G90 mode (absolute), the rotation angle takes on the value specified by **R**. When Setting 73 (G68 INCREMENTAL R) is set to ON, then the rotational value can be changed incrementally on each call of G68. In G91 mode (incremental), the rotation angle is changed incrementally by the value in **R**. Each G68 command block in G91 mode will change the rotation angle by the value specified in **R**. Angles are modulo 360, so that when an angle is specified as larger than 360 degrees, the angle will become an equivalent value between 0 and 360 degrees. The rotational angle is set to zero upon cycle start, or it can be set explicitly using a G68 block in the G90 mode.



The following examples illustrate rotation using G68.



The first example illustrates how the control uses the current work coordinate location as a rotation center. Here, it is X0 Y0 Z0.



The next example specifies the center of the window as the rotation center.



This example shows how the G91 mode can be used to rotate patterns about a center. This is often useful for making parts that are symmetric about a regular polygon.







Do not change the plane of rotation while G68 is in effect.

ROTATION WITH SCALING

If scaling and rotation are used simultaneously, it is recommended that scaling be turned on prior to rotation, and that separate blocks be used. Use the following template when doing this.

```
G51 ..... (SCALING) ;
...
G68 ..... (ROTATION) ;
.
. program.
.
G69 ..... (ROTATION OFF) ;
...
G50 ..... (SCALING OFF) ;
```

When rotating after scaling, any center specified as the center of rotation will be scaled. Any angle specified in the G68 block is NOT scaled. The control applies scaling and then rotation to any block with motion commands.

Below is an example of a program that has been scaled and rotated:

```
O0004 ;
G59 ;
G00 G90 X0 Y0 Z0 ;
M98 P1 ;
G90 G00 X0 Y0 ;
G51 P3.0 ;
G68 R60. ;
M98 P1 ;
G69 G51 G90 G00 X0 Y0 ;
M30 ;
```

ROTATION WITH CUTTER COMPENSATION

Cutter compensation should be turned on after the rotation and scaling commands are issued. Compensation should also be turned off prior to turning rotation or scaling off.

G69 Cancel G68 Rotation (This G-code is optional and requires Rotation and Scaling.) Group 16

G69 cancels any rotation specified previously.

216 -



Work Coordinate System Selection (G52, G53, G54-59)

NOTE: The G52 command works differently depending on the value of Setting 33. This setting selects the Fanuc, Haas, or Yasnac style of coordinates, which are listed below:

G52 Set Work Coordinate System G52 YASNAC

This code selects the G52 work coordinate system. G52 works the same as G54, etc., except that the G52 system will be set by a G92 command as well as from the Offsets display.

YASNAC compatible.

G52 Set Local Coordinate System FANUC

This code sets the origin of the local (child) coordinate system to the commanded location, relative to the current work system origin. G52 is a non-modal, no motion code. The G52 coordinate system will stay in effect for all work systems until it is canceled. The G52 command is canceled when RESET is pressed and at the end of a program. It is also canceled during a program by M30, G52 X0 Y0 Z0, or by a G92 command.

G52 Set Local Coordinate System HAAS

This code works the same as in the Fanuc control except that G52 is not cleared at power-up, RESET, or when an M30 is performed.

G53 Non-Modal Machine Coordinate Selection

This code temporarily cancels work coordinate offsets and uses the machine coordinate system. It is nonmodal, so the next block will revert to whatever conditions were previously selected.

G54-59 Select Coordinate System #1 - #6

These codes select one of the six user coordinate systems stored within the Offset memory. All subsequent references to axis positions will be interpreted in the new coordinate system. Work coordinate system offsets are entered from the Offsets display page.

More Miscellaneous G Codes (G60, G61, G64)

G60 Uni-Directional Positioning

This **G** code is used to provide positioning always from the positive direction. In older systems it was used to reduce backlash, and it is not recommended for use with this control. It is provided only for compatibility. It is non-modal, so does not affect the blocks that follow it. Setting 35 controls the distance an axis will travel past the target point prior to reversing for an approach in the positive direction.

G61 Exact Stop Modal

96-8000 rev E

The G61 code is used to specify an exact stop. It is modal and thus affects the blocks that follow it. Rapid and interpolated moves will decelerate to an exact stop before another block is processed. With exact stop in effect, moves will take longer and continuous cutter motion will not occur.

This may cause deeper cutting where the tool stops.

G64 G61 Cancel (Select Normal Cutting Mode)

The G64 code is used to cancel exact stop. It is modal and thus affects subsequent blocks. Rapid and interpolated moves will not decelerate to an exact stop before another block is processed. Rapid blocks will decelerate to within the distance specified in Parameters 101-104 before another block is processed, and interpolated motion will not decelerate at all before the next block is processed.

Group 12

Group 00

Group 00

Group 12

Group 00

Group 00

Group 13

Group 13

uai

BOLT HOLE PATTERNS (G70, G71, G72)

There are three **G** codes that provide patterns usually used for bolt holes. These are G70, G71, and G72. They are normally used with one of the Group 09 canned cycles.

G70 Bolt Hole Circle

- I Radius (minus reverses direction)
- J Starting angle (0 to 360.0 degrees CCW from horizontal)
- L Number of holes evenly spaced around the circle

This **G** code must be used with one of the canned cycles G73, G74, G76, G77, or G81-G89. The tool must be positioned at the center of the circle either in a previous block or in the G70 block. G70 belongs to Group 00 and thus is non-modal. For a G70 to work correctly, a canned cycle should be active so that at each position, some type of drill or tap function is performed.

G71 Bolt Hole Arc

- I Radius
- J Starting angle (degrees CCW from horizontal)
- K Angular spacing of holes (+ or –)
- L Number of holes

This **G** code is similar to G70 except that it is not limited to one complete circle. G71 belongs to Group 00 and thus is non-modal. For a G71 to work correctly, a canned cycle should be active so that at each position, some type of drill or tap function is performed.

G72 Bolt Holes Along an Angle

- I Distance between holes (minus will reverse direction)
- J Angle of line (degrees CCW from horizontal)
- L Number of holes

This G code drills **L** holes in a straight line at the specified angle. It operates similarly to G70 and G71. G72 belongs to Group 00 and thus is non-modal. For a G72 to work correctly, a canned cycle should be active so that at each position, some type of drill or tap function is performed.



1145

Group 00

Group 00

Group 00









If a canned cycle is defined in a block without an **X** or **Y** motion, there are two common actions taken by other controls: Some will execute the canned cycle at that time, and some will not. With the VF Series Mill, one of these options is selectable from Setting 28.

In addition, if a canned cycle is defined without an **X** or **Y** and with a loop count of 0 (L0), the cycle will not be performed initially. The operation of the canned cycle will vary according to whether incremental (G91) or absolute (G90) positioning is active. Incremental motion in a canned cycle is often useful as a loop (**L**) count. It can be used to repeat the operation with an incremental **X** or **Y** move between each cycle.



The positioning of the X and Y axes prior to a canned cycle is normally done with rapid moves, without an exact stop prior to plunging the Z axis to the **R** depth. This may cause a crash with a close-tolerance fixture. Setting 57 can be used to select an exact stop for these XY moves.



The G80 code is used to cancel a canned cycle; in addition, a G00 or G01 code will also cancel any active canned cycle. Once a canned cycle is defined, that operation is performed at every XY position in subsequently listed blocks.

Some of the canned cycle numerical values can be changed after the canned cycle is defined. The most important of these are the **R** plane value and the **Z** depth value. If these are listed in a block with XY commands, the XY move is done and all subsequent canned cycles are performed with the new **R** or **Z** value.

Changes to the G98/G99 selection can also be made after the canned cycle becomes active. If changed, the new G98/G99 value will change all subsequent canned cycles.





Setting 52 also changes the way G73 works when it returns to the **R** plane. Most programmers set the **R** plane well above the cut, to ensure that the chip-clearing motion actually allows the chips to get out of the hole, but this causes wasted motion when first drilling through this "empty" space. If Setting 52 is set to the distance required to clear chips, the **R** plane can be put much closer to the part being drilled. When the chip-clearing move to **R** occurs, the **Z** axis will be moved above **R** by this setting.

G74 Reverse Tap Canned Cycle

Group 09

- F Feedrate in inches (mm) per minute
- J Retract Multiple
- L Number of repeats
- R Position of the R plane
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Position of bottom of tap

This G code is modal. Once activated, every commanded motion of **X** and/or **Y** will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected. Note that operation of this cycle is different if rigid tapping is selected. When rigid tapping is used, the ratio between the feedrate and spindle speed must be precisely the thread pitch being cut.

You do not need to start the spindle CCW before this canned cycle. The control does this automatically.



-111445-



Group 09

G77 Back Bore Canned Cycle

- F Feedrate in inches (mm) per minute
- I Optional shift value, if Q is not specified

SERIES

- J Optional shift value, if Q is not specified
- L Number of repeats
- Q The shift value, always incremental
- R Position of the R plane
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Position of bottom of hole

This G code is modal. Once activated, every commanded motion of **X** and/or **Y** will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected. This cycle will shift the X and/or Y axis prior to and after cutting in order to clear the tool while entering and exiting the part. If Setting 57 is on, the tool will perform an exact stop between rapids. This will prevent tool breakage and any nicking at the bottom of the hole. The shift direction is determined by Setting 27. If Q is not specified, the optional I and J values are used to determine the shift direction and distance.

Operator's Manual



G80 Canned Cycle Cancel

This G code is modal. It deactivates all canned cycles until a new one is selected. Note that use of G00 or G01 will also cancel a canned cycle.

G81 Drill Canned Cycle

- F Feedrate in inches (mm) per minute
- L Number of repeats
- R Position of the R plane
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Position of bottom of hole

This G code is modal. Once activated, every commanded motion of **X** and/or **Y** will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected.

Group 09

Group 09

224



Group 09



G82 Spot Drill Canned Cycle

- F Feedrate in inches (mm) per minute
- L Number of repeats
- P The dwell time at the bottom of the hole
- R Position of the R plane
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Position of bottom of hole

This G code is modal. Once activated, every commanded motion of **X** and/or **Y** will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected.

G82 FORMAT

G82 Z – ____ P ____ R ____ F ____;

These are the required codes for **spot drilling**.

P = Dwell time, in milliseconds, at the bottom of the Z-axis move. For example, P300 is approximately 1/3 second.

PROGRAM EXAMPLE

% O1234 T1 M06 G90 G54 G00 X.565 Y-1.875 S1275 M03 G43 H01 Z0.1 M08 G82 Z-0.175 P.3 R0.1 F10. X1.115 Y-2.750 X3.365 Y-2.875 X4.188 Y-3.313 X5.0 Y-4.0 G80 G00 Z1.0 M09

DESCRIPTION

(Sample program) (Tool #1 is a 0.5" x 90-degree spot drill)

(90-degree spot drill; the depth is) (half of the chamfer diameter)



G82 Spot drilling example









PROGRAM EXAMPLE

T2 M06 G90 G54 G00 X0.565 Y-1.875 S2500 M03 G43 H02 Z0.1 M08 G83 Z-0.720 Q0.175 R0.1 F15. X1.115 Y-2.750 X3.365 Y-2.875 X4.188 Y-3.313 X5.0 Y-4.0 G80 G00 Z1.0 M09

G84 **Tapping Canned Cycle**

- F Feedrate in inches (mm) per minute
- **Retract Multiple** J
- L Number of repeats
- R Position of the R plane
- Х Optional X-axis motion command
- Y Optional Y-axis motion command
- Ζ Position of bottom of tap



G 84 Tapping Canned Cycle Example

DESCRIPTION (Tool #2 is a 0.3125" stub drill)

(Drill point is 1/3 of the drill diameter)

Group 09





SERIES Operator's Manual

Group 09

G85 Boring Canned Cycle

- F Feedrate in inches (mm) per minute
- L Number of repeats
- R Position of the R plane
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Position of bottom of hole



This G code is modal. Once activated, every commanded motion of **X** and/or **Y** will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected.

G86 Bore and Stop Canned Cycle

Group 09

- F Feedrate in inches (mm) per minute
- L Number of repeats
- R Position of the R plane
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Position of bottom of hole



This G code is modal. Once activated, every commanded motion of **X** and/or **Y** will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected.



SERIES

Group 09

June 2002

G89

- F Feedrate in inches (mm) per minute
- Number of repeats L
- Ρ The dwell time at the bottom of the hole
- R Position of the **R** plane
- Х Optional X-axis motion command
- Y Optional Y-axis motion command
- Ζ Position of bottom of hole

This G code is modal. Once activated, every commanded motion of X and/or Y will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected.

Operator's Manual



Absolute / Incremental Selection (G90, G91)

G90 **Absolute Position Commands**

This code is modal and changes the way axis motion commands are interpreted. G90 makes all subsequent commands within the selected user coordinate system absolute positions. Each axis moved will be placed at the position coded in the command block.

G91 **Incremental Position Commands**

Group 03

Group 03

This code is modal and changes the way axis motion commands are interpreted. G91 makes all subsequent commands incremental. Each axis moved will be moved by the amount coded in the command block. This code is not compatible with G143 (5-Axis Tool Length Compensation).

More Work Coordinate Selection (G92)

The way this command works depends on Setting 33, which selects a FANUC, HAAS, or YASNAC coordinate system. This command does not move any of the axes; it only changes the values stored as user work offsets.

G92 Set Work Coordinate Systems Shift Value – FANUC OR HAAS Group 00

A G92 command effectively shifts all work coordinate systems (G54-59, G110-129) so that the commanded position becomes the current position in the active work system. G92 is a non-modal, non-motion code.

A G92 command cancels any G52 in effect for the commanded axes. Example: G92 X1.4 cancels the G52 for the X axis. The other axes are not affected.

-1.11.1.1.5--

Canned Cycle Auxiliary Functions (G98, G99)

SERIE

G98 Canned Cycle Initial Point Return

This G code is modal and changes the way canned cycles operate. With G98, the Z axis returns to its initial starting point (the Z position it was at when the canned cycle was first defined) between each new X and/or Y location. This allows for positioning up and around areas of the part and/or clamps and fixtures that are in the tool path.

Operator's Manual

G99 Canned Cycle R Plane Return

This G code is modal and changes the way canned cycles operate. With G99, the Z axis will stay down at the R plane between each new X and/or Y location, when no obstruction is in the path of the tool to the next location.

Programmable Mirror Image (G100, G101)

G100 Cancel Mirror Image

G101 Enable Mirror Image

- X Optional X-axis command
- Y Optional Y-axis command
- Z Optional Z-axis command
- A Optional A-axis command

At least one of theaxis commands is required. Settings 45 through 48 are used to select mirror imaging.

Programmable mirror imaging can be turned on or off individually for any of the four axes. The two G codes (G100 and G101) are non-modal, but the mirror image status of each axis is modal. The bottom of the screen will indicate when an axis is mirrored. These G codes should be used in a command block without any other G codes. They do not cause any axis motion. G101 will turn on mirror imaging for any axis listed in that block. G100 will turn off mirror imaging for any axis listed in the block. The actual value given for the **X**, **Y**, **Z**, or **A** code has no effect. G100 or G101 by itself will have no effect and should be entered as zero value.

Example:

G101 X0 = Will turn on mirror imaging for the X axis.

G100 X0 = Will turn off mirror imaging for the X axis.

Most mirror imaging applications would consist of irregular pockets and contours, and would most likely be set up in subprograms for convenience.

When using cutter compensation with mirror imaging, follow this guideline: After turning mirror imaging on or off with G100 or G101, the next motion block should be to a different work coordinate position than the first one. The following code is an example:

Incorrect:	Correct:
G41 X1.0 Y1.0	G41 X1.0 Y1.0
G01 X2.0 Y2.0	G01 X2.0 Y2.0
G101 X0	G101 X0
G00 Z1.0	G00 Z1.0
G00 X2.0 Y2.0	G00 X1.0
	G00 X2.0 Y2.0
G40	G40.

Group 00

Group 00

Group 10

Group 10



PROGRAM CODE FOR MIRROR IMAGING IN THE X AXIS: **PROGRAM EXAMPLE DESCRIPTION** % O3600 (Mirror image X axis) (Tool #1 is a 0.250" diameter endmill) T1 M06 G00 G90 G54 X-.4653 Y.052 S5000 M03 G43 H01 Z.1 M08 G01 Z-.25 F5. F20. M98 P3601 G00 Z.1 G101 X0. X-.4653 Y.052 G01 Z-.25 F5. F20. M98 P3601 G00 Z.1 G100 X0. G28 G91 Y0 Z0 M30 % % O3601 G01 X-1.2153 Y.552 G03 X-1.3059 Y.528 R.0625 G01 X-1.5559 Y.028 G03 X-1.5559 Y-.028 R.0625 G01 X-1.3059 Y-.528 G03 X-1.2153 Y-.552 R.0625 G01 X-.4653 Y-.052 G03 X-.4653 Y.052 R.0625 M99 % PROGRAM CODE FOR MIRROR IMAGE IN THE X, Y, AND XY AXES:



Mirror image (X, Y, and XY) and pocket milling exercise for 03700.

(Contour subprogram)

236 -

-111145-



PROGRAMMABLE OUTPUT TO RS-232 (G102)

G102 Programmable Output to RS-232

Group 00

- X Optional X-axis command
- Y Optional Y-axis command
- Z Optional Z-axis command
- A Optional A-axis command

Programmable output to the RS-232 port allows the current work coordinates of the four axes to be output. This **G** code (G102) is non-modal, so it only affects the block in which it is programmed. It should be used in a command block without any other **G** codes and it will not cause any axis motion. The actual value given for the **X**, **Y**, **Z**, or **A** code has no effect. One complete line of text is sent to the first RS-232 port (same one used for upload, download, and DNC). Each axis listed in the G102 command block is output to the RS-232 port in the same format as values displayed in a program.

Optional spaces (Setting 41) and EOB control (Setting 25) are applied. The values sent out are always the current axis positions referenced to the current work coordinate system.

Digitizing of a part is possible using this **G** code and a program which steps over a part in XY and probes downward in **Z** with a G31. When the probe hits, the next block could be a G102 to send the **X**, **Y**, **Z** position out to a computer which could store the coordinates as a digitized part.

LIMIT BLOCK BUFFERING FUNCTION (G103)

G103 Limit Block Buffering

Group 00

P = 0-15 Maximum number of blocks the control will look ahead

G103 [P..]

"Block Look-ahead" is a term used to describe what the control is doing in the background during machine motion. A motion block may take several seconds to execute. The control can take advantage of this by preparing additional blocks of the program ahead of time. While the current block is executing, the next block has already been interpreted and prepared for continuous, uninterrupted motion between consecutive blocks. Block look-ahead is also important for obtaining the information necessary for predicting compensated positions for cutter compensation.

When G103 P0 is programmed, block limiting is disabled. Block limiting is also disabled if G103 appears in a block without a P address code.

When G103 Pn is programmed, look-ahead is limited to n blocks.

At this time G103 cannot be used if cutter compensation, G41 or G42, is in effect. Alarm 387 (Cutter Comp Not Allowed with G103) is generated if you attempt to do so.

G103 is also useful for debugging programs using macros. Macro expressions are executed at look-ahead time. By inserting a G103 P1 into the program, macro expressions will be performed one block ahead of the currently executing block.

G103 is not a Fanuc-compatible command.



This means that the rotary axis diameter as specified on the Settings page is always used as the default cylindrical mapping surface diameter, unless a previously issued G107 has established a different value. This allows the default cylindrical surface diameter to either be synchronized with, or operate independently from, the rotary axis diameter defined in the Settings.

To force the default cylindrical surface diameter to be "in sync" with the Settings page rotary axis diameter (which may be desirable if the current default diameter status is unknown), the following G107 command can be used:

G107 A0 Q0

This command will reset the A-axis default cylindrical surface diameter to zero, which forces the Settings page value to be used as the default for that axis.

R specifies the radius of the rotary axis. If Q has already been specified, R will be ignored. Except as noted above, the conditions and/or restrictions associated with the use of this parameter are exactly the same as for Q.

2) The above parameters can be entered in any order.

3) Pressing the RESET key will turn off any cylindrical mapping that is currently in effect, regardless of the status of Setting 56. Cylindrical mapping will also be turned off automatically whenever the G-code program ends, but only if Setting 56 is ON. If Setting 56 is OFF, any cylindrical mapping in effect when the program ends will remain in effect.

4) A G107 code issued without any parameters turns off cylindrical mapping. This should normally be done at the end of the program. However, if cylindrical mapping is not turned off and Setting 56 is OFF, then the mapping parameters established can be used by other programs.

5) Re-issuing a G107 command with either the same or a different linear axis specification will turn off the cylindrical mapping currently in effect before new mapping is initiated.

6) Issuing a G107 command with only a rotary axis specification and either a Q or an R will only change the default diameter or radius for the specified rotary axis; it will not turn cylindrical mapping on or off.

NOTE: Note: Due to the fact that the maximum acceleration of a rotary axis (as parameterized in steps/second/second on the Parameters page) is different from the maximum acceleration of a linear axis, there is a maximum achievable feedrate that can be programmed for a circular interpolated move when one of the rotary axes has been cylindrically mapped. Refer to the next section for a description of feedrate alteration.

Feedrate Alteration To Ensure Concurrent Axis Motion

The actual feedrate achieved in any interpolated motion on the CNC Mill is limited by the maximum speed achievable in each axis of motion. The feedrate may be lowered from its programmed value if that value would cause the Mill to command an axis to move faster than its parameterized maximum speed.

This means that the actual feedrate achieved may be less than or equal to the programmed feedrate, ensuring that all axes of interpolated motion move concurrently. When this condition occurs, the warning "LIM" will be displayed on the screen immediately to the left of the "FEED" display. Note also that the MAX FEEDRATE EXCEEDED alarm will still be issued if the programmed feedrate exceeds parameter 59, MAX FEEDRATE (currently 500 ipm), but only if the mill is not in Inverse Time mode.

More Work Coordinate Selection (G110-G129)

G110-G129 Coordinate System #7-26

These codes select one of the additional 20 user coordinate systems stored within the Offsets memory. All subsequent references to axis positions will be interpreted in the new coordinate system. Operation of G110 to G129 is the same as G54 to G59.

Compensation (G141,G143)

G141 3D+ Cutter Compensation

This feature performs 3D+ cutter diameter compensation. The form is:

G141 Xnnn Ynnn Znnn Dnnn Innn Jnnn Knnn

Subsequent lines can be of the form:

G01 Fnnn Xnnn Ynnn Znnn Innn Jnnn Knnn

or:

G00 Xnnn Ynnn Znnn Innn Jnnn Knnn

The 3D+ G141 cutter compensation command is not just for 5-axis work. Any CAD system can output the I, J, K values to shift the tool by the amount in the Offsets memory of the control, even if the motions are only in 2 or 3 axes. In the Haas control, only G00 and G01 can use G141 cutter compensation; no other functions or canned cycles will get the offset. G91 incremental motion also cannot be used. G141 is used to indicate, without any doubt, what type of compensation is being requested. G141 is modal with G40, G41, and G42. Inverse time is usually used with this type of motion but is not required. The Dnn code selects which radius or diameter offset to use. The I, J, and K values give the direction in which cutter compensation is to be applied. When G141 is active, the tool diameter will have a vector component that will be added to commanded motion of the X, Y, or Z axis, based on the direction defined by I, J, and K. For example:

T1 M06 G00 G90 G54 X0 Y0 Z0 A0 B0 G141 D01 X0.Y0. Z0. (RAPID POSIT WITH 3 AX C COMP) G01 G93 X.01 Y.01 Z.01 I.1 J.2 K.9747 F300. (FEED INV TIME) X.02 Y.03 Z.04 I.15 J.25 K.9566 F300. X.02 Y.055 Z.064 I.2 J.3 K.9327 F300

. X2.345 Y.1234 Z-1.234 I.25 J.35 K.9028 F200. (LAST MOTION) G94 F50. (CANCEL G93) G0 G90 G40 Z0 (RAPID TO ZERO, CANCEL 3 AXIS C COMP) X0 Y0 M30

G40 will cancel G141 3D+ cutter compensation.

NOTE: G141 is a group 7 G code, G40 cancels G141, G91 is not compatible with G141, G141 uses a D code

Group 07



General Purpose Pocket Milling Function (G150)

G150 General Purpose Pocket Milling

Group 00

- D Cutter size selection
- F Feedrate
- I X-axis cut increment
- J Y-axis cut increment
- K Finishing cut allowance
- L Optional repetition count
- P Subroutine number defining outside of shape
- Q Incremental Z-axis cut depth per pass, positive values only (> 0)
- R R plane position
- S Optional spindle speed
- X X position of starting hole
- Y Y position of starting hole
- Z Final depth of the pocket

This **G** code provides for general purpose pocket milling. The shape of the pocket to be cut must be defined by a series of motions within a subroutine. A series of motions in either the X or Y axis will be used to cut out the specified shape, followed by a finishing pass to clean up the outer edge. Either **I** or **J** must be specified and must be a positive number; this is the shift amount or cutter overlap. If **I** is used, the pocket is cut from a series of strokes in the X-axis. If **J** is used, the pocket is cut from a series of strokes in the X-axis. If **J** is used, the pocket is no finishing pass in the **Z** depth. The **R** value should be specified even if it is zero (R0). Otherwise the last value specified for R will be used.



Multiple passes over the area can be selected to control the depth of the cut. At least one pass is made over the pocket and multiple passes are made after feeding down by amount \mathbf{Q} until the \mathbf{Z} depth is reached. \mathbf{Q} must be a positive number. If an \mathbf{L} count is specified, the entire block is repeated and an incremental \mathbf{X} or \mathbf{Y} (G91) will reposition the pocket.

The subroutine must define a closed area by a series of G01, G02, or G03 motions in **X** and **Y** and must end with an M99. **G** codes G90 and G91 can also be used in the subroutine to select absolute or incremental positioning. Any codes other than **G**, **I**, **J**, **R**, **X**, or **Y** are ignored in the subroutine. This subroutine must consist of less than 20 strokes.

In order to clear the tool on entry, pocket milling should begin from a hole which has been previously drilled to the Z depth. The G150 block must specify this hole location with X and Y.

-1.11.4.5-



% O4600 G01 X__Y__

X___ Y___ X___ %



NOTE: When defining the contour in the subprogram, the idea to keep in mind is to only connect the contour — not to return to the starting point.

MORE G150 EXAMPLES

ABSOLUTE SUBPROGRAM:	INCREMENTAL SUBPROGRAM:
%	%
O0500	O0500
G01 Y2.0	G01 G91 Y2.0
X-2.0	X-2.0
Y-2.0	Y-4.0
X2.0	X4.0
Y2.0	Y4.0
XO	G90
M99	M99
%	%



SQUARE ISLAND:



Square island programming exercise using G150.

% O1000 T1 M06 (Tool is a 0.500" diameter endmill) G90 G54 G00 X2. Y2. S2500 M03 G43 H01 Z0.1 M08 G01 Z0.01 F30. G150 P500 X2. Y2. Z-0.5 Q0.5 R0.01 I0.3 K0.01 G41 D01 F10. G40 G01 X2. Y2. G00 Z1.0 M09 G28 G91 Y0 Z0 M30 % % O0500 G01 Y1. X7. Y7. X1. Y3.75 X3.5 Y4.5 X4.5 Y3.5 X3.5 Y4.25 X1. Y1. X2. M99 %

248 -



These are all Group 9 G-codes

5-Axis Canned Cycles

G153 5-Axis High Speed Peck G154 5-Axis Reverse Tap Cycle G161 5-Axis Drill Cycle G162 5-Axis Spot Drill G163 5-Axis Normal Peck G164 5-Axis Tapping Cycle G165 5-Axis Bore In/Bore Out G166 5-Axis Bore/Stop/Rapid G169 5-Axis Bore/Dwell/Manual

These correspond to the existing G73, G74, G81, G82, G83, G84, G85, G86 and G89 3-axis canned cycles. There are three differences between a 3-axis canned cycle and a 5-axis canned cycle:

- 1) Five-axis canned cycles will rapid to the specified X,Y, Z, A, B position, which is used as the starting point.
- 2) Five-axis canned cycles require an **E** code, which specifies the distance from the starting position to the bottom of the hole. If this is not given, an alarm will be generated.
- 3) Five-axis canned cycles ignore any **R** codes. The starting point is always the **R** position.

Notes: Retraction and pecking, which would be rapid motions in a normal canned cycle, are fast feeds, not true rapids. Currently, G154 and G164 only perform floating taps. G184 is available for 5-axis rigid tapping.

G153 5-Axis High Speed Peck Drilling Canned Cycle

Group 09

- E Specifies the distance from the start position to the bottom of the hole
- F Feedrate in inches (mm) per minute
- I Optional size of first cutting depth
- J Optional amount to reduce cutting depth each pass
- K Optional minimum depth of cut / number of pecks between retract
- L Number of repeats
- P Optional pause at end of last peck, in seconds
- Q The cut-in value, always incremental
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Position of bottom of hole



This G code is modal. Once activated, every commanded motion of **X** and/or **Y** will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected. This is a high-speed peck cycle where the retract distance is set by Setting 22.

-111445-





If **K** and **Q** are both specified, a different operating mode is selected for this canned cycle. In this mode, the tool is returned to the **start position** after the number of passes totals up to amount **K**. This allows much faster drilling than G83 but still returns to the **start position** plane occasionally to clear chips.

I, J, K, and Q are always positive numbers.

G161 5-Axis Drill Canned Cycle

- Group 09
- E Specifies the distance from the start position to the bottom of the hole
- F Feedrate in inches (mm) per minute
- L Number of repeats
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Position of bottom of hole



This G code is modal. Once activated, every commanded motion of **X** and/or **Y** will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected. A specific X, Y, Z, A, B position must be programmed before the canned cycle is programmed. This position is used as the "Start position" by the canned cycle.

If **P** is specified, the tool will pause at the bottom of the hole after the last peck for that amount of time. The following example will peck several times and dwell for one and a half seconds at the end:

SERIES

G163 Z-0.62 F15. R0.1 Q0.175 P1.5.

G CODES

The same dwell time applies to all subsequent blocks that do not specify a dwell time. When the canned cycle is cancelled (by G00, G01, G80, or RESET) the dwell time will be reset to zero. This dwell cannot be used in the same block as an M97, M98, M99, or G65, because these codes use **P** for different purposes.



Setting 52 also changes the way G163 works when it returns to the **start position**. Most programmers set the **R** plane well above the cut to ensure that the chip-clearing motion actually allows the chips to get out of the hole, but this causes wasted motion when first drilling through this "empty" space. If Setting 52 is set to the distance required to clear chips, the **start position** can be put much closer to the part being drilled. When the chip-clearing move to the **start position** occurs, the **Z** axis will be moved above the **start position** by the amount given in this setting.





This G code is modal. Once activated, every commanded motion of **X** and/or **Y** will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected. A specific X, Y, Z, A, B position must be programmed before the canned cycle is programmed. This position is used as the "Start position" by the canned cycle.

G166 5-Axis Bore and Stop Canned Cycle

Group 09

- E Specifies the distance from the start position to the bottom of the hole
- F Feedrate in inches (mm) per minute
- L Number of repeats
- X Optional X-axis motion command
- Y Optional Y-axis motion command
- Z Position of bottom of hole



This G code is modal. Once activated, every commanded motion of **X** and/or **Y** will cause this canned cycle to be executed, until it is canceled or another canned cycle is selected. A specific X, Y, Z, A, B position must be programmed before the canned cycle is programmed. This position is used as the "Start position" by the canned cycle.

G CODES _____





IN POSITION ACCURACY (G 187)

G187 Accuracy Control

Group 00

The G187 code is used to select the accuracy with which corners are machined. The format for using G187 is **G187 Ennnn**, where **nnnn** is the desired accuracy. Refer to "Contouring Accuracy" for more information.

Program G187 as follows:

G187 E0.01	(to set value)
G187	(to revert to Setting 85 value)



5. M CODES (MISCELLANEOUS FUNCTIONS)

M Code Summary

Only one **M** code may be programmed per block of a program. All **M** codes are effective or cause an action to occur at the end of the block. However, when Parameter 278 bit "CNCR SPINDLE" is set to 1, an M03 (spindle start) will occur at the beginning of a block.

M00	Stop Program
M01	Optional Program Stop
M02	Program End
M03	Spindle Forward
M04	Spindle Reverse
M05	Spindle Stop
M06	Tool Change
M08	Coolant On
M09	Coolant Off
M10	Engage 4th Axis Brake
M11	Release 4th Axis Brake
M12	Engage 5th Axis Brake
M13	Release 5th Axis Brake
M16	Tool Change (same as M06)
M17	Unclamp APC Pallet And Open APC Door (used for maintenance only)
M18	Clamp APC Pallet And Close APC Door (used for maintenance only)
M19	Orient Spindle. P and R values optional.
M21-M28	Optional Pulsed User M Function with Fin
M30	Prog End and Rewind
M31	Chip Conveyor Forward
M32	Chip Conveyor Reverse
M33	Chip Conveyor Stop
M34	Increment Coolant Spigot Position
M35	Decrement Coolant Spigot Position
M36	Pallet Rotate
M39	Rotate Tool Turret
M41	Low Gear Override
M42	High Gear Override
M50	Execute Pallet Change
M51-M58	Set Optional User M
M59	Set Output Relay
M61-M68	Clear Optional User M
M69	Clear Output Relay
M75	Set G35 or G136 Reference Point
M76	Disable Displays
M77	Enable Displays
M78	Alarm if skip signal found
M79	Alarm if skip signal not found
M80	Auto Door Open
M81	Auto Door Close
M82	Tool Unclamp
M83	Air Gun On
M84	Air Gun Off
M86	Tool Clamp
M88	Through the Spindle Coolant ON





M89

Through the Spindle Coolant OFF

SERIES

- M93 Start Axis POS Capture
- M94 Stop Axis POS Capture
- M95 Sleep Mode
- M96 Jump if no Input
- M97 Local Sub-Program Call
- Sub Program Call M98
- Sub Program Return Or Loop M99
- M109 Interactive User Input

M00 Stop Program

The M00 code is used to stop a program. It also stops the spindle and turns off the coolant and stops interpretation lookahead processing. The program pointer will advance to the next block and stop. A cycle start will continue program operation from the next block. If the Through the Spindle Coolant option is ON, M00 will shut it off.

Operator's Manual

M01 **Optional Program Stop**

The M01 code is identical to M00 except that it only stops if OPTIONAL STOP is turned on from the front panel. A cycle start will continue program operation from the next block. If the Through the Spindle Coolant option is ON, M01 will shut it off.

M02 Program End

The M02 code will stop program operation the same as M00 but does not advance the program pointer to the next block.

M03 Spindle Forward

The M03 code will start the spindle moving is a clockwise direction at whatever speed was previously set. The block will delay until the spindle reaches about 90% of commanded speed.

When Parameter 278 bit 10, "CNCR SPINDLE", is set to 1, the machine will not wait for the spindle to come up to speed immediately after an M03 command. Instead, it will check and/or wait for the spindle to come up to speed immediately before the next interpolated motion is initiated.

M04 Spindle Reverse

The M04 code will start the spindle moving is a counterclockwise direction at whatever speed was previously set. The block will delay until the spindle reaches about 90% of commanded speed.

When Parameter 278 bit 10, "CNCR SPINDLE", is set to 1, the machine will not wait for the spindle to come up to speed immediately after an M04 command. Instead, it will check and/or wait for the spindle to come up to speed immediately before the next interpolated motion is initiated.

Running an M04 command with TSC on is not recommended

M05 Spindle Stop

The M05 code is used to stop the spindle. The block is delayed until the spindle slows below 10 RPM.



M06 Tool Change

The M06 code is used to initiate a tool change. The previously selected tool (**Tn**) is put into the spindle. If the spindle was running, it will be stopped. No previous axis commands are required before the tool change unless there is a problem with tool/part/fixture clearance. The Z-axis will automatically move up to the machine zero position and the selected tool will be put into the spindle. The Z-axis is left at machine zero. The spindle will not be started again after the tool change but the **Snnnn** speed and gear will be unchanged. The **Tnn** must be in the same block or in a previous block. The coolant pump will be turned off during a tool change.

When the Through the Spindle Coolant (TSC) is ON, M06 will orient the spindle and move the Z-axis to tool change position, turn off the TSC pump, purge the coolant from the drawbar, then perform a tool change. TSC will remain OFF until an M88 is called.

M08 Coolant On

The M08 code will turn on the coolant supply. Note that the **M** code is performed at the end of a block; so that if a motion is commanded in the same block, the coolant is turned on after the motion. The low coolant status is only checked at the start of a program so a low coolant condition will not stop a program which is already running.

M09 Coolant Off

The M09 code will turn off the coolant supply.

M10 Engage 4th Axis Brake

The M10 code is used to apply the brake to the 4th axis. The brake is normally engaged, so M10 is only required when M11 is used to release the brake.

M11 activates a relay that releases the brake. M10 deactives this relay, engaging the brake.

M11 Release 4th Axis Brake

The M11 code will "pre-release" the 4th axis brake. This is useful in preventing the delay that otherwise occurs when a 4th axis is used with a brake and a motion is commanded in that axis. It is not required but, without a prior M11, there will be a delay in motion in order to release the air.

M12 Engage 5th Axis Brake

The M12 code is used to apply the brake to the 5th axis. The brake is normally engaged, so M12 is only required when M13 is used to release the brake.

M13 activates a relay that releases the brake. M12 deactives this relay, engaging the brake.

M13 Release 5th Axis Brake

The M13 code will "pre-release" the 5th axis brake. This is useful in preventing the delay that otherwise occurs when a 5th axis is used with a brake and a motion is commanded in that axis. It is not required but, without a prior M13, there will be a delay in motion in order to release the air.

M16 Tool Change

The M16 code is used to initiate a tool change. In the present machine configuration, M16 works exactly like M06.

M17 Unclamp APC Pallet And Open APC Door

Used for maintenance only

M18 Clamp APC Pallet And Close APC Door

Used for maintenance only

M19 Orient Spindle. P and R values optional

The M19 code is used to orient the spindle to a fixed position. The spindle is oriented electronically. A P value can be added as an option that will cause the spindle to be oriented to a particular angle (in degrees). For example, M19 P270 will orient the spindle to 270 degrees. An R value will recognize up to four places to the right of the decimal point. An M19 R123.4567 will position the spindle to the angle specified by the R value.





M21-M28 Optional User M

The M21 through M28 codes are optional for user interfaces. They will activate one of relays (see parameter 352), wait for the M-fin signal (discrete input 1009), release the relay, and wait for the M-fin signal to cease. The RESET button will terminate any operation that is hung-up waiting for M-fin.

M30 Prog End and Rewind

The M30 code is used to stop a program. It also stops the spindle and turns off the coolant. The program pointer will be reset to the first block of the program and stop. The parts counters displayed on the Current Commands display are also incremented. M30 will also cancel tool length offsets. When the Through the Spindle Coolant (TSC) option is ON, M30 will shut it OFF, and then perform an M30 operation.

M31 Chip Conveyor Forward

M31 starts the chip conveyor motor in the forward direction. The forward direction is defined as the direction that the conveyor must move to transport chips out of the work cell. The conveyor will not turn if the door is open. This may be overridden by setting bit 17 of parameter 209 (CNVY DR OVRD).

M32 Chip Conveyor Reverse

M32 starts the chip conveyor motor in the reverse direction. The reverse direction is defined as the direction opposite of forward. The conveyor will not turn if the door is open. This may be overridden by setting bit 17 of parameter 209 (CNVY DR OVRD).

M33 Chip Conveyor Stop

M33 Stops Conveyor motion.

M34 Increment Coolant Spigot Position

M34 Increments the current spigot position one place. Incrementing the spigot position causes the spigot to advance one place from the home position. The home position is designated as zero. If the current home position is designated as 5 and M34 is executed, then the current spigot position will advance to position 6. The spigot home places the spigot at the most positive Z axis location the spigot can attain. Incrementing the spigot then lowers the coolant stream direction.

M35 Decrement Coolant Spigot Position

M35 decrements the coolant spigot position one place. Decrementing the spigot position causes the spigot to move toward the spigot home position. The home position is designated as zero. If the current spigot position is 5 and M35 is executed, then the current spigot position will move to 4. The spigot home position for a horizontal mill places the spigot at the most positive Z axis location. Decrementing the spigot will raise the coolant stream direction.

M36 Wait Pallet Ready

This is used on **Horizontal mills only**. Flashes PART READY button on the front switch box. It delays the pallet change execution until the PART READY button is depressed.

M39 Rotate Tool Turret

The M39 code is used to rotate the tool turret without performing a tool change. The desired tool pocket number (**Tn**) must be programmed previous to the M39.

This M code may be useful to move an empty pocket to face the spindle. This is not normally required but is useful for diagnostic purposes or to recover from a tool changer crash. Remember that the pocket facing the spindle must always be empty for a tool change.

M41 Low Gear Override

The M41 code is used to override the spindle gear implied by the **Snnn** command. With M41, the spindle gear will always be low. If the speed commanded is above the low gear limit, the spindle speed will be the low gear limit. This **M** code does not turn the spindle on or off. If the spindle was turning before this command, it will be started again. If it was stopped before this command it will be left off. M41 is ignored if there is no gear box.

262

-1,11,1,1,5--



M42 High Gear Override

The M42 code is used to override the spindle gear implied by the **Snnn** command. With M42, the spindle gear will always be high. Note that this may reduce the torque at the tool. This **M** code does not turn the spindle on or off. If the spindle was turning before this command, it will be started again. If it was stopped before this command it will be left off. M42 is ignored if there is no gear box.

M50 Execute Pallet Change

Signals the calling program and executes a pallet change sequence.

M51-M58 Set Optional User M

The M51 through M58 codes are optional for user interfaces. They will activate one of relays (see parameter 352) and leave it active. These are the same relays used for M21-M28. Use M61-M68 to turn these off. The RESET key will turn off all of these relays.

See 8M option section for more information on additional user outputs.

M59 Set Output Relay

This M-code directly enables a discrete output relay. The syntax for its usage is M59 Pnn where "nn" specifies the number of the relay being turned ON. An M59 command can be used to turn ON any of the discrete output relays in the range of 1100 and 1155. For example, M59 P1103 does the same thing as #1103=1 except that it is processed as an M code (pro cessed when coming out of the queue instead of going into the queue). To turn off a relay, use M69.

M61-M68 Clear Optional User M

The M61 through M68 codes are optional for user interfaces. They will deactivate one of relays (see parameter 352). These are the same relays used for M21-M28.

M69 Clear Output relay

This M-code directly disables a discrete output relay. The syntax for its usage is M69 Pnn where "nn" specifies the number of the relay being turned OFF. An M69 command can be used to turn OFF any of the discrete output relays in the range of 1100 and 1155. For example, M69 P1103 does the same thing as #1103=0 except that it is processed as an M-code (processed when coming out of the queue instead of going into the queue). To turn on a relay, use M59.

M75 Set G35 or G136 Reference Point

This code is used to set the reference point used for G35 and G136. It must be used after a motion which is terminated with the skip function.

M76 Disable Displays

This code is used to disable the updating of the screen displays. It is not necessary for machine performance.

M77 Enable Displays

This code is used to enable the updating of the screen displays. It is only used when M76 has been used to disable the displays.

M78 Alarm if Skip Signal Found

This code is used to generate an alarm if the previous skip function actually got the skip signal. This is usually used when a skip signal is not expected and may indicate a probe crash. This code can be placed in a block with the skip function or in any subsequent block. The skip functions are G31, G36, and G37.

M79 Alarm if Skip Signal Not Found

This code is used to generate an alarm if the previous skip function did not actually get the skip signal. This is usually done when the absence of the skip signal means a positioning error of a probe. This code can be placed in a block with the skip function or in any subsequent block. The skip functions are G31, G36, and G37.




M80 and M81 Auto Door Open / Close

The M-Codes that control the Auto Door have been changed. The new M-codes are M80 to open and M81 to close the Auto door. Note: Setting 51 DOOR HOLD OVERRIDE must be set to ON, parameter 57 bit 31 DOOR STOP SP must be set to zero and setting 131 AUTO DOOR set to ON, an M80 will cause the door to open and an M81 will cause it to close. Also, the control will beep while the door is in motion.

M82 Tool Unclamp

This code is used to release the tool from the spindle. It is not normally needed as tool change operations do this automatically and a manual TOOL RELEASE button is available to the operator. THIS M CODE IS NOT RECOMMENDED FOR USE AS THE TOOL WILL BE DROPPED FROM THE SPINDLE AND MAY DAMAGE THE TOOL, THE MACHINE, OR YOUR SETUP.

M83 and M84 Air Gun On / Off

An M83 will turn the Air Gun on, and an M84 will turn it off. Additionally, an M83 Pnnn (where nnn is in milliseconds) will turn it on for the specified time, then off automatically. Note: The Air Blast is assigned to discrete output #1138.

M86 Tool Clamp

This code will clamp a tool into the spindle. It is not normally needed as tool change operations do this automatically and a manual TOOL RELEASE button is available to the operator.

M88 Thru Spindle Coolant ON

This code is used to turn on the Through the Spindle Coolant (TSC) option. When M88 is called, the spindle will stop, then the TSC pump will turn on, and the spindle will restart.

M89 Thru Spindle Coolant OFF

This code is used to turn off the Through the Spindle Coolant (TSC) option. When M89 is called, the spindle will stop and the TSC pump will shut off. Turns on purge for the amount of time specified in parameter 237 then turns off purge.

M93 Start Axis Pos Capture and M94 Stop Axis Pos Capture

These M codes permit the control to capture the position of an auxiliary axis when a discrete input goes high. The format is:

M93 Px Qx (where P is the axis number and Q is a discrete input number from 0 to 63) M94

M93 causes the control to watch the discrete input specified by the Q value, and when it goes high, captures the position of the axis specified by the P value. The position is then copied to hidden macro variable 749. M94 stops the capture. M93 and M94 were introduced to support the Horizontal Mill Bar Feeder.

M95 Sleep Mode

Sleep mode is essentially a long dwell. Sleep mode can be used when the user wishes his machine to begin warming itself up early in the morning and be ready for use upon his arrival. The format of the M95 command is:

M95 (hh:mm)

The comment immediately following the M95 must contain the hours and minutes that the machine is to sleep for. For example, if the current time were 6pm and the user wanted the machine to sleep until 6:30am the next morning, the following command would be used:

M95 (12:30)

Up to 99 hours can be specified thus allowing the machine to sleep for over 4 days. If the time is specified using an incorrect format, alarm 324 DELAY TIME RANGE ERROR will be generated. When the machine enters sleep mode and the following message is displayed:

HAAS SLEEP MODE REMAINING TIME nnn MIN.





The message will be re-displayed in a different position on the screen each second so that the user can see at a glance that the machine is sleeping. This has the advantage of preventing the message from being "burned" into one spot on the screen.

When less than one minute of sleep time remains, the message will change to:

REMAINING TIME nn SEC.

If the user presses any key or opens the door, sleep mode will be cancelled and the active program will wait at the block following the M95 until the user presses the Cycle Start key.

For the last 30 seconds of the sleep time, the machine will beep and display an additional message:

WAKE UP IN nn SECONDS

When the sleep time has elapsed and the active program will continue at the block following M95.

M96 Jump If No Input

Ρ

Block to branch to when conditional test succeeds

Q Discrete input to test, 0..31

This code is used to test a discrete input for 0 status. When this block is executed and the input signal specified by Q is 0, a branch to the block specified by P is performed. A Pnnnn code is required and must match a line number within the same program. The Q value must be in the range of 0 to 31. These correspond to the discrete inputs found on the diagnostic display page with the upper left being input 0 and the lower right being 31. Q is not required within the M96 block. The last specified Q will be used. This command stops the lookahead queue until the test is made at runtime. Since the lookahead queue is exhausted, M96 cannot be executed when cutter compensation is invoked. M96 cannot be executed from a main DNC program. If you wish to use M96 in DNC, it must be in a resident subroutine called from the DNC program.

The following is an M96 example:

(TEST INPUT DOOR S, UNTIL CLOSED); (START OF SOME PROGRAM LOOP);
(PROGRAM THAT MACHINES PART)

N85 M21(EXECUTE AN EXTERNAL USER FUNCTION)N90 M96 P10 Q27(LOOP TO N10 IF SPARE INPUT IS 0);N95 M30(IF SPARE INPUT IS 1 THEN END PROGRAM);

M97 Local Sub-Program Call

This code is used to call a subroutine referenced by a line **N** number within the same program. A **Pnnnn** code is required and must match a line number within the same program. This is useful for simple subroutines within a program and does not require the complication of a separate program. The subroutine must still be ended with an M99. An **L** count on the M97 block will repeat the subroutine call that number of times.

M98 Sub Program Call

This code is used to call a subroutine. The **Pnnnn** code is the number of the program being called. The **Pnnnn** code must be in the same block. The program by the same number must already be loaded into memory and it must contain an M99 to return to the main program. An **L** count can be put on the line containing the M98 and will cause the subroutine to be called **L** times before continuing to the next block.





M99 Sub Program Return Or Loop

This code is used to return to the main program from a subroutine or macro. It will also cause the main program to loop back to the beginning without stopping if it is used in other than a subprogram without a **P** code. If an M99 **Pnnnn** is used, it will cause a jump to the line containing **Nnnnn** of the same number.

M99 Pnnnn in the HAAS control varies from that seen in FANUC compatible controls. In FANUC compatible controls M99 Pnnnn will return to the calling program and resume execution at block N specified in Pnnnn. For the HAAS control, M99 will NOT return to the calling program, but instead will jump to block N specified in Pnnnn in the current program.

You can simulate FANUC behavior by using the following code.

calling program	: HAAS O0001	FANUC O0001
	 N50 M98 P2 N51 M99 P100 N100 (continue here) 	 N50 M98 P2 N100 (continue here) M30
subroutine:	M30 O0002 M99	O0002 M99 P100

If you have macros, you can use a global variable and specify a block to jump to by adding #nnn=dddd in the subroutine and then using M99 P#nnn after the subroutine call. There are many ways to jump conditionally after a M99 return when using macros.

M109 INTERACTIVE USER INPUT

This M code allows a G-code program to place a short prompt on the screen, get a single character input from the user and store it in a macro variable. The first 15 characters from the comment following the M109 will be displayed as a prompt in the lower left corner of the screen. A macro variable in the range 500 through 599 must be specified by a P code. Note also that due to the look-ahead feature, it is necessary to include a loop in the program following the M109 to check for a non-zero response before continuing. The program can check for any character that can be entered from the keyboard by comparing with the decimal equivalent of the ASCII character. Here are a few common characters:

A - 65	a - 97	N-78 n-110	1 - 49	-	45
B - 66	b - 98	Y-89 y-121	2 - 50	*	42
C - 67	c - 99	0 - 48 + - 43	3 - 51	1	47

The following sample program will ask the user a Yes or No question then wait for either a Y or an N to be entered. All other characters will be ignored.

N1 #501= 0. (CLEAR THE VARIABLE) M109 P501 (Sleep 1 min?) N5 IF [#501 EQ 0.] GOTO5 (WAIT FOR A KEY) IF [#501 EQ 89.] GOTO10 (Y) IF [#501 EQ 78.] GOTO20 (N) GOTO1 (KEEP CHECKING) N10 (A Y WAS ENTERED) M95 (00:01) GOTO30 N20 (AN N WAS ENTERED) G04 P1. (DO NOTHING FOR 1 SECOND) N30 (STOP) M30

Series Operator's Manual



The following sample program will ask the user to select a number then wait for a 1, 2 or a 3 to be entered. All other characters will be ignored.

O00234 (SAMPLE PROGRAM) N1 #501= 0. (CLEAR THE VARIABLE) M109 P501 (Pick 1, 2 or 3:) N5 IF [#501 EQ 0.] GOTO5 (WAIT FOR A KEY) IF [#501 EQ 49.] GOTO10 (1) IF [#501 EQ 50.] GOTO20 (2) IF [#501 EQ 51.] GOTO30 (3) GOTO1 (KEEP CHECKING) N10 (A 1 WAS ENTERED) M95 (00:01) GOTO30 N20 (A 2 WAS ENTERED) G04 P5. (DO NOTHING FOR 5 SECONDS) N30 (A 3 WAS ENTERED) M30





6. SETTINGS

The setting pages contain values that the user may need to change and that control machine operation. Most settings can be changed by the operator. The settings are preceded by a short description on the left and the value on the right. In general, settings allow the operator or setup person to lock out or turn on specific functions.

The settings are organized into pages of functionally similar groupings. This will make it easier for the user to remember where the settings are located and reduces the amount of time spent maneuvering through the settings display.

Use the vertical cursor keys to move to the desired setting. Depending on the setting, you may change it by entering a new number or, if the setting has specific values, press the horizontal cursor keys to display the choices. Press the WRITE key to enter or change the value. The message near the top of the screen tells you how to change the selected setting.

The serial number is Setting 26 on this page and is protected from user change. If you need to change this setting, contact HAAS or your dealer.

One of the more commonly adjusted settings will be number 34, the "Rotary Axis Diameter". This setting is used to control the surface feed rate when the fourth axis is used in a cutting feed. Feeding with the **X**, **Y**, or **Z** and the **A** axes assumes that the linear motion is along the axis of the rotary motion. When this is true and the diameter setting is correct, the programmed surface feed rate will be correct for helical cuts. In addition, feeds of just the A-axis depend on this setting to determine the correct angular rate.

If you have a fourth axis 5C, fifth axis, or rotary table, it may be disabled from the setting page and removed from the machine. Do not connect or disconnect any cables with the control on. If you do not disable the fourth axis when it is disconnected, you will get an alarm.

Settings may be sent and received with the RS-232 port. See the "Data Input / Output" section for a description of how to do this.

The following is a detailed description of each of the settings:

1 AUTO POWER OFF TIMER

This is a numeric setting. When it is set to a number other than zero, the machine will be automatically turned off after that many minutes of idle operation. This will not occur while a program is running and will not occur while the operator is pressing any keys. The auto off sequence gives the operator a 15 second warning and pressing any key will interrupt the sequence.

2 POWER OFF AT M30

This is an On/Off setting. If it is set to ON, the machine will begin an automatic power down when an M30 ends a program. The auto off sequence gives the operator a 30 second warning and pressing any key will interrupt the sequence.

3 RESERVED

This setting is reserved for future use.

4 GRAPHICS RAPID PATH

This is an On/Off setting. It changes what is displayed in graphics. When it is **off**, the rapid motions do not leave a trail. When it is **on**, rapid motions leave a dashed line on the screen.

5 GRAPHICS DRILL POINT

This is an On/Off setting. It changes what is displayed in graphics. When it is **off**, nothing is added to the graphics display. When it is **on**, any motion in the Z-axis will leave an **X** mark on the screen.







6 FRONT PANEL LOCK

This is an On/Off setting. When it is **off**, the machine operates normally. When it is **on**, the spindle CW and CCW buttons are disabled.

7 PARAMETER LOCK

This is an On/Off setting. When it is **off**, parameters can be changed. When it is **on**, parameter changes are locked out except for parameters 81 through 100. When the control is turned **on**, this setting is set to On.

8 PROG MEMORY LOCK

This is an On/Off setting. When it is **off**, memory can be edited. When it is **on**, memory edit functions are locked out.

9 DIMENSIONING

This is an Inch/Metric setting. When it is set to Inch, the programmed units for **X**, **Y**, and **Z** are inches to 0.0001. When it is set to Metric, programmed units are millimeters to 0.001. Note: Changing this setting will not automatically translate a program already stored in memory. You must change program axis values for the new units. When set to Inch, the Group 6 default G Code is G20. When set to Metric, the default G Code is G21. When this setting is changed from inches to metric, or vice versa, all offset values will be converted accordingly.

	INCH	METRIC
Feed	inches/min.	mm/min.
Max Travel	+/- 15400.0000	+/-39300.000
Min. Programmable Dimension	.0001	.001
Feed Range	.0001 to 300.000 in/min.	.001 to 1000.000

Axis Jog Keys		
.0001 Key	.0001 in/jog click	.001 mm/jog click
.001	.001 in/jog click	.01 mm/jog click
.01	.01 in/jog click	.1 mm/jog click
.1 Key	.1 in/jog click	1 mm/jog click

10 LIMIT RAPID AT 50%

This is an On/Off setting. When it is **off**, the highest rapid speed of 100% is available normally. When it is **on**, the highest rapid rate is limited to 50% of maximum. When you press the 100% button, the display will indicate a 50% rapid override. When this settings is turned **on**, the rapid override will not automatically change from 100% to 50%; you must press the 100% override buttons to get 50%. If the machine is turned on after this setting is turned on, the maximum override will automatically be limited to 50%.

11 BAUD RATE SELECT

This setting allows the operator to change the serial data rate for the first serial port. This applies to program, settings, offsets, and parameters upload and download and to DNC functions.

12 PARITY SELECT

This setting allows the setting of parity for the first serial port. The possible values are: NONE, ODD, EVEN, ZERO. When set to none, no parity bit is added to the serial data. When set to zero, a 0 bit is added in the place of parity. Even and odd work like normal parity functions. Make sure you know what your system needs. XMODEM must use 8 data bits and no parity.

13 STOP BIT

This setting changes the number of stop bits for the first serial port. It can be selected to be 1 or 2.

14



This changes the synchronization protocol between sender and receiver for the first serial port. When set to RTS/CTS, the signal wires in the serial data cable are used to tell the sender to temporarily stop sending data while the receiver catches up. When it is set to XON/XOFF, those ASCII character codes are used by the receiver to tell the sender to temporarily stop. XON/XOFF is the most common setting.

DC CODES is like XON/XOFF but the paper tape punch or reader start/stop codes are sent. XMODEM is a receiver-driven communications protocol that sends data in blocks of 128 bytes. XMODEM gives the RS-232 communication added reliability because each block is checked for integrity. Refer to "Data Input/Output" section for more information. XMODEM must use 8 data bits and no parity.

15 H & T CODE AGREEMENT

This is an On/Off setting. When it is **off**, no special functions occur. When it is set to **on**, a check is made to ensure that the **H** offset code matches the tool presently in the spindle. This check can help to prevent crashes. In program restart this check is not done until motion begins.

16 DRY RUN LOCK OUT

This is an On/Off setting. When it is **off**, the machine operates normally. When it is **on**, the DRY RUN function cannot be turned on.

17 OPT STOP LOCK OUT

This is an On/Off setting. When it is **off**, the machine operates normally. When it is **on**, the OPTIONAL STOP function cannot be turned on.

18 BLOCK DELETE LOCK OUT

This is an On/Off setting. When it is **off**, the machine operates normally. When it is **on**, the BLOCK DELETE function cannot be turned on.

19 FEED RATE OVERRIDE LOCK

This is an On/Off setting. When it is **off**, the machine operates normally. When it is **on**, the feed rate override buttons are locked out.

20 SPINDLE OVERRIDE LOCK

This is an On/Off setting. When it is **off**, the machine operates normally. When it is **on**, the spindle speed override buttons are locked out.

21 RAPID OVERRIDE LOCK

This is an On/Off setting. When it is **off**, the machine operates normally. When it is **on**, the rapid speed override buttons are locked out.

22 CAN CYCLE DELTA Z

This is a decimal numeric entry. It must be in the range of 0.0 to 29.9999 inches. This setting specifies the delta **Z** used in the G73 canned cycle when the Z-axis is moved up to clear chips.

23 9xxx PROGS EDIT LOCK

This is an On/Off setting. When it is **off**, the machine operates normally. When it is **on**, the 9000 series programs (usually macro programs) are invisible to the operator and cannot be uploaded or download. They also cannot be listed, edited, or deleted.

24 LEADER TO PUNCH

This setting is used to control the leader sent to a paper tape punch device connected to the first RS-232 port. The values that can be selected are: NONE, BLANK, or NUL CHAR. None causes no extra data to be sent as a leader. Blank causes two feet of blanks to be punched at the start of a program and one foot of blanks at the end. Null causes the same thing as blanks but uses the ASCII code null which is all zero.

96-8000 rev E

-///45-







25 EOB PATTERN

This setting controls what is sent out and expected as input to represent the EOB (end of block) on serial port one. The possible selections are: CR LF, LF only, CR only, or LF CR CR.

26 SERIAL NUMBER

This is a numeric entry. It is the serial number of your machine. It cannot be changed.

27 G76/G77 SHIFT DIR.

This setting controls the shift direction used to clear a boring tool during a G76 or G77 canned cycle. The possible selections are: X+, X-, Y+, or Y-.

28 CAN CYCLE ACT W/O X/Y

This is an On/Off setting. When it is **off**, an initial canned cycle definition without an **X** or **Y** motion will not cause the canned cycle to be executed. When it is **on**, the initial canned cycle definition will cause one cycle to be executed even if there is no **X** or **Y** motion in that command block. Note that if an L0 is in that block, it will never execute the canned cycle on the definition line.

29 G91 NON-MODAL

This is an On/Off setting. When it is **off**, the machine operates normally. When it is **on**, G91 is not modal and applies only to the command block on which it occurs.

30 4TH AXIS ENABLE

When it is **off**, the fourth axis is disabled and no commands can be sent to that axis. When **off** is not selected, the selected rotary table type parameters are called up. A change to rotary parameters is saved under the selected table type for later recall. In order to change this setting the servos must be turned off.

31 RESET PROGRAM POINTER

This is an On/Off setting. When it is **off**, the RESET button will not change the execution program pointer. When it is **on**, a RESET will change the program execution pointer to the beginning of the program.

32 COOLANT OVERRIDE

This setting controls how the coolant pump operates. The possible selections are: NORMAL, OFF, or IGNORE. The "NORMAL" setting allows the operator to turn the pump on and off manually or with **M** codes. The "OFF" setting will generate an alarm if an attempt is made to turn the coolant on manually or from a program. The "IGNORE" setting will ignore all coolant commands, but the pump can be turned on manually.

33 COORDINATE SYSTEM

This setting changes the way the G92/G52 offset system works. It can be set to FANUC, HAAS, or YASNAC. The Fanuc and HAAS class of controls uses the G52 offset differently than the Yasnac class of controls. In a Fanuc or HAAS control, G52 sets a local coordinate system. In a Yasnac control, the G52 stands on its own as another work offset.

34 4th AXIS DIAMETER

This is a numeric entry. It is used to set the angular feed rate of the **A**-axis. It must be in the range of 0.0 to 29.9999 inches. Since the feed rate specified in a program is always inches per minute (or mm per minute), the control must know the diameter of the part being worked in the **A**-axis in order to compute the angular feed rate. When this setting is set correctly, the surface feed rate on a rotary cut will be exactly the feed rate programmed into the control. The feed rate will be correct only as long as the axis remains orthogonal (at right angles) to all other axes. If the user wishes to program in degrees per minute, this can be done in metric mode and changing this setting to 114.592. A feed rate of F1.0 (1mm/min.) will result in a rotation of 1 degree per minute. The Fanuc convention is to translate 1 inch per minute to 10 degrees per minute. In this case, this setting should be set to 11.459 in.

272 -



This is a numeric entry in the range of 0.0 to 0.9999 inches. It is used to specify the amount of overshoot when unidirectional positioning (G60) is programmed.

36 PROGRAM RESTART

This is an On/Off setting. When it is **off**, starting a program from anywhere other than the beginning may produce inconsistent results. When it is **on**, starting a program from the middle causes the entire program to be scanned to ensure that the correct tools, offsets, **G** codes, and axes positions are set correctly before starting at the block where the cursor is positioned. Some alarm conditions are not detected prior to motion starting.

Note:	The following M codes will be processed when setting 36 PROGRAM					
	M08 Coolant On	M41	Low Gear Override			
	M09 Coolant Off	M42	High Gear Override			
	M10 Engage 4th Axis Brake	M51-M58	Set Optional User			
	M11 Release 4th Axis Brake	M61-M68	Clear Optional User M			
	M12 Engage 5th Axis Brake	M83	Air Gun On			
	M13 Release 5th Axis Brake	M84	Air Gun Off			
	M34 Increment Coolant Spigot Position	M88	Through the Spindle			
	M35 Decrement Coolant Spigot Position	ı	Coolant ON			
		M89	Through the Spindle Coolant OFF			

37 RS-232 DATA BITS

This setting can be selected to be either 7 or 8. It is used to change the number of data bits for serial port one. Normally, seven data bits should be used. Some computers require eight. Note that parity is added to this count. XMODEM must use 8 data bits and no parity.

38 AUX AXIS NUMBER

This is a numeric entry between 0 and 4. It is used to select the number of external auxiliary axes added to the system. If it is set to 0, there are no auxiliary axes. If it is set to 1, there is a C-axis. If it is set to 2, there are C and U axes.

39 BEEP AT M30

This is an On/Off setting. When it is **off**, nothing is changed. When it is **on**, a program ending in an M30 will cause the keyboard beeper to sound until another keyboard key is pressed.

40 TOOL OFFSET MEASURE

This setting selects how tool size is specified for cutter compensation. It can be set to either Radius or Diameter. The value in the tool offset tables is used differently depending on this setting. In addition, the label on the offsets page changes to indicate how offsets should be entered.

41 ADD SPACES RS232 OUT

This is an On/Off setting. When it is **off**, programs sent out the serial port have no spaces and are difficult to read. When it is **on**, spaces are added between address codes when a program is sent out RS-232 serial port one. This can make program much easier to read.

42 M00 AFTER TOOL CHANGE

This is an On/Off setting. When it is **off**, tool changes occur normally. When it is **on**, a program stop will occur after a tool change and M00 AFTER TOOL CHANGE is displayed as a message at the bottom left. This affects only programmed tool changes.





43 CUTTER COMP TYPE

This setting controls how an entry to cutter compensation occurs. It can be selected to be A or B. It affects only the first stroke that begins cutter compensation and changes the way the tool is cleared from the part being cut.

44 MIN F IN RADIUS CC %

This setting is a numeric entry between 1 and 100. It affects the feed rate when cutter compensation moves the tool towards the inside of a circular cut. In order to maintain a constant surface feed rate, such a cut will be slowed down. This setting specifies the minimum feed rate as a percentage of the programmed feed rate.

45 MIRROR IMAGE X-AXIS

46 MIRROR IMAGE Y-AXIS

47 MIRROR IMAGE Z-AXIS

48 MIRROR IMAGE A-AXIS

These are On/Off settings. When it is **off**, axes motions occur normally. When it is **on**, the specific axis motion is mirrored (or reversed) around the work zero point.

49 SKIP SAME TOOL CHANGE

This is an On/Off setting. When it is **off**, an M16 will always cause a tool change sequence to occur; even if the same tool is put back into the spindle. When it is **on**, a tool change to the same tool as is in the spindle will cause no action.

50 AUX AXIS SYNC

This changes the synchronization protocol between sender and receiver for the second serial port. When set to RTS/CTS, the signal wires in the serial data cable are used to tell the sender to temporarily stop sending data while the receiver catches up. When it is set to XON/XOFF, those ASCII character codes are used by the receiver to tell the sender to temporarily stop. XON/XOFF is the most common setting. Make sure that the Haas servo control is set to the same condition.

DC CODES is like XON/XOFF but the paper tape punch or reader start/stop codes are sent. XMODEM is a receiver-driven communications protocol that sends data in blocks of 128 bytes. XMODEM gives the RS-232 communication added reliability because each block is checked for integrity. Refer to "Data Input/Output" section for more information.

51 SAFETY SWITCH OVERRIDE

This is an On/Off setting. When it is **off**, a program cannot be started when the doors are open and opening the doors will cause a running program to stop just like in FEED HOLD. When it is **on**, and Parameter 57 bits DOOR STOP SP and SAFETY CIRC are set to zero, the door condition is ignored. When the control is turned on, this setting is set to Off.

52 G83 RETRACT ABOVE R

This is a numeric entry in the range of 0.0 to 9.9999 inches. This setting changes the way G83 and G73 works when it returns to the **R** plane. Most programmers set the **R** plane well above the cut to ensure that the chip clear motion actually allows the chips to get out of the hole but this causes a wasted motion when first drilling through this "empty" space. If Setting 52 is set to the distance required to clear chips, the **R** plane can be put much closer to the part being drilled. When the clear move to **R** occurs, the **Z** will be moved above **R** by this setting.

53 JOG W/O ZERO RETURN

This is an On/Off setting. When it is **off**, jogging of an axis is inhibited until the zero return operation is completed. When it is **ON**, jogging of an axis is allowed prior to the zero return. The **ON** condition can be dangerous in that an axis can be run into the stops, however, the maximum speed allowed is one inch per minute or 0.0010 inches per handle increment. When the control is turned **on**, this setting is set to **OFF**.



54 AUX AXIS BAUD RATE

This setting allows the operator to change the serial data rate for the second serial port. This applies to the interface with the optional C, U, V, and W axes. The possible values include: 50, 110, 200, 300, 600, 1200, 2400, 4800, 7200, 9600, 19200, 38400. Note that 4800 is standard in Haas servo controls and this should be set to the same value.

55 ENABLE DNC FROM MDI

This is an On/Off setting. When it is **off**, DNC cannot be selected. When it is turned **on**, DNC is selected by pressing MDI while already in MDI. The DNC option must be enabled in the control.

56 M30 RESTORE DEFAULT G

This is an On/Off setting. When it is **off**, no change to the modal **G** codes occurs at the end of a program (normally M30). When it is **on**, an M30 will reset all of the modal **G** codes to their defaults. If this setting is **on**, RESET will also reset defaults.

57 EXACT STOP CANNED X-Y

This is an On/Off setting. When it is **off**, the rapid X-Y motion associated with a canned cycle may not get exact stop; according to other conditions. When it is **on**, the X-Y motion always gets exact stop. This will make canned cycles slower but less likely to run into a close tolerance fixture.

58 CUTTER COMPENSATION

This setting controls the type of cutter compensation used in the control. The types are similar to the method of cutter compensation available in other classes of controls.

59 PROBE OFFSET X+

60 PROBE OFFSET X-

61 PROBE OFFSET Y+

62 PROBE OFFSET Y-

Settings 59 through 62 are used to define the displacement and size of the spindle probe. These numbers only apply to the probing option. These four numbers specify the travel distance in four directions from where the probe is triggered to where the actual sensed surface is located. They are used by G31, G36, G136, and M75. They can be both positive and negative numbers. If the probe width were 0.23 inches in diameter and the probe was set exactly at the center of the spindle, these four settings would all be 0.115 inches.

63 TOOL PROBE WIDTH

This setting is used to specify the width of the probe that is used to test tool diameter. This setting only applies to the probing option. It is used by G35.

64 T. OFS MEAS USES WORK

This is an on/off setting. It changes the way the TOOL OFSET MESUR button works. When this is ON, the entered tool offset will be relative to the currently selected work coordinate Z offset. When it is OFF, the tool offset equals the Z machine position.

65 GRAPH SCALE (HEIGHT)

This setting specifies the height of the work area that is displayed on the graphics screen. The maximum size is automatically limited to default height. The default shows the machine's entire work area. A specific scale can be set by using the following formula. The default of the setting is the total Y travel.

Total Y travel = Parameter 20 / Parameter 19 (16.25 VF-0 through VF-2) Scale = Total Y travel / Setting 65





66 GRAPHICS X OFFSET

This setting locates the right side of the scaling window relative to the machine X zero position, (See "Displays" section). Its default is zero.

67 GRAPHICS Y OFFSET

This setting locates the top of the scaling window relative to the machine Y zero position, (See "Displays" section). Its default is zero.

68 GRAPHICS Z OFFSET

Reserved for future use.

69 DPRNT LEADING SPACES

This is an on/off setting. It suppresses leading spaces that are generated by a macro DPRNT format statement. In a DPRNT statement the format specifies the number of characters printed to the serial port for the whole portion of a variable. If the number is smaller than the space allowed for, then leading spaces are sent to the serial port. When this setting is OFF, then no leading spaces are generated. The following example illustrates control behavior when this setting is OFF or ON.

#1= 3.0 ; G0 G90 X#1 ; DPRNT[X#1[44]] ; Setting 69: OFF ON OUTPUT: X3.0000 X 3.0000

The default value is OFF.

70 DPRNT OPEN/CLOS DCODE

This is an on/off setting. It controls whether the POPEN and PCLOS statements in macros send DC control codes to the serial port. When the setting is ON, these statements will send DC control codes. When it is OFF, the control codes are suppressed. Its default value is ON.

71 DEFAULT G51 SCALING

Specifies the scaling for a G51 command when the P address is not contained in the same block. It must be in the range of .001 to 8380.000. This settings default is 1.000.

72 DEFAULT G68 ROTATION

Specifies the rotation, in degrees, for a G68 command when the R address is not contained in the same block. It must be in the range of 0.0000 to 360.0000. This settings default is 0.0000.

73 G68 INCREMENTAL ANGLE

This is an on/off setting. It is a switch that allows the internal variable that controls rotation to be incremented for each call to a G68 command. When this switch is ON, and a G68 command is executed in the incremental mode (G91), then the value specified in the R address is added to the internal variable. Otherwise, the internal variable is set to the rotation value specified by R. The default setting is OFF.

74 9xxxx PROGS TRACE

This setting, along with Setting 75, is useful for debugging CNC programs. When Setting 74 is set to ON, the control will display all blocks that are executed in programs that have an **O** number of 9000 or above. When the setting is OFF, the control will not display 9000 series blocks. The default setting is ON.

75 9xxx PROGS SINGLE BLK

When Setting 75 is set to ON and the control is operating in SINGLE BLOCK mode, then the control will stop at each block in a 9000 series program and wait for the operator to press CYCLE START. When Setting 75 is set to OFF, then all blocks in a 9000 series program are executed in a continuous manner even if SINGLE BLOCK is ON. The default setting is ON.

When Setting 74 and Setting 75 are both ON, the control acts normally. That is, all blocks executed are highlighted and displayed and when in single block mode there is a pause before each block is executed.

When Setting 74 and Setting 75 are both OFF, the control will execute 9000 series subroutines without displaying the blocks contained in that subroutine If the control is in single block mode, no single block pause will occur within a 9000 series subroutine.

When Setting 75 is ON and Setting 74 is OFF, then 9000 series subroutines will be displayed as they are executed.

76 TOOL RELEASE LOCK OUT

When this setting is set to ON, the tool release key is disabled. The default setting is OFF.

77 SCALE INTEGER F

This setting aids those wishing to run programs developed on a control other than HAAS. It allows the operator to select how the control interprets an F address code that does not contain a decimal point, (It is recommended that the programmer always use a decimal point). The setting can be set to the following values:

-	F12	F12 is interpreted as			.0012 units/minute.			
-	"	"	"	12.0	"	"		
-	"	"	1.2	"	"			
-	"	"	.12	"	"			
	-	"	"	.012	"	"		
	-	"	"	.0012	"	"		
	- - -	- F12 - " - " - "	- F12 is interpl - " " - " " - " " - " "	- F12 is interpreted as - " " 1.2 - " 1.2 - " .12 - " "	 F12 is interpreted as .0012 u " " 12.0 " " 1.2 " " " .12 " " " .012 " " .0012 	- F12 is interpreted as .0012 units/r - """12.0" - ""1.2""" - "".12"" - "".012" - "".0012"		

The default setting is DEFAULT.

78 FIFTH-AXIS ENABLE

When this setting is **off**, the fifth axis is disabled and no commands can be sent to that axis. When **off** is not selected, the selected rotary table type parameters are called up. A change to rotary parameters is saved under the selected table type for later recall. In order to change this setting the servos must be turned off.

79 FIFTH-AXIS DIAMETER

This is a numeric entry. It is used to set the angular feed rate of the **B**-axis. It must be in the range of 0.0 to 50 inches. Since the feed rate specified in a program is always inches per minute (or mm per minute), the control must know the diameter of the part being worked in the **B**-axis in order to compute the angular feed rate. When this setting is set correctly, the surface feed rate on a rotary cut will be exactly the feed rate programmed into the control. The feed rate will be correct only as long as the axis remains orthogonal (at right angles) to all other axes.

80 MIRROR IMAGE B-AXIS

This is an On/Off setting. When it is off, axes motions occur normally. When it is on, the **B** axis motion is mirrored (or reversed) around the work zero point.

81 TOOL AT POWER DOWN

When the POWER UP key is pressed, the control will change to the tool specified in this setting. If zero (**0**) is specified, no tool change occurs at power up. **1** is the default.

82 LANGUAGE

This setting allows the user to change between available languages. If the language selected does not reside in the control, NOT AVAILABLE will be displayed in the message area when that language is selected.





83 M30 /RESETS OVERRIDES

When on, an M30 causes feed rate override, rapid override, and spindle override to be reset to default values.

84 TOOL OVERLOAD ACTION

Causes the specified action to occur anytime a tool becomes overloaded (ALARM, FEEDHOLD, BEEP, AUTOFEED). When set to FEEDHOLD, the message "Tool Overload" will be displayed whenever this condition occurs. Pressing any key will clear the message. When set to AUTOFEED, the mill automatically limits the feed rate based on the tool load (see tool load monitor display).

NOTES: When tapping (rigid and floating), the feed and spindle overrides will be locked out, so the AUTOFEED feature will be ineffective (although the display will appear to respond to the override buttons.)

The AUTOFEED feature should not be used when doing thread milling or using autoreversing tapping head as it may cause unpredictable results or even a crash.

The last commanded feed rate will be restored at the end of the program execution, or when the operator presses RESET or turns off the AUTOFEED feature.

The operator may use the feed rate override buttons while the AUTOFEED feature is active. As long as tool load limit is not exceeded, these buttons will have the expected effect and the overridden feed rate will be recognized as the new commanded feed rate by the AUTOFEED feature. However, if the tool load limit has already been exceeded, the control will ignore the feed rate override buttons and the commanded feed rate will remain unchanged.

85 MAX CORNER ROUNDING

Defines the accuracy of corners within a selected tolerance. Initial default value is set to .05 inch. If this setting is zero, the control acts as if exact stop is commanded on each motion block. Parameter 134 is used as a floor so the machine will not slow down to extremely slow speeds. Alternatively, a G187 can be used in the program to alter the effective value of Setting 85 without permanently changing that setting. This method likewise takes advantage of the floor, but does not require that the machine be rebooted. The amount of slow down that occurs depends on how one stroke blends with the next.



Setting 85 Examples

86 M39 LOCKOUT

This is an on/off setting. Locks out the rotation of the tool changer.



87 M06 RESETS OVERRIDE

This is an on/off setting. When M06 is executed and this setting is on, any overrides are canceled and set to their programmed values.

88 RESET RESETS OVERRIDES

When the reset key is pressed and this is on, any overrides are cancelled and set to their programmed values.

100 SCREEN SAVER DELAY

This feature is intended to activate when the machine is idle or unattended to prevent the monitor screen from becoming etched (burned-in) after displaying the same information for many hours. When the setting is zero, the machine behaves normally. If it is set to some number of minutes, then after that amount of time with no key presses, no jog handle motion and no alarms, the screen saver will be activated. It will be deactivated by any key press, jog handle motion or alarm. Note that the screen saver will not activate if the control is in Sleep Mode, in Jog mode, Edit Mode, MEM or MDI Mode with the PRGRM screen displayed, Graphics Mode or on any of the editor screens. When it is active, the words SCREEN SAVER will be displayed in random places on an otherwise blank screen and will be changed every two seconds.

101 FEED OVERIDE -> RAPID

When this setting is OFF, the machine will behave normally. When it is ON and HANDLE CONTROL FEED RATE is pressed, the jog handle will affect both the feed rate override and the rapid rate override simultaneously. That is, changing the feed rate override will cause a proportional change to the rapid rate. The maximum rapid rate will be maintained at 100% or 50% according to setting 10.

103 CYC START/FH SAME KEY

This is an ON/OFF setting. When it is OFF, the machine operates normally. When it is ON, CYCLE START must be pressed and held to run a program. When CYCLE START is released, a FEED HOLD is generated.

This setting cannot be ON while Setting 104 is ON. When one of them is set to ON, the other will automatically turn OFF. This setting can be changed while running a program.

104 JOG HANDL TO SNGL BLK

This is an ON/OFF setting. When it is OFF, the machine operates normally. When it is ON, and SINGLE BLOCK is selected, the jog handle can be used to single step through a program.

Reversing the jog handle direction will generate a FEED HOLD. This can be useful when an unexpected long motion block is encountered.

CYCLE START must be used to begin running a program.

This setting cannot be ON while Setting 103 is ON. When one of them is set to ON, the other will automatically turn OFF. This setting can be changed while running a program.

108 QUICK ROTARY G28

This is an ON/OFF setting. When it is ON, the G28 command will return a rotary axis only back to zero when it has been commanded to greater than 360 degrees. For example, if a rotary axis has been commanded 361 degrees, and this setting is on, a G28 command will move it back only one degree instead of "unwinding" it all 361 degrees. Note that other G codes, such as G00 and G01, are unaffected by this setting.

109 WARM-UP TIME IN MIN.

This is the number of minutes (maximum= 300 minutes from the time the machine is powered on) to apply the compensation. If it is set to zero no compensation will be applied.





110 WARMUP X DISTANCE

111 WARMUP Y DISTANCE

112 WARMUP Z DISTANCE

Setting 110,111 and 112 specify the amount of compensation (maximum=+/- .0020" or +/-.051mm) applied to the X, Y and Z axis respectively. No compensation is applied if the setting is zero.

114 CONVEYOR CYCLE TIME (MINUTES)

115 CONVEYOR ON-TIME (MINUTES)

The above two settings control the intermittent chip conveyor function. If setting 114 is zero, the chip conveyor will behave normally. If it is set to some number of minutes, the chip conveyor will automatically turn itself off after the number of minutes specified by setting 115, then turn itself back on later.

Setting 114 controls how often the cycle is to be repeated, that is, if setting 114 is set to 30 and setting 115 is set to 2, the chip conveyor will turn itself on every half hour, run for two minutes, then turn itself off. On-time should be set no greater than 80% of cycle time.

NOTE: The CHIP FWD button (or M31) will start the conveyor in the forward direction and activate the cycle.

NOTE: The CHIP REV button (or M32) will start the conveyor in the reverse direction and activate the cycle.

NOTES: The CHIP STOP button (or M33) will stop the conveyor and cancel the cycle. If Parameter 209 CNVY DR OVRD bit 16 is set to 0 and the chip conveyor is cycling, opening the door will cause the conveyor to stop and suspend cycling. When the door is closed, the cycle will resume.

If Parameter 209 CNVY DR OVRD is set to 1 and the chip conveyor is cycling, the conveyor will continue to run when the door is open but will stop at the end of the cycle and cancel the cycle. When the door is closed, the cycle will resume.

Under no circumstances will the chip conveyor automatically start running when the door is open.

116 PIVOT LENGTH only changeable in DEBUG mode

This is to prevent accidental loss of the setting value. Setting 116 is intended to be set once when the machine is first built, then never changed unless the machine is physically altered. A setting file can be loaded from disk or RS-232 and the values of all settings will be replaced. However, now, if the control is not in DEBUG mode at the time, and the value of setting 116 is to be changed, all setting except 116 will be changed and alarm 202 SETTING CRC ERROR will be generated.

117 G143 GLOBAL OFFSET

This setting is provided for customers who have several 5-axes mills and want to transfer the programs and tools from one to another. The user can enter the pivot length difference into this setting, and it will be applied to the G143 tool length compensation.

118 M99 BUMPS M30 CNTRS

When this setting is turned ON, an M99 will increment the M30 counters that are visible by pressing CURNT COMNDS and PAGE DOWN twice. Note that an M99 will only increment the counters in loop mode in a main program, not a sub program. An M99 used as a subprogram return or used with a P value to jump to another part of the program will not increment the M30 counters.

Operator's Manual



119 OFFSET LOCK

This is an ON / OFF setting. When it is OFF, no special functions occur. When it is ON, the user is prevented from altering any of the offsets. However, programs which alter offsets will still be able to do so.

120 MACRO VAR LOCK

This is an ON / OFF setting. When it is OFF, no special functions occur. When it is ON, the user is prevented from altering any of the macro variables. However, programs which alter macro variables will still be able to do so.

121 APC PAL. ONE LOAD X

This is intended for use future pallet changer software that replaces the macro program. This is the APC pallet #1 X axis load position. It should be set at the time the APC is installed. Units are inch/mm.

122 APC PAL. ONE LOAD Y

This is intended for use future pallet changer software that replaces the macro program. This is the APC pallet #1 Y axis load position. It should be set at the time the APC is installed. Units are inch/mm.

123 APC PAL. ONE UNLOAD X

This is intended for use future pallet changer software that replaces the macro program. This is the APC pallet #1 X axis unload position. It should be set at the time the APC is installed. Units are inch/mm.

124 APC PAL. ONE UNLOAD Y

This is intended for use future pallet changer software that replaces the macro program. This is the APC pallet #1 Y axis unload position. It should be set at the time the APC is installed. Units are inch/mm.

125 APC PAL. TWO LOAD X

This is intended for use future pallet changer software that replaces the macro program. This is the APC pallet #2 X axis load position. It should be set at the time the APC is installed. Units are inch/mm.

126 APC PAL. TWO LOAD Y

This is intended for use future pallet changer software that replaces the macro program. This is the APC pallet #2 Y axis load position. It should be set at the time the APC is installed. Units are inch/mm.

127 APC PAL. TWO UNLOAD X

This is intended for use future pallet changer software that replaces the macro program. This is the APC pallet #2 X axis unload position. It should be set at the time the APC is installed. Units are inch/mm.

128 APC PAL. TWO UNLOAD Y

This is intended for use future pallet changer software that replaces the macro program. This is the APC pallet #2 Y axis unload position. It should be set at the time the APC is installed. Units are inch/mm.

129 APC PAL. SAFE X POS

This is intended for use future pallet changer software that replaces the macro program. This is the receiver X axis position where it is safe to open the door. It should be set at the time the APC is installed. Units are inch/ mm.

130 RIGID-TAP RETRACT MULT

This setting augments the quick-reverse-out of a G84 rigid-tapped hole. If it is set to 0 or 1, the machine behaves normally. If it is set to 2, it will be the equivalent of running a G84 with a J-code of 2. That is, the spindle will retract twice as fast as it went in. If this setting is set to 3, it will retract three times as fast. Note that specifying a J-code for a rigid-tap will override setting 130.

-/////5-



131 AUTO DOOR

This is a new setting that supports the Auto-Door feature. It should be set to ON when the automatic door hardware is installed and the operator wants it to function. Otherwise it should be set to OFF. When it is set to ON, the following need to be verified:

Setting 51 DOOR HOLD OVERRIDE is set to ON Parameter 57 SAFETY CIRC is set to zero

Parameters 292, 293 and 251 are set appropriately, (see their definitions in the following parameter section) The door will close when cycle start is pressed and will open when the program has reached an M00, M01 (with OPT STOP turned ON) or M30 and the spindle has stopped turning. Note that if any of the aforementioned parameters and settings are set incorrectly, the Auto Door feature will not function.

133 NETWORK/ZIP OFF/ON

This is an ON/OFF setting that is used to activate the internal Zip/Enet PC104 board at power-on time. When it is set to OFF, the CNC will not access the board. When it is set to ON, the CNC will access it at power-on time and display the message "LOADING" on the Zip/Enet settings page just below setting 139. After some time (2 minutes maximum,) the control will instead display the message "DISK DONE" indicating that communications have been established with the internal PC104 board and the user can now use the control.

134 CONNECTION TYPE

This setting can be FLOPPY, NET, or ZIP. When it is set to FLOPPY, program loading and saving will be performed in the usual way via the floppy disk drive installed in the control. When it is set to NET, program loading and saving will be performed via the user-supplied network connection (provided that connection was successfully established at power-on time.) When it is set to ZIP, program loading and saving will be performed via the user-supplied is connected.) When setting 133 is set to ON, the value of this setting will appear on the LISTPROG screen as follows: F4 DIR-FLOPPY, F4 DIR-NET, or F4 DIR-ZIP,

135 NETWORK TYPE

This setting can be NONE, NOVELL, NT/IPX, or NT/TCP and specifies the user-supplied network connection type. When it is set to NONE, only a floppy disk or a user-supplied Zip drive is accessible.

136 SERVER

This setting is used to contain the user-supplied server name (up to 8 characters long.) If this setting is not to be used, the user should enter a semicolon (EOB.)

137 USERNAME

This setting is used to contain the user-specified account name (up to 8 characters long.) If this setting is not to be used, the user should enter a semicolon (EOB.)

138 PASSWORD

This setting is used to contain the user-specified password (up to 8 characters long.) If this setting is not to be used, the user should enter a semicolon (EOB.)

139 PATH

This setting is used to contain the user-specified Novell-Path or NT Root Directory name depending on the network server used (up to 18 characters long.) For a Novell network, this is the user's path name, for example: U:\USERS\JOHNDOE. For a Microsoft network, this is the root directory\desired directory name, for example: USERS\JOHNDOE. If this setting is not to be used, the user should enter a semicolon (EOB.)

140 TCP ADDR

This setting is used only for TCP networks and contains the static user-specified TCP/IP address in the server domain (up to 15 characters long.) For example: 192.168.1.2. If this setting is not to be used, the user should enter a semicolon (EOB.)

141





This setting is used only for TCP networks and contains the user-specified subnet mask (up to 15 characters long.) For example: 255.255.255.0. If this setting is not to be used, the user should enter a semicolon (EOB.)

142 OFFSET CHNG TOLERANCE

This is a new setting to generate a warning message if an offset is changed more than the specified amount. It is intended to help prevent operator errors. The user can set it to any number from 0 to 99.9999. When the setting contains zero, the feature is inactive and the control behaves as before. When it contains a non-zero number and an attempt is made to change an offset by more that this amount (either positive of negative) the following prompt is displayed:

xx changes the offset by more than Setting 142! Accept (Y/N)? If "Y" is entered, the control updates the offset as usual, otherwise, the change is rejected.

143 MACHINE DATA COLLECT

This is a new feature that enables the user to extract data from the control using a Q command sent via the RS-232 port. Note that the control will only respond to a Q command when this setting is ON. The following output format is used:

<STX> <CSV response> <ETB> <CR/LF> <0x3E>

Note: STX = 0x02 (ctrl-B), ETB = 0x17 (ctrl-W) The following commands can be used:

Q100 - Machine Serial Number Q101 - Control Software Version Q102 - Machine Model Number Q104 - Mode (LIST PROG, MDI, MEM, JOG, etc.) Q200 - Tool Changes (total) Q201 - Tool Number in use Q300 - Power-on Time (total) Q301 - Motion Time (total) Q303 - Last Cycle Time Q304 - Previous Cycle Time Q400 - not currently used Q401 - not currently used Q402 - M30 Parts Counter #1 (resettable at control) Q403 - M30 Parts Counter #2 (resettable at control) Q500 - Three-in-one (PROGRAM,Oxxxxx,STATUS,PARTS,xxxxx)

If the control is busy, the control will output «STATUS, BUSY». If a request is not recognized, the control will output «UNKNOWN».





143 MACHINE DATA COLLECT

This setting enables the user to extract data from the control using a Q command sent via the RS-232 port. Note that the control will only respond to a Q command when this setting is ON. The following output format is used: STX> <CSV response> <ETB> <CR/LF> <0x3E>

Note: STX = 0x02 (ctrl-B), ETB = 0x17 (ctrl-W)

The following commands can be used:

- Q100 Machine Serial Number
- Q101 Control Software Version
- Q102 Machine Model Number
- Q104 Mode (LIST PROG, MDI, MEM, JOG, etc.)
- Q200 Tool Changes (total)
- Q201 Tool Number in use
- Q300 Power-on Time (total)
- Q301 Motion Time (total)
- Q303 Last Cycle Time
- Q304 Previous Cycle Time
- Q400 not currently used
- Q401 not currently used
- Q402 M30 Parts Counter #1 (resettable at control)
- Q403 M30 Parts Counter #2 (resettable at control)
- Q500 Three-in-one (PROGRAM, Oxxxxx, STATUS, PARTS, xxxxx)
- If the control is busy, the control will output "STATUS, BUSY"

If a request is not recognized, the control will output "UNKNOWN".

144 FEED OVERIDE->SPINDLE

This feature is intended to keep the chip load constant when an override is applied. When this setting is OFF, the control behaves normally. When it is ON, any feed rate override that is applied will be applied to the spindle speed also, and the spindle overrides will be disabled.