

# How To: Perfect Clamp Placement

Making a spring-loaded marker adds the ability to draw features on your parts.

Here's what you'll need:

- (1) Permanent Marker
- (1) ½" PVC, cut to 3" (~\$2.03 for 10')
- (1) ½" PVC CAP, Female Pipe Thread (~\$0.61)
- (1) ½" PVC Male Adapter SXMPT (~\$0.26)
- (1) Bag of Store Balloons (~\$1.00)

Approximate total build cost: \$3.90

