







Installed Dimensions





Leveling Pad Height




*All Height Dimensions Based on Suggested Leveling Pad Height

*ADD 4in for Extended Z-Clearance

Shipping Dimensions



Air & Power



Maintain 3 feet [915mm] clearance to the nearest obstruction around all sides of machine perimeter for maintenance access

Note:

Machine must be placed on one continuous concrete slab. Slab should extend 12in [305mm] beyond anchor holes in all directions

Anchor Pattern


Anchor Hole Detail

Ø 5/8in[15.9mm]

▽ 2.0in[50mm]-


▽ 2.5in[66mm]

NOT AVAILABLE FOR THIS MACHINE







Height Breakdown




Width Breakdown




X&Y-Axis Travel and Clearance



Z-AXIS TRAVEL & CLEARANCE



All dimensions based on stackup of sheetmetal, subject to variation of 1/2" (13 mm) Due to continual product improvements, dimensions are subject to change without notice



Tool Changer

